Application of Linux Single Board Computers to Amateur Radio

Willem A Schreüder AC0KQ willem@prinmath.com

RMHAM University October 15, 2016

http://www.prinmath.com/ham/talks/ http://www.rmham.org/wordpress/course-syllabus

Talk Outline

- Why Linux SBCs
- Installing and Configuring the OS
- BPQ Packet/RMS Gateway/APRS iGate
- AllStarLink Repeater
- Control and Monitoring
- SDR
- Questions and Pizza
- Don't freak out over the number of slides. Most of them take 10 seconds to cover.

Single Board Computers

- Full Linux boxes (today's topic)
 - Raspberry Pi
 - Beaglebone
- Microcontrollers (not covered)
 - Arduino
 - PICAXE
 - BASIC Stamp

Why Linux SBCs?

- Runs a full Linux OS
- Usable stand alone computer or server
- Built in connectivity
 - Ethernet networking
 - USB and serial
 - General purpose IO
- Low power (5V 1A)
- Expandable using daughter boards
- Inexpensive (\$50 for a working system)

SBC Pros and Cons

Pros

- Inexpensive
- No moving parts
- 5V power
- Expandable
- Cons
 - SD cards corrupted by bad power
 - SD card is not a great hard disk

Raspberry Pi

- Most Popular
- Best supported
- rPi3 most powerful
- Lots of USB ports
- Lots of daughterboards
- No analog inputs
- \$35 plus SD card



Raspberry Pi models

- Raspberry Pi
 - A/A+700 MHz CPU & 256MB SDRAM, 1xUSB
 - B 700 MHz CPU & 512MB SDRAM, 2xUSB, Ethernet
 - B+ 700 MHz CPU & 512MB SDRAM, 4xUSB, Ethernet
 - 2B 900 MHz Quad A7 & 1GB SDRAM, 4xUSB, Ethernet
 - 3B 1.2GHz Quad 64bit & 1GB SDRAM, 4xUSB, Ethernet
- Compute Module
 - 700MHz CPU & 512MB SDRAM
- Zero
 - 1GHz CPU & 512MB SDRAM

Raspberry Pi 2B



Beagle Bone

- Less well supported
- Onboard eMMC
- Power & Reset buttons
- More GPIO pins
- 8 analog inputs
- \$50 street price



Beaglebone Models

- White
 - Original 720 MHz A8
- Black
 - Most Popular 1GHz A8
- Green
 - Same CPU as Black
 - No barrel power, two Grove connectors
- Industrial
 - Black with extended temperature range

Beagle Bone Black



Other Linux SBCs

- Examples
 - Intel Edison
 - VoCore
 - Odroid
- Less well supported
- Fewer peripherals
- Sometimes better performance
- Mostly higher priced

Power and Storage

- Runs on 5V DC
 - Needs clean power
 - Draws 0.5-1.0 A without daughter boards
- Micro SD card storage
 - Finite life
 - Marginal performance
 - Bad power kills SD

Must Have Accessories

- Micro SD card
 - Faster is better
 - Class 10
 - UHS 1
 - UHS 3
 - At least 4GB
 - 16GB is ample
- Real time clock
 - PiFace Shim RTC
 - Adafruit DS1307
 - Needed if no network (NTP)





Nice to have

Official Raspberry 7" Touchscreen



Power Control

- Andice Labs
 Powercape
- Adafruit
 Powerboost
 1000C
- Charges and boosts 4V from LIPO battery





TNC-X/Pi/Black

- Designed by John Hansen W2FS
- Based on PIC Microcontroller
- MX614 Bell 202 modem chip
- KISS interface
 - Serial
 - USB
 - **I2C**



Why the **BB/TNC-Black?**

- BBB has 5 serial ports
- Mechanically stable stacked capes
- Powercape battery backup
- Lots of pins for site monitoring
- 50% more expensive



Part 1a Getting Started on the Raspberry Pi

rPi Materials

- Raspberry Pi 2B or 3B
- Micro SD card
- 5V 1A power supply
- USB A to micro USB B cable
- Ethernet cable
- Direct connection
 - Monitor or TV
 - HDMI cable
 - USB keyboard and mouse

Raspberry OS Choices

- https://www.raspberrypi.org/downloads/
- Debian derivatives are most popular
 - Raspbian (Official Supported OS)
 - Alternatives are
 - NOOBS (New Out Of the Box Software)
 - Ubuntu Mate (Ubuntu Desktop)
 - Windows 10 IOT (a.k.a. YGBSM)
 - several others, some not Linux based
- Debian 8 (Jessie) adopts systemd
 - This changes how system programs are run
 - No more /etc/init.d/XXX and /etc/inittab
 - Control programs with systemctl

Burning the Image

- Unzip image
 - 2016-09-23-raspbian-jesse.img
- Linux or OSX command line
 - dd if=2016-09-23-raspbian-jesse.img of=/dev/mmcblk0
 - sync;sync
- Windows
 - Download Win32DiskImager
 - Select image file name
 - Select SD card drive letter
 - Click Write

First boot with Pixel



Raspberry > Preferences > Raspberry Pi Configuration

🖲 🕕 🔁 💌	🔅 🔇 🔁 [pi@	@raspberry.	👹 Raspl	oerry Pi	* 1 l •	(1)) 3 %	21:23 🛕
	F	Raspberry F	Pi Configurati	on	_ = ×		
Wasteluniost	System Int	erfaces	Performance	Localisatio	on	200	
	Filesystem:			Expand File	system	-	-
	Password:			Change Pas	sword	-	-
	Hostname:		raspberrypi			-	
	Boot:		• To Desk	top 🔾 To C	LI	W21010207202	and the second
E STATE OF THE OWNER	Auto Login:			🖌 Login as i	user 'pi'		A Maria Carrow
and the second second	Network at Boot:			🗆 Wait for n	etwork		
	Underscan:		 Enabled 	l 💿 Disa	abled	and a little	Here
	Rastrack:			Add to Ras	track		A State
			C	ancel	ОК		the file

Finding your IP Address

ا 🗗 🕒 後	🚬 🔆 🔇 🗾 [pi@raspberry 🗾 pi@raspberry 🕴 🗍 📢 🛛 2	1:25 🔺
	pi@raspberrypi: ~ _ □ ×	
File E	dit Tabs Help	
pi@rasp eth0	<pre>berrypi: _ \$ ifconfig Link encap:Ethernet HWaddr b8:27:eb:d4:df:ec inet addr:192.168.11.114 Bcast:192.168.11.255 Mask:255.255.255.0 inet6 addr: fe80::a1d3:ab61:3e01:8222/64 Scope:Link UP BROADCAST RUNNING MULTICAST MTU:1500 Metric:1 RX packets:8327 errors:0 dropped:39 overruns:0 frame:0 TX packets:7299 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1000 RX bytes:8814824 (8.4 MiB) TX bytes:5044447 (4.8 MiB) Link encap:Local Loopback inet addr:127.0.0.1 Mask:255.0.0.0 inet6 addr: ::1/128 Scope:Host</pre>	
wlan0	UP LOOPBACK RUNNING MTU:65536 Metric:1 RX packets:1109 errors:0 dropped:0 overruns:0 frame:0 TX packets:1109 errors:0 dropped:0 overruns:0 carrier:0 collisions:0 txqueuelen:1 RX bytes:8385980 (7.9 MiB) TX bytes:8385980 (7.9 MiB) Link encap:Ethernet HWaddr 74:da:38:0d:14:f2 inet6 addr: fe80::203e:da2d:4ee2:231c/64 Scope:Link UP BROADCAST MULTICAST MTU:1500 Metric:1 RX packets:0 errors:0 dropped:14 overruns:0 frame:0 TX packets:0 errors:0 dropped:0 overruns:0 carrier:0	

Remote Access

- Do ifconfig from the keyboard
- Look for hostname raspberrypi
 - Assign a reserved IP address and add DNS
- Advantages of using ssh
 - Can access the device from anywhere
 - Automatic logins using authorized_keys
 - Text based menus work great remotely

Configuring rPi

- Plug in keyboard, mouse and screen
 - Menu >Preferences > rPi Configuration
- Plug in ethernet cable and locate the IP address
 - Default hostname is raspberrypi
 - ssh pi@XXX.XXX.XXX.XXX
 - password raspberry

Running raspi-config

File Edit View Search Terminal Help willem@bashful: \$ ssh pi@192.168.11.114 pi@192.168.11.114 's password: The programs included with the Debian GNU/Linux system are free software; the exact distribution terms for each program are described in the individual files in /usr/share/doc/*/copyright. Debian GNU/Linux comes with ABSOLUTELY NO WARRANTY, to the extent permitted by applicable law. Last login: Sat May 7 18:09:10 2016 from 192.168.11.126 pi@raspberrypi: \$ sudo raspi-config

Expand file system

pi@raspberrypi: ~

File Edit View Search Terminal Help

Raspberry Pi Software Configuration Tool (raspi-config)

1 Expand Filesystem	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
0 About raspi-config	Information about this configurat

<Select>

<Finish>

- 🗆 🗙

Change the Password

pi@raspberrypi: ~

File Edit View Search Terminal Help

Raspberry Pi Software Configuration Tool (raspi-config)

1 Expand Filesystem	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
0 About raspi-config	Information about this configurat

<Select>

<Finish>

- 🗆 🗙

Set timezone 1

- 🗆 🗙

pi@raspberrypi: ~

File Edit View Search Terminal Help

Deceloperu Di Cofficiere C	
Raspberry Pi Software Co	onfiguration lool (raspi-config)
1 Expand Filesystem	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
0 About raspi-config	Information about this configurat
<select></select>	<finish></finish>

Set timezone 2

pi@raspberrypi: ~		×
File Edit View Search Terminal Help		
Raspherry Pi Software (Configuration Tool (raspi-config)	
I1 Change Locale	Set up language and regional sett	
I2 Change Timezone	Set up timezone to match your loc	
I3 Change Keyboard Layout	Set the keyboard layout to match	
I4 Change Wi-fi Country	Set the legal channels used in yo	
<select></select>	<back></back>	
Seccer		
L		

Advanced Options

pi@raspberrypi: ~

File Edit View Search Terminal Help

<pre>1 Expand Filesystem</pre>	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
<pre>0 About raspi-config</pre>	Information about this configurat <finish></finish>

- 🗆 🗙

Set Hostname

- 🗆 🗙

pi@raspberrypi: ~

File Edit View Search Terminal Help

A1 Overscan		You may need to configure oversca 1
A2 Hostname		Set the visible name for this Pi
A3 Memory Split A4 SSH A5 Device Tree A6 SPI A7 I2C A8 Serial A9 Audio AA GL Driver		Change the amount of memory made Enable/Disable remote command lin Enable/Disable the use of Device Enable/Disable automatic loading Enable/Disable automatic loading Enable/Disable shell and kernel m Force audio out through HDMI or 3 Enable/Disable experimental deskt
	<select></select>	<back></back>

Disable serial login

pi@raspberrypi: ~

- 🗆 🗙

File Edit View Search Terminal Help

A1 Overs A2 Hostn A3 Memor A4 SSH A5 Devic A6 SPI A7 I2C	<mark>aspberry Pi</mark> can ame y Split e Tree	. Software	Configuration Tool (raspi-config) You may need to configure oversca f Set the visible name for this Pi Change the amount of memory made Enable/Disable remote command lin Enable/Disable the use of Device Enable/Disable automatic loading Enable/Disable automatic loading	
A7 12C A8 Seria A9 Audio AA GL Dr	l iver		Enable/Disable automatic loading Enable/Disable shell and kernel m Force audio out through HDMI or 3 Enable/Disable experimental deskt	
	<s< td=""><td>elect></td><td><back></back></td><td></td></s<>	elect>	<back></back>	

Reboot and log in again

pi@raspberrypi: ~

File Edit View Search Terminal Help

T Ruspoerry i e soremare cor	regulation root (raspe conteg) [
I Expand Filesystem	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
0 About raspi-config	Information about this configurat

<Select>



- 🗆 🗙
Add user willem

```
🛛 🗖 🔲 pi@aid2: ~
File Edit View Search Terminal Help
pi@aid2:🤇$ sudo adduser willem
Adding user willem'
Adding new group `willem' (1001) ...
Adding new user `willem' (1001) with group `willem' ...
Creating home directory `/home/willem' ...
Copying files from `/etc/skel' ...
Enter new UNIX password:
Retype new UNIX password:
passwd: password updated successfully
Changing the user information for willem
Enter the new value, or press ENTER for the default
        Full Name []: Willem ACOKO
        Room Number []:
        Work Phone []:
       Home Phone []:
       Other []:
Is the information correct? [Y/n]
pi@aid2: 🥵 sudo adduser willem sudo
Adding user willem' to group `sudo' ...
Adding user willem to group sudo
Done.
pi@aid2:~ $
```

Install required packages

🗴 🗖 🔲 pi@aid2: ~

File Edit View Search Terminal Help

Part 1b Getting Started on the Beaglebone Black

Beaglebone Materials

- Beaglebone Black or Green
- Micro SD card
- 5V 1A power supply
- USB A to mini USB B cable or barrel connector
- Ethernet cable
- Direct connection
 - Monitor or TV
 - HDMI to micro HDMI cable
 - USB keyboard and mouse

Beaglebone OS Choices

- http://beagleboard.org/latest-images
- Debian 8 Jessie
 - Linux Kernel 4.4 (Jesse 8.4)
- Debian 7 Wheezy
 - Linux Kernel 3.8 (Wheezy 7.11)
- I have had trouble with Jessie on the BBB, so use Wheezy for now

Burning the Image

- Images are compressed with xz
 - p7zip on windows
 - xz-utils on Linux
- Uncompress image (Linux)
 - xz -d bone-debian-*.img.xz
- Burn image using dd or Win32DiskImager

Beaglebone Resize Image

File Edit View Search Terminal Help

willem@bashful:~\$<mark>ssh root@192.168.11.88</mark> Debian GNU/Linux 7

BeagleBoard.org Debian Image 2016-06-15

Support/FAQ: http://elinux.org/Beagleboard:BeagleBoneBlack_Debian

default username:password is [debian:temppwd]

Last login: Thu Oct 12 01:22:20 2016 from bachful local root@beaglebone:~# /opt/scripts/tools/grow_partition.sh Media: [/dev/mmcblkoj

```
Disk /dev/mmcblk0: 474880 cylinders, 4 heads, 16 sectors/track
Old situation:
Warning: The partition table looks like it was made
for C/H/S=*/112/62 (instead of 474880/4/16).
For this listing I'll assume that geometry.
Units = mebibytes of 1048576 bytes, blocks of 1024 bytes, counting from 0
Device Boot Start End MiB #blocks Id System
/dev/mmcblk0p1 * 1 3399 3399 3480576 83 Linux
```

start: (c,h,s) expected (0,33,3) found (0,32,33) end: (c,h,s) expected (1002,85,42) found (433,111,62)

Reboot to apply resize

Beaglebone Configuration

File Edit View Search Terminal Help
root@beaglebone:~# dpkg-reconfigure tzdata
Current default time zone: 'America/Denver' Local time is now: Wed Oct 12 19:51:11 MDT 2016. Universal Time is now: Thu Oct 13 01:51:11 UTC 2016.
root@beaglebone:~# sed -i -e 's/beaglebone/bpqconifer/g' /etc/hostname /etc/hosts
root@beaglebone:~# apt-get -qq update root@beaglebone:~# apt-get install telnet unzip minicom Reading package lists vone
Building dependency tree
The following extra packages will be installed: lrzsz
Suggested packages: zip
The following NEW packages will be installed: lrzsz minicom telnet unzip
0 upgraded, 4 newly installed, 0 to remove and 60 not upgraded.
Need to get 672 kB of archives.
After this operation, 1,554 kB of additional disk space will be used. Do you want to continue [Y/n]? [

Beaglebone User Configuration

- Set root and debian passwords
 - passwd
 - passwd debian
- Add additional user(s)
 - adduser willem
 - adduser willem sudo

Part 1c Getting around in Linux

Command Line Basics

- Is list files
- cd change directory
- cp copy file(s)
- mv move file(s)
- rm remove file(s)
- mkdir make new directory
- rmdir remove directory
- sudo run the command as root
- man help
- Command line parameters start with -

Customizing your environment

- Create a file named .bashrc in your home directory
 - alias cp='cp -i'
 - alias mv='mv -i'
 - alias rm='rm -i'
 - export PATH=\$PATH:/new/location
- Files starting with . (period) are hidden unless you do *ls -a*

Software Maintenance

- apt-get update
 - Download index of latest software available
- apt-get upgrade
 - Upgrade all packages to latest versions
- apt-get install foo
 - Install package foo
- apt-get remove foo
 - Remove package foo

Editing files

- leafpad rPi editor
- nano Easy to use
- vi/vim/gvim The editor for real men
- emacs For uber-nerds
- BPQ has an editor built into the web interface to update bpq32.cfg

Part 2 BPQ BBS/RMS/iGate

What is **BPQ**?

- NET/ROM compatible Packet Switch

 Multiple ports
 - As many I2C or serial ports as you have available
 - Multiple protocols
 - Packet, Pactor, IP
 - Multiple functionsBBS, Chat, APRS

What can we use BPQ for?

- AX25 (Packet) Access point
- Bulletin Board System (BBS)
- Radio Message Server (RMS)
- APRS Internet Gateway
- Application Gateway

BPQ Web Configuration

🛞 🖨 💿 KONTS's BPQ32 Web Server - Mozilla Firefox						
[₽] % KONTS's BPQ32 We × 🕂						
(i ctnpi:8080/Node/NodeIndex.html	C C	२ Search	☆	ê 🛡 🖡	A 9	• •
BPQ3	B2 Nod	le KO	NTS			
Routes Nodes Ports Links Users Stats Terminal Wi	iver S indows S	tream tatus	Mail Server Pages	<u>Chat Server</u> <u>Pages</u>	<u>SYSOP</u> <u>Signin</u>	Edit Config

BBS Message Page

😣 🔿 💿 Edit Messages - Chromium		
^B _{Po} Edit Messages ×		
C C C C C C C C C C C C C C C C C C C	?M000039592D06	☆ =
	BPQ32 BBS KONTS	
Status Configuration	Users Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu	
Filter	Message 2555	
Via 2504 2503 2498 2407	From AC0KQ Sent 08-May 21:40Z Type P T To K0TER Received 08-May 21:40Z Status F T BID 2555 K0NTS Last Changed 08-May 21:41Z Size 210 VIA	
2497 2494 2493 2492 2491	Edit Text Save Save Message Save Attachment Print Export Green = Sent, Yellow = Queued	
2486 2485 2483 2482 2482 2481	KONTS RMS	

Message Forwarding

😣 📾 🗈 Edit Forwarding - Mozilla Firefox	
📴 Edit Forwarding 🛛 🗙 🕂	
(ctnpi:8080/Mail/FWD?M000038DD423A	C Q Search ☆ 自 ♥ ● ● ■
	BPQ32 BBS KONTS
Status Configuration Users Messages H	orwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu
Max size to Send	Forwarding Config for RMS - 0 Messages Queued
	TO AT TIMES Connect Script
Max Size to Receive	RMS KØTER
	K6HTN N1IQI
Max age for Bulls	AL7N NX9K
Worn if no route	
for P or T	Hierarchical Routes (Flood Bulls) HR (Personals and Directed Bulls)
Use Local Time	
Allases	
	BBS HA
	Enable Forwarding 🗹 Interval 3600 (Secs)
	Request Reverse SInterval 3600 (Secs)
Update	Send new messages without waiting for poll timer 🖾
	FBB Max Block 10000 Send Personal Mail Only
	Allow Binary 🖾 Use B1 Protocol 🖾 Use B2 Protocol 🖾
	Send ctrl/Z instead of /ex in text mode forwarding
	Update Start Forwarding

APRS Page

C

Q Search

☆ 自

 \sim

9

Ξ

N0SZ-14's BPQ32 Web Server - Mozilla Firefox 80

📴 N0SZ-14's BPQ32 W... 🗴 🕂

① 192.168.11.88:8008/aprs/all.html

N0SZ-14's BPQ32 APRS Web Server Home All Stations All Stations **RF Stations** All WX Stations (This page will automatically refresh every five minutes) **RF WX Stations** The following is a list of all the stations heard in the past 120 minutes, both on RF and on the internet. All Mobile Stations There are 90 callsigns in the list, **RF Mobile** click a callsign to get an information page for that station. Stations AD0WB-B ACOVP-10 AC0XW-1 AC0YV-9 AE5VO ALMGRE BVILLE **KOBAN** All Objects KOHEY-9 K0JSC-1 K0OED-10 K0RTS-9 K1DDN-4 KOOED K7HRO-9 K7RFW-9 **RF Objects** K7YE-3 K8ZTT-9 KBOJIT **KBOUSF** KB9UZO-9 KC0D KC0D-6 KC0FAC-7 Information KD0FPY-9 KC0LAD-1 **KCOWUV** KC6ETE-9 KD0JZX-10 KD0KVJ-15 KD0LAC-10 KD0SQA-4 Node Pages KE0GDI-7 KI4GYZ-1 KI0CFW-9 KN0MAP-1 N0BN-1 KD0SOA-9 KG4IAM KT0AM-9 NOEB NOLNE NOOI N0RUX-13 N0SZ-14 N0SZ-2 NOWAR-9 N0WGM-3 N3GPS N1GEP-1 N2XGL-5 N2XGL-9 N4ATA-7 N4IIR-9 N7GN-5 N7MJ-9 N7SOI-9 NOADM SAG1 WOAKO-B WOARP W0BSP-10 W0BSP-13 W0CDS-A W0CDS-B W0CDS-C W0DPD-1 WOIAW W0JRL-15 W0LRA-5 W0IAW-9 W0QEY-5 WORDR-9 W0UPS-5 W8XAL-10 W8XAL-9 WA0GEH WA0TOG WA5VRL WA6IFI-3 WB5PIB-B WB7GR-3 WB7GR-9 WD4IXD WD4IXD-10 W08M-1 W08M-9 WR0AEN-B WR0AEN-D WY7ATH-2

Stations Heard on RF

1.5	92.168.11.88:8008/aprs	/allrf.html		C Q Search	☆ 🛍		↓ ☆	Ø
	TT-max	NIOCZ	14-1		TAL	h C		_
	Home	11052	-14 5 1	bry52 Arks	o vvo	en 26	erver	
	All Stations			RF Stations				
	<u>RF Stations</u>							
	All WX Stations	(Tl	nis page will	automatically refresh ev	very fiv	e minute	es)	
	RF WX Stations		The fol	llowing is a list of all the	statio	ns		
	All Mobile Stations		heard on RF in the past 120 minutes. '*' after a callsign means that it was heard via a digi					
	DE Mobilo							
	Stations	Th	e list only inc	ludes callsigns heard or	n RF, di	irect or v	via	
	All Objects	digipeaters. It does not include callsigns heard on the internet, or heard as third-party RF traffic via IGATEs.						
	RF Objects							
	Information							
		click a callsign to get an information page for that station.						
	Node Pages	0110	5		.		011.	
	<u>Node Pages</u>	Callsign	Symbol	Location	Miles	Bearing	Last hea	rd
	<u>Node Pages</u>	Callsign ALMGRE*	Symbol No. Digi	Location 38°46.33'N 104°59.55'W	Miles 54.9	Bearing 159	Last hea 16:31:27	rd
	<u>Node Pages</u>	Callsign <u>ALMGRE*</u> <u>K0BAN*</u>	Symbol No. Digi Truck	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W	Miles 54.9 62.9	Bearing 159 12	Last hea 16:31:27 16:37:20	rd
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1*	Symbol No. Digi Truck No. Digi	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W	Miles 54.9 62.9 97.3	Bearing 159 12 156	Last hea 16:31:27 16:37:20 16:30:12	ard
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED*	Symbol No. Digi Truck No. Digi Rec Veh'le	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W	Miles 54.9 62.9 97.3 56.9	Bearing 159 12 156 130	Last hea 16:31:27 16:37:20 16:30:12 16:32:21	ard
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED* KOQED-10*	Symbol No. Digi Truck No. Digi Rec Veh'le No. Diam'd	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W 38°59.87'N 104°38.52'W	Miles 54.9 62.9 97.3 56.9 52.1	Bearing 159 12 156 130 133	Last hea 16:31:27 16:37:20 16:30:12 16:32:21 15:55:59	urd
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED* KOQED-10* KORTS-9*	Symbol No. Digi Truck No. Digi Rec Veh'le No. Diam'd Truck	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W 38°59.87'N 104°38.52'W 39°17.25'N 103°30.01'W	Miles 54.9 62.9 97.3 56.9 52.1 100.0	Bearing 159 12 156 130 133 99	Last hea 16:31:27 16:37:20 16:30:12 16:32:21 15:55:59 15:57:58	ard
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED* KOQED-10* KORTS-9* K1DDN-4*	Symbol No. Digi Truck No. Digi Rec Veh'le No. Diam'd Truck Car	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W 38°59.87'N 104°38.52'W 39°17.25'N 103°30.01'W 38°25.62'N 105°11.37'W	Miles 54.9 62.9 97.3 56.9 52.1 100.0 75.8	Bearing 159 12 156 130 133 99 173	Last hea 16:31:27 16:37:20 16:30:12 16:32:21 15:55:59 15:57:58 16:06:07	nrd
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED* KOQED-10* KORTS-9* K1DDN-4* K7HRO-9*	Symbol No. Digi Truck No. Digi Rec Veh'le No. Diam'd Truck Car Truck	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W 38°59.87'N 104°38.52'W 39°17.25'N 103°30.01'W 38°25.62'N 105°11.37'W 41°09.63'N 104°47.80'W	Miles 54.9 62.9 97.3 56.9 52.1 100.0 75.8 117.1	Bearing 159 12 156 130 133 99 173 14	Last hea 16:31:27 16:37:20 16:30:12 16:32:21 15:55:59 15:57:58 16:06:07 16:21:42	ırd
	<u>Node Pages</u>	Callsign ALMGRE* KOBAN* KOJSC-1* KOQED* KOQED-10* KORTS-9* K1DDN-4* K7HRO-9* K7RFW-9*	Symbol No. Digi Truck No. Digi Rec Veh'le No. Diam'd Truck Car Truck Van	Location 38°46.33'N 104°59.55'W 40°24.41'N 105°05.68'W 38°13.86'N 104°36.65'W 38°58.91'N 104°32.53'W 38°59.87'N 104°38.52'W 39°17.25'N 103°30.01'W 38°25.62'N 105°11.37'W 41°09.63'N 104°47.80'W 41°33.88'N 106°08.23'W	Miles 54.9 62.9 97.3 56.9 52.1 100.0 75.8 117.1 147.3	Bearing 159 12 156 130 133 99 173 14 344	Last hea 16:31:27 16:37:20 16:30:12 16:32:21 15:55:59 15:57:58 16:06:07 16:21:42 16:39:01	

38°59.63'N 105°03.46'W

K8ZTT-9*

Jeep

39.4

157 16:24:34

Station Map

192.100.11.00.0000/0013/1	ind.cgi?call=N052-2 C C Search 2 E C C
Home	N0SZ-14's BPQ32 APRS Web Server
All Stations	
RF Stations	(This page will automatically refresh every five minutes)
All WX Stations	Information about <u>N0SZ-2</u>
RF WX Stations	Click the callsign to look it up on qrz.com
All Mobile	The bearing from NOSZ-14 to NOSZ-2 is 028 degrees, the distance is 47.9
<u>Stations</u>	Miles
RF Mobile	Last posit: APTT4,W0UPS-5,WIDE1,KC0D,WIDE2*
Stations	Status: /TinyTrak4 Alpha
All Objects	Last heard 00:54:36 ago
<u>RF Objects</u>	Berthoud
Information	Map Satellite OSM MQ
Node Pages	
	Lyons Mead Platteville
	k (36) Hygiene
	Longmont NoSZ-2 (85)
	Altona den Lake Jamestown
	(1) Dacono Fort Lupton
	Gold Hill (287) Erie
	Boulder 7
	Lafayette

How does it work?

- BPQ is a software program
 - Runs on most computers
 - Somewhat complex configuration file
- Connects to radio via Terminal Node Controller (TNC)
 - Typically serial connection
- Interconnects via IP
- Built-in BBS, iGate, Chat server, ...

rPi/BPQ vs. KPC3+ BBS

rPi/BPQ Pros

- Lower cost (\$100)
- Much larger capacity (GB vs. kB)
- More ports (multiple RF, serial and IP)
- Sophisticated forwarding
- rPi/BPQ Cons
 - Higher current draw
 - Less tolerant of bad power

Complaint: Hard to set up BPQ

- BPQ is very sophisticated, and that necessarily adds complexity
- Solutions:
 - -Use bpq-config to get started
 - -Web interface for BBS etc.
 - -Join a support group
 - Yahoo BPQ32
 - RMHAM

Why so rPi and BBB centric?

- BPQ is software runs anywhere
 - Supported on Windows, OSX, Linux
 - Best run as a headless server
- rPi and BBB are
 - Inexpensive
 - Reliable Linux boxes
 - DC powered
 - TNC/Pi & TNC/Black daughter boards
 - All the cool kids have one

Why the rPi/TNC-Pi?

- Extremely well supported
- Complete package with screen



Brief history of BPQ

- Written by John Wiseman G8BPQ
- Originally called BPQCODE
- Became BPQ32 in late 90s
- Ported to OSX/Linux in 2000s
- Ported to Raspberry Pi/TNC-PI and Beagle Bone Black/TNC-Black

Building the TNC kit

- It takes a few hours to build
 - Quality soldering iron time
 - Simple, excellent instructions
- Test it
 - Check voltages, insert ICs
 - LEDs should flash on power up
 - Configure OS and BPQ
- John W2FS provides outstanding aftersales support

Selecting a Username

- Default user name
 - Raspberry Pi = pi
 - Beaglebone Black = debian
- The default user name is good for BPQ and similar programs with multiple users
- Create a login for each user
- Create subdirectories for programs like BPQ which will clutter the home directory

Download and run bpq-config

File Edit View Search Terminal Help

pi@aid2:~ \$ mkdir BPQ
pi@aid2:~ \$ cd BPQ
pi@aid2:~/BPQ \$ wget -q http://www.prinmath.com/ham/bpq-config
pi@aid2:~/BPQ \$ chmod a+x bpq-config
pi@aid2:~/BPQ \$ sudo ./bpq-config []

Download BPQ (Can also be used to update BPQ)

File Edit View Search Terminal Help
ACOKQ bpq-config version 1.0
Installation Steps Select next step 1 Download BPQ 2 Configure BPQ 3 About bpq-config <select></select>

Configure BPQ



Node Configuration

File Edit View Search Terminal Help ACOKQ bpq-config version 1.0 Configuration Steps Select next step 1 Node Configuration 2 Port configuration 3 Telnet users 4 AXIP Node Maps 5 Write Configuration <Select> <Finish>

Node Callsign 1

File Edit Vie	ew Search Terminal Help	
ΑC0KQ bpq-«	config version 1.0	
	Node Configuration	
	Set Parameter	
	Node Callsign 1	
	Owner Acronym	
	Grid Square	
	Telnet Port 8010	
	FBB Port 8011 HTTP Port 8008	
	AXIP Port 10093	
	AXIP AutoAdd Yes	
	WINLINK RMS ↓	
	<set> <finish></finish></set>	
Node Callsign 2

File Edit Vie	iew Search Terminal Help	
AC0KQ bpq-	config version 1.0	
	Node Callsign Enter Node Callsign e.g. KONTS (no -1 or -10) NOSZ	
	<ok> <cancel></cancel></ok>	

Owner Acronym 1

ile Edit Vie COKQ bpq-c	ew Search Terminal Help config version 1.0	
	Set Parameter	
	Node Callsign NOSZ ↑ Owner Acronym Owner Name Grid Square Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS ↓	
	<set> <finish></finish></set>	

Owner Acronym 2

File Edit View	File Edit View Search Terminal Help				
AC0KQ bpq-con	ıfig version 1.0				
Ei Pi	Owner Acronym Inter Owner Acronym 1-4 letters, e.g. CTN, used in prompts and alternate callsigns				
	<ok> <cancel></cancel></ok>				

Owner Name 1

	A.				
File Edit View Search Terminal Help					
ACOKQ bpq-c	onfig version 1.0				
	2				
		Node Configu	ration		
	Set Parameter				
		Node Callsign	NOSZ	<u>1</u>	
		Owner Acronym	RMH		
		Owner Name		1	
		Grid Square			
		Telnet Port	8010		
		FBR POLT	8011		
		HIIP POFT	8008		
		AXIP POFT	10093		
		Highigh DMC	res	- -	
		WUILLIIK KMS		¥	
	<set:< th=""><th>></th><th><fi< th=""><th>nish></th><th></th></fi<></th></set:<>	>	<fi< th=""><th>nish></th><th></th></fi<>	nish>	
	0000				

Owner Name 2

File Edit View Search Terminal Help						
AC0KQ bpq-0	COKQ bpq-config version 1.0					
	Owner Name					
	Enter Owner Name e.g. Colorado Traffic Net, used in prompts					
	Rocky Mountain Ham Radio					
	<ok> <cancel></cancel></ok>					

Grid Square 1

ile Edit View Search Terminal Help							
COKQ bpq-	COKQ bpq-config version 1.0						
	Node Configuration	_					
	Set Parameter						
	Node Callsign NOSZ 1						
	Owner Acronym RMH						
	Owner Name Rocky Mountain Ham Radio						
	Telnet Port 8010						
	FBB Port 8011						
	AXIP Port 10093						
	AXIP AutoAdd Yes						
	WinLink RMS ↓						
	<set> <finish></finish></set>						

Grid Square 2

File Edit Vi	iew Search Terminal Help	
AC0KQ bpq-	config version 1.0	
	Grid Square Enter Grid Square e.g. DM79gr	
	DM79hm	
	<0k> <cancel></cancel>	

Winlink RMS 1 (notice that it skipped items with defaults)

File Edit View	w Coassh Terminal Hele	
	w Search Terminal Help	
ACOKQ bpq-c	onfig version 1.0	
	Node Configuration	
	Set Parameter	
	Node Callsign NOSZ	
	Owner Acronym RMH	
	Owner Name Rocky Mountain Ham Radio	
	Grid Square DM79hm	
	Telnet Port 8010	
	FBB Port 8011	
	HTTP Port 8008	
	AXIP Port 10093	
	AXIP AutoAdd Yes	
	WinLink RMS ↓	
	<set> <finish></finish></set>	

Winlink RMS 2

File Edit Vi	iew Search Terminal Help	
AC0KQ bpq-	config version 1.0	
	WinLink RMS Enable access to WinLink	
	<yes> <no></no></yes>	

CMS Callsign 1

(CMS call and password added when WinLink is Yes)

File Edit View Search Terminal Help						
ACOKQ bpq-config version 1.0						
_						
	Set Parameter					
	Owner Acronym RMH Owner Name Rocky Mountain Ham Radio Grid Square DM79hm Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS Yes CMS Callsign					
	<set> <finish></finish></set>					

CMS Callsign 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 CMS Callsign Enter CMS Callsign used to access WinLink. NOSZ <0k> <Cancel>

CMS Password 1

File Edit View Search Terminal Help					
ACOKQ bpq-	config version 1.0				
	Node Configuration				
	Set Parameter				
	Owner Name Rocky Mountain Ham Radio ↑ Grid Square DM79hm Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS Yes CMS Callsign N0SZ CMS Password				
	<set> <finish></finish></set>				

CMS Password 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 CMS Password Enter CMS Password used to access WinLink. BlahBlahBlah <0k> <Cancel>

Chat Server 1

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0

> Node Configuration Set Parameter DM79hm Grid Square Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS Yes CMS Callsign NOSZ CMS Password BlahBlahBlah Chat Server <Set> <Finish>

Chat Server 2

File Edit Vie	w Search Terminal Help			
ACOKQ bpq-0	onfig version 1.0			
		- Chat Server		
	Enable Chat Server			
	<yes></yes>		<no></no>	

APRS iGate 1

File Edit Vie	ile Edit View Search Terminal Help			
COKQ bpq-c	onfig version 1.0			
ſ	Set Parameter			
	Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS Yes CMS Callsign NOSZ CMS Password BlahBlahBlah Chat Server No APRS iGate			
	<set> <finish></finish></set>			

APRS iGate 2

File Edit Vie	ew Search Terminal	Неір			
ACOKO bpg-	config version 1	.0			
	-				
			APRS iGate		
	Enable APRS iG	ate			
		<ves></ves>		<no></no>	
		1052			

Finish Node Configuration

ile Edit View Search Terminal Help	
COKQ bpq-config version 1.0	
Node Configuration	
Set Parameter	
Node Callsign N0SZ ↑	
Owner Acronym RMH	
Owner Name Rocky Mountain Ham Radio	
Telnet Port 8010	
FBB Port 8011	
AXTP Port 8008	
AXIP AutoAdd Yes	
WinLink RMS Yes ↓	
<set> <finish></finish></set>	

Configure Port

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Configuration Steps
Select next step

1 Node Configuration 2 Port configuration 3 Telnet users

4 AXIP Node Maps

5 Write Configuration

<Select> <Finish>

Add Port

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0



Port Type 1

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Set Parameter	Configure po	rt	
	Type Device Type Device Number Frequency Digipeat Power Height Gain	Yes	
<set></set>		<finish></finish>	

Port Type 2



Device Type 1

File Edit Vie	ew Search Terminal H	elp		
AC0KQ bpq-0	config version 1.0			
	Set Parameter	Configure	port	
		Type <mark>Device Type</mark> Device Number Frequency	Packet	
		Digipeat Power Height Gain	Yes	
	<set< th=""><th>t></th><th><finish></finish></th><th></th></set<>	t>	<finish></finish>	

Device Type 2 (Devices description is board specific)



Device Number 1

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 Configure port Set Parameter Packet Туре Device Type Serial Device Number Frequency Digipeat Yes Power Height Gain <Finish> <Set>

Device Number 2

File Edit Vi	ew Search Terminal Help	
AC0KQ bpq-	config version 1.0	
	Device Number Enter Device Number There is only one serial port numbered 0 For multiple devices the I2C bus must be used I2C bus addresses are in decimal	
	[⊙] <ok> <cancel></cancel></ok>	

Frequency 1

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Set Parameter	— Configure p	port
	Type Device Type Device Number <mark>Frequency</mark> Digipeat Power	Packet Serial 0 Yes
<set></set>	Height Gain	<finish></finish>

Frequency 2

File Edit Vi	iew Search Terminal Help	
AC0KQ bpq-	config version 1.0	
	Enter Frequency kHz e.g. 145050	
	145050	
	<ok> <cancel></cancel></ok>	

Transmit Power 1 (Used for WinLink reporting)

File Edit View Search Terminal Help					
AC0KQ bpq-c	COKQ bpq-config version 1.0				
ſ	Configure port				
	Set Parameter				
	Type Packet				
	Device Type Serial				
	Device Number 0				
	Frequency 145050				
	Power				
	Height				
	Gain				
	<set> <finish></finish></set>				

Transmit Power 2

File Edit View Search Terminal Help					
ΑC0KQ bpq-co	ACOKQ bpq-config version 1.0				
	Power				
	Enter Power Transmitter power in watts				
	40				
	<ok> <cancel></cancel></ok>				

Antenna Height 1 (Used for WinLink reporting)

File Edit View Search Terminal Help				
COKQ bpq-config version 1.0				
	Configure	port		
Set Parameter				
	Туре	Packet		
	Device Type	Serial		
	Device Number	0 145050		
	Digipeat	Yes		
	Power	40		
	Height			
	Gath			
<set></set>	•	<finish></finish>		

Antenna Height 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 Height Enter Height Antenna height in feet 35 <0k> <Cancel>

Antenna Gain 1 (Used for WinLink reporting)

File Edit View Search Terminal Help					
AC0KQ bpq-config ver	COKQ bpq-config version 1.0				
	Configure	port			
Set Para	ameter				
	Tupo	Packet			
	Device Type	Serial			
	Device Number	0			
	Frequency	145050			
	Digipeat	Yes			
	Height	35			
	Gain				
	<set></set>	Finich			
	<581>	<r til="" tsil=""></r>			

Antenna Gain 2

File Edit View Search Terminal Help					
ΑϹΘΚQ Ϸϼϥ-	config version 1.0				
	Gain Enter Gain Antenna gain in dB 6				
	< <u>Cancel></u>				

Finish Port Configuration

e Edit View Search Terminal He	lp		
0KQ bpq-config version 1.0			
	- Configure	port	
Set Parameter	,		
	Туре	Packet	
	Device Type	Serial	
	Frequency	145050	
	Digipeat	Yes	
	Power	40	
	Height	35	
	Gain	0	
<set></set>	>	<finish></finish>	

Finish Adding Ports

File Edit View Search Terminal Help

ACOKQ bpq-config version 1.0


Add Telnet (IP) Users (You mast have at least one)

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Configuration Steps Select next step 1 Node Configuration 2 Port configuration 3 Telnet users 4 AXIP Node Maps 5 Write Configuration

<Select> <Finish>

Add new Telnet user

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0



User Name 1

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Set Parameter	Configure user
	Username Password Callsign Application SysOp
<set></set>	<finish></finish>

User Name 2

ile Edit Vi	ew Search Terminal Help	
COKQ bpq-	config version 1.0	
	Enter Username e a willem	1
	Enter Osername e.g. witten	
	willem	
	<ok> <cancel></cancel></ok>	
		1

Password 1

File	Edit	View	Search	Terminal	Help
------	------	------	--------	----------	------

AC0KQ bpq-config version 1.0

Set Parameter	Configure	user	
	Username <mark>Password</mark> Callsign Application SysOp	willer	1
<set></set>		<f< td=""><td>inish></td></f<>	inish>

Password 2

File Edit View	w Search Terminal Help	
ΑC0KQ bpq-co	onfig version 1.0	
	Password Enter Password e.g. XyZ123 abc123	
	<ok> <cancel></cancel></ok>	

Callsign 1

File Edit Vi	ew Search Terminal Help	p	
AC0KQ bpq-	config version 1.0		
	Set Parameter	Configure user	
		Username willem Password abc123 Callsign Application SysOp	
	<set></set>	<pre><finish></finish></pre>	

Callsign 2

File Edit Vi	iew Search Terminal Help	
ACOKQ bpq-	config version 1.0	
	Callsion	
	Enter Callsign Callsign	
	ΑϹϿΚϘ	
	<ok> <cancel></cancel></ok>	

Application 1

File Edit Vi ACOKQ bpq-	ew Search Terminal Help config version 1.0)		
	Set Parameter	Configure Username Password Callsign Application	user willem abc123 ACOKQ	
	<set></set>	5550	<finish></finish>	

Application 2

File Edit View Search Terminal Help	
AC0KQ bpq-config version 1.0	
Select application to (*) NODE () BBS	Application connect to
<pre><select></select></pre>	<cancel></cancel>

System Operator 1

File Edit View Search Terminal Help ACOKQ bpq-config version 1.0 Configure user Set Parameter Username willem Password abc123 Callsign ACOKQ Application NODE Sys0p <Finish> <Set>

System Operator 2

File Edit View Search Terminal Help	
AC0KQ bpq-config version 1.0	
SysOp	
System operator priviliges	
<yes> <no></no></yes>	

Finish User Configuration

File Edit View Search Terminal Help ACOKQ bpq-config version 1.0 Configure user Set Parameter willem Username Password abc123 Callsign ACOKQ Application NODE Sys0p Yes <Finish> <Set>

Add Another User

File Edit View Search Terminal Help

ACOKQ bpq-config version 1.0



Finish adding second user

File Edit View Search Terminal Help ACOKQ bpq-config version 1.0 Configure user Set Parameter Username iohn Password xyz123 Callsign WOVG Application NODE Sys0p Yes <Finish> <Set>

Finish adding Telnet Users

File Edit View Search Terminal Help

ACOKQ bpq-config version 1.0



Configure AXIP Node Maps

File Edit View Search Terminal Help ACOKO bpq-config version 1.0 Configuration Steps Select next step 1 Node Configuration 2 Port configuration 3 Telnet users 4 AXIP Node Maps 5 Write Configuration <Select> <Finish>

Add new AXIP map

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0



Callsign 1

File Edit View Search Terminal Help		
AC0KQ bpq-config version 1.0		
	Configure man	
Set Parameter		
See Paranecer		
	Callsign	
	Address	
	Port 10093	
<set></set>	<finish></finish>	

Callsign 2

File Edit Vi	iew Search Terminal Help	
ΑC0KQ bpq-	config version 1.0	
	Callsign	
	Enter Callsign Node callsign (SSID optional)	
	KONTS-1	
	<ok> <cancel></cancel></ok>	

AX IP Address 1

File Edit Vi	ew Search Terminal Help			
AC0KQ bpq-	config version 1.0			
	Set Parameter	- Configure map Callsign KONTS- Address Port 10093	1	
	<set></set>		<finish></finish>	

AX IP Address 2

File Edit View Search Terminal Help						
ACOKQ bpq-config version 1.0						
Address	_					
Enter Address IP address or DNS address						
ctnpi.ac0kq.rmham						
<pre><cancel></cancel></pre>						

Done Adding AXIP Map

File Edit View Search Terminal Help
ACOKQ bpq-config version 1.0
Set Parameter
<mark>Callsign KONTS-1</mark> Address ctnpi.ac0kq.rmham Port 10093
<set> <finish></finish></set>

Finish adding AXIP maps

File Edit View Search Terminal Help

ACOKQ bpq-config version 1.0



Write **BPQ** Configuration



Files Written by bpq-config

File Edit View Search Terminal Help

ACOKQ bpq-config version 1.0

bpq-config save

Wrote bpq32.cfg Write linmail.cfg Wrote BPQBBSUsers.dat Wrote /lib/systemd/system/bpq.service Wrote /etc/minicom/minirc.bpq Wrote minicombpq Wrote /usr/local/bin/bterm



Done with Configuration

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0



Start BPQ

File Edit View Search Te	erminal Help
AC0KQ bpq-config vers	ion 1.0
	Select next step
	1 Download BPQ 2 Configure BPQ <mark>3 Start BPQ</mark> 4 Enable BPQ start at boot 5 About bpq-config
	<select> <finish></finish></select>

Options after Starting BPQ

File Edit View Search Termin	nal Help
AC0KQ bpq-config version	1.0
Sel	lect next step
	1 Download BPQ 2 Configure BPQ 3 Restart BPQ 4 Stop BPQ 5 Enable BPQ start at boot 6 About bpq-config
	<select> <finish></finish></select>

Browse to BPQ node port 8008 (if you configured a different port, use it instead)



BPQ Ports



Click Mail Server Pages

^{BP} BPQ32 Mail Serve	er ×					
← → C (i) 192.10	58.11.114:8008/Mail/Header				\$]
	BPQ	32 Mai	Server N0SZ-7 A	ccess		
	Please enter C	Callsign	and Password to a	access the BBS		
	I I I I I I I I I I I I I I I I I I I	User		rillem		
	I I I I I I I I I I I I I I I I I I I	Password				
			Submit Cancel			
	进行在 教育法 经					

BBS Configuration (bpq-config set most of these in linmail.cfg)

^{Bp} Main Configuration		Î	±
← → ♂ 🛈 192.168.1	11.114:8008/Mail/Conf?M000077442E50	☆	:
Status Con	BPQ32 BBS N0SZ figuration Users Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu		
	Main Configuration		
	BBS Params		
E	BS Call NOSZ SYSOP Call WOVG		
H H	Route Redirect msgs to BBS Call to SYSOP Call		
	ABS APPL No 1 Streams 32 Send System Msgs to SYSOP Call Refuse Bulls Enable FBB UI System Send Mail For Beacons every 0 Minutes Config UI Ports and Digis Don't Hold Messages From New Users Don't Request Name Don't Request Name Don't Request Home BBS Allow users to kill T messages Forward Messages to BBS Call POP3 Port 0 SMTP Port 0 NTPPort 0 Enable Remote Access MMPR Address Send AMPR Mail to AMPR host		

BBS Users (bpq-config added RMS and telnet users)

^B Po Edit Users ×			1
← → C ① 192.168.11.114:8008/Mail/Us	ers?M000077442E50	☆	:
Status Configuration Users	BPQ32 BBS N0SZ Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu		
ACOKQ NOSZ RMS WOVG	Update User AC0KQ BBS Permit Email PMS RMS Express User SYSOP Poll RMS Expert For SSID's Excluded Hold Messages Include SYSOP msgs in LM Don't add @winlink.org Allow Sending Bulls NTS MPS Connects In 0 Msgs in 0 Rejects In 0 Gonnects Out 0 Msgs Out 0 Rejects Out 0 Bytes In 0 Last Connect 01-Jan 00:00Z Bytes Out 0 Last Listed 0 Name Password CMS Pass QTH ZIP Home BBS Update Delete		

User RMS is a WinLink2000

BPQ32 BBS NOSZ Status Configuration Users Messages Forwarding Welcome Msgs & Prompts Hous ACOKQ Update User RMS NOSZ PMS Permit Email WOVG PMS RMS Express Us Sysop Poll RMS Expert For SSID's Excluded Hold Messages Include SYSOP msgs in LM Don't add @win Allow Sending Bulls NTS MPS	r	
ACOKQ NOSZ RMS Update User RMS WOVG ● BBS ● Permit Email WOVG ● PMS ● RMS Express Us ● SYSOP ● Poll RMS ● Expert For SSID's ● Excluded ● Hold Messages ● Include SYSOP msgs in LM ● Don't add @win ♥ Allow Sending Bulls ● NTS MPS	лт	
Connects Out 0 Msgs Out 0 Reject Bytes In 0 Last Connect 01-Jan 00:00 Bytes Out 0 Last Name Password CMS Pass OTH Z	ink.org ts In 0 ts Out 0 Z Listed 0	

Forwarding to Winlink is Enabled


Housekeeping

BPQ32 BBS N0SZ

^B Housekeeping 192.168.11.114:8008/Mail/HK?M000077442E50 C Status Configuration Users Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu





*

☆

4

Connect out via RF

🕄 🖨 🕒 willem@bashful: ~
File Edit View Search Terminal Help
willem@bashful: \$ telnet 192.168.11.114 8010 Trying 192.168.11.114 Connected to 192.168.11.114. Escape character is '^]'. user:chris password:
AID2 BPQ32 Telnet Server Enter ? for list of commands
NOSZ} Connected to KONTS-1 [BPO-6.0.12.35-IHJMS]
Hello KD0ZYF. Latest Message is 2506, Last listed is 2506
73 de CTN BBS *** Disconnected from Stream 1
Connection closed by foreign host. willem@bashful:~\$ [

Connect in via RF (as AC0KQ)

🖸 🖨 🗐 👘 willem@bashful: ~

File Edit View Search Terminal Help

cmd c N0SZ cmd:*** CONNECTED to NOSZ Welcome to the Aid Station 2 BP032 Node. NOSZ> BBS CONNECT BYE INFO NODES ROUTES PORTS USERS MHEARD info NOSZ} This is the BPO32 Node for the Aid Station 2. Sysop KD0ZYF. Traffic left on this node will be forwarded using the National Traffic System. Type BBS to connect to the BBS. ports NOSZ} Ports 1 145.030 MHz 1200 bps 2 Telnet Server 3 AX/IP/UDP bbs NOSZ} Connected to BBS [BPO-6.0.12.35-IHJM\$] Hello ACOKQ. Latest Message is 2, Last listed is 2 de NOSZ> Ь *** DISCONNECTED cmd:

Connect via RF to WinLink

🕄 🗐 🗊 willem@bashful: ~

```
File Edit View Search Terminal Help
cmd:c N0SZ-10
cmd:*** CONNECTED to NOSZ-10
Trying brentwood.winlink.org
*** ACOKO Connected to CMS
[WL2K-3.2-B2FWIHJM$]
;PO: 72781840
Brentwood CMS via NOSZ >
lm
Login [246]:
Brentwood CMS via NOSZ >
CR 067MRW
Hello ACOKO
Brentwood CMS via NOSZ >
lm
2884 KOTER 2016/05/07 01:27 676 KOTER@Winlink.org OTC 2
3KYUXDSAP727 2016/05/02 15:51 889 K6HTN@Winlink.org Re: OTC 1 K6HTN
2882 KOTER 2016/05/04 16:40 1180 KOTER@Winlink.org OTC 4
6AQ9DQG3C59D 2016/05/04 18:30 1295 WA3QLW@Winlink.org OTC 8
2883 KOTER 2016/05/05 18:35 2281 KOTER@Winlink.org OTC 7
2868 KOTER 2016/05/03 17:26 2803 KOTER@Winlink.org OTC 9
2886 KOTER 2016/05/07 21:52 3103 KOTER@Winlink.org OTC 10
Brentwood CMS via NOSZ >
b
Disconnecting...
*** DISCONNECTED
cmd:
```

BBS Messages

Be Edit Messages - Chromium				4
C C ctnpi:8080/Mail/Msgs?M00	0039592D06			☆ =
	BPQ	32 BBS KONTS		
Status Configuration User	Messages Forwarding	Welcome Msgs & Prompts House	keeping WP Update Nod	e Menu
Filter From To To Via 2503 2498 2498 2497 2494 2493 2492 2491 2486 2485 2483 2482 2481 T	From ACOKQ To KOTER BID 2555 KONTS VIA Title QTC1P EditText Save G KONTS	Message 2555 Sent 08-May 21:40Z Received 08-May 21:40Z Last Changed 08-May 21:40Z HILA PA 215 276 Save Message Save Message Save Attachment reen = Sent, Yellow = Queued RMS	Type P Status F Size 210 Print Export	

General BBS Users

😹 🖻 💿 Edit Users - Chromium		
Control Con	039592D06	루☆ ☰
Status Configuration Users	BPQ32 BBS K0NTS Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Nod	<u>le Menu</u>
KB5YZB KCOJPO KCOONP KCOWDN KC4YLV KDOCIM KDOCRX KDOCRX KDOFDS KDOGBX KDOGBX KDOKVJ KDORML KDORNF KDORML KDORNF KDORML KDORNF KDORNF KDORNF KDORNF KDORNF KDORNF KDORNF KDOSQA KDOSQA KDOSQA KDOSQA KDOYGO KDOZYF KD8BQN KEOCRD	Update User KD0ZYF BBS Permit Email PMS RMS Express User SYSOP Poll RMS Expert For SSID'S Excluded Hold Messages Include SYSOP msgs in LM Don't add @winlink.org Allow Sending Bulls NTS MPS Connects In 6 Msgs in 0 Rejects In 0 Connects Out 0 Msgs Out 0 Rejects Out 0 Bytes In 0 Last Connect 08-May 20:122 Bytes Out 0 Last Listed 2507 Name KD0ZYF Password CMS Pass Update Delete Add Update Delete Add	

WinLink User Download

Solution Edit Users - Chromium		
C C Ctnpi:8080/Mail/Users?M000039	9592D06	¶☆ Ξ
Status Configuration Users M	BPQ32 BBS K0NTS essages Forwarding Welcome Msgs & Prompts Housekeeping WP Update No	de Menu
AA0QC AC0KQ AC0TG AC0VC AC9D AD0RX A18Z K0KAI K0LAI K0MEL K0MEL K0MEL K0MEL K0MEL K0MEL K0MEL K0XK K6DHN K0XK K6DHN K6XCQ KA0BSA KB0BSA KB1SGJ KB5YZB KB5YZB KC0JPO KC00NP KC0WDN KC4YLV	Update User ACOKQ BBS Permit Email PMS RMS Express User SYSOP Poll RMS Expert For SSID's Excluded Hold Messages Include SYSOP msgs in LM Don't add @winlink.org Allow Sending Bulls NTS MPS Connects In 9 Msgs in 42 Rejects In 0 Connects Out 0 Msgs Out 1 Rejects Out 0 Bytes In 10416 Last Connect 08-May 21:39Z Bytes Out 533 Last Listed 2514 Name Willem ZIP Password CMS Pass ZIP Update Delete Add	

Forwarding BBS

See Edit Users - Chromium		4
🔇 🕽 🥑 🗋 192.168.11.114:8080/Ma	il/Users?M0000399D835D	Q 🖧 🔳
Status Configuration User:	BPQ32 BBS N0SZ <u>Messages Forwarding Welcome Msgs & Prompts Housekeeping WP Update Node Menu</u>	
ACOKO KBISGJ KBSYZB KDOZYF NOSZ RMS	Update User KB1SGJ Image: BBS Permit Email Image: PMS RMS Express User SYSOP Poll RMS Expert For SSID's Excluded Hold Messages Include SYSOP msgs in LM Don't add @winlink.org Allow Sending Bulls NTS MPS Connects In 0 Msgs in 0 Rejects In 0 Bytes In 0 Last Connect 01-Jan 00:00Z Bytes Out 0 Last Listed 0 Name CMS Pass ZIP Home BBS Update Delete Add	

Forwarded Users



RF > NOSZ & AXIP > KONTS-1

🕄 🗐 🔲 willem@bashful: ~ File Edit View Search Terminal Help cmd:c N0SZ cmd:*** CONNECTED to NOSZ Welcome to the Aid Station 2 BPQ32 Node. NOSZ> BBS CONNECT BYE INFO NODES ROUTES PORTS USERS MHEARD ports NOSZ} Ports 1 145.030 MHz 1200 bps 2 Telnet Server 3 AX/IP/UDP c 3 KONTS-1 NOSZ} Connected to KONTS-1 [BPO-6.0.12.35-IHJM\$] CTN BBS> No New Messages CTN BBS> b 73 de CTN BBS *** DISCONNECTED cmd: cmd: cmd: cmd:

Setting up an iGate

- This iGate setup is on a BeagleBone Black
 - The only difference with an rPi is the serial port names in the Port section
- The Node setup is the same as what was done previously
 - Some but not all the parameters are relevant
- Ports are mapped as Packet or APRS in port configuration
 - You can have both Packet and APRS ports on the same BPQ node

Node Configuration (Note that Winlink RMS and Chat is NO)

File Edit Vie	ew Search Terminal Help	
AC0KQ bpq-c	config version 1.0	
ſ	Node Configuration	
	Set Parameter	
	Owner Name Rocky Mountain Ham Radio Grid Square DM79hm Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS No Chat Server No APRS iGate	
	<set> <finish></finish></set>	

Enable iGate

rite cuit view search lenninal neip	
AC0KQ bpq-config version 1.0	
APRS lGate	
Enable APRS iGate	
<yes> <no></no></yes>	

iGate APRS SSID 1 (note APRS specific new items)

File Edit Vie	ew Search Terminal Help	
AC0KQ bpq-0	config version 1.0	
	Set Parameter	
	Grid Square DM79hm Telnet Port 8010 FBB Port 8011 HTTP Port 8008 AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS No Chat Server No APRS iGate Yes APRS SSID	
	<set> <finish></finish></set>	

iGate APRS SSID 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 APRS SSID Enter APRS SSID (e.g. 11]) 14 <0k> <Cancel>

APRS Symbol Set 1 (used to set symbol on aprs.fi)

File Edit Vi	ew Search Terminal Help	
ΑC0KQ bpq-	config version 1.0	
	Node Configuration	
	Set Parameter	
	Telnet Port8010↑FBB Port8011HTTP Port8008AXIP Port10093AXIP AutoAddYesWinLink RMSNoChat ServerNoChat ServerNoAPRS iGateYesAPRS SSID14APRS Symset↓	
	<set> <finish></finish></set>	

APRS Symbol Set 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 APRS Symset Enter APRS Symset Single character or digit (e.g. B) B <Cancel> <0k>

APRS Symbol 1 (used to set symbol on aprs.fi)

File Edit View Search Termi	nal Help			
ACOKQ bpq-config version	1.0			
	Node	e Configuration		
Set Paramete	r.			
FBB HTTP AXIP AXIP WinL Chat APRS APRS APRS	Port Port AutoAdd ink RMS Server iGate SSID Symset Symbol	8011 8008 10093 Yes No No Yes 14 B		
	<set></set>	<fi< td=""><td>nish></td><td></td></fi<>	nish>	

APRS Symbol 2

File Edit Vie	/iew Search Terminal Help	
AC0KQ bpq-0	-config version 1.0	
	Enter APRS Symbol Single character or digit (e.g. a)	
	a	
	< <u><0k></u> <cancel></cancel>	

APRS Status Message 1 (used when beaconing)

File Edit Vi	'iew Search Terminal Help	
АС0КQ Ьрq-	-config version 1.0 Node Configuration Set Parameter	
	AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS No Chat Server No APRS iGate Yes APRS SSID 14 APRS Symset B APRS Symbol a	
	Status Message ↓ <set> <finish></finish></set>	

APRS Status Message 2

File Edit View	Search Terminal Help	
AC0KQ bpq-cont	ifig version 1.0	
	Status Message	
Er	inter Status Message (used in broadcast)	
RI	RMHAM iGate Conifer	
	<ok> <cancel></cancel></ok>	

iGate Latitude 1

File Edit Vi	iew Search Terminal Help	
ACOKQ bpq-	config version 1.0 Node Configuration Set Parameter AXIP Port 10093 AXIP AutoAdd Yes WinLink RMS No Chat Server No APRS iGate Yes APRS Symset B APRS Symbol a	
	Status Message RMHAM iGate Conifer Latitude <set> <finish></finish></set>	

iGate Latitude 2

File Edit Vie	w Search Terminal Help	
AC0KQ bpq-c	onfig version 1.0	
	Enter Latitude (ddmm.mm[NS])	ide
	3931.04N	
	<0k>	<cancel></cancel>
Ľ		

iGate Longitude 1

File Edit Vie	ew Search Terminal Help	
AC0KQ bpq-a	config version 1.0 Node Configuration Set Parameter	
	AXIP AutoAdd Yes WinLink RMS No Chat Server No APRS iGate Yes APRS SSID 14 APRS Symset B APRS Symbol a Status Message RMHAM iGate Conifer Latitude 3931.04N Longitude	
	<set> <finish></finish></set>	

iGate Longitude 2

File Edit Vi	iew Search Terminal Help	
ΑC0KQ bpq-	config version 1.0	
	Longitude Enter Longitude (dddmm.mm[EW]) 10521.00W	
	<ok> <cancel></cancel></ok>	

APRS2 Gateway 1 (where to send APRS reports)

	Nod	e Configurati	on	
Set Pa	rameter			
	WinLink RMS Chat Server APRS iGate APRS SSID APRS Symset APRS Symbol Status Message Latitude Longitude APRS2	No Yes 14 B a RMHAM iGate 3931.04N 10521.00W	Conifer	
	<set></set>		<finish></finish>	

APRS2 Gateway 2 (bpq-config generates password automatically)



Finish iGate Node Configuration

File Edit View Search Terminal Help

AC0KQ bpq-config version 1.0

Set Parameter	le Configuration	
Node Callsign Owner Acronym Owner Name Grid Square Telnet Port FBB Port HTTP Port AXIP Port AXIP AutoAdd WinLink RMS	NOSZ RMH Rocky Mountain Ham Radio DM79hm 8010 8011 8008 10093 Yes No	
<set></set>	<mark><finish></finish></mark>	

iGate Add Port Configuration

File Edit View Search Terminal Help			
AC0KQ bpq-config version 1.0			
Set Parameter	- Configure po	rt	
Set Fai aneter			
	Туре		
	Device Type		
	Frequency		
	Digipeat	Yes	
	Power Height		
	Gain		
<set></set>		<finish></finish>	

Set Port Type to APRS

File Edit View Search Terminal Help				
ACOKQ bpq-config version 1.0				
of port () Packet (*) APRS () APRS rx only				
<pre><select> <cancel></cancel></select></pre>				

Set Serial Port (Note that this is a Beaglebone so 4 ports)

File Edit View Search Terminal Help
ACOKQ bpq-config version 1.0
Device Type
Serial ports are numbered 1, 2, 4 or 5
(<mark>*</mark>) Serial () I2C
<select> <cancel></cancel></select>

Select Serial Port Number

File Edit Vie	ew Search Terminal He	lp		
AC0KQ bpq-o	config version 1.0			
	Set Parameter		port	
		Type Device Type Device Number	APRS Serial	
		Frequency Digipeat Power Height Gain	Yes	
	<set></set>	>	<finish></finish>	

Select Serial Port Number

File Edit View Search Terminal Help				
ΑϹΘΚQ bpq-c	config version 1.0			
	Device Number Enter Device Number Serial ports are numbered 1, 2, 4 or 5 1			
	<0k> <cancel></cancel>			

APRS Frequency 1

File Edit View Search Terminal Help						
AC0KQ bpq-c	config version 1.0 Set Parameter	— ⊂ Configure (port			
		Type Device Type Device Number Frequency Digipeat Power Height Gain	APRS Serial 1 Yes			
	<set></set>		<finish></finish>			

APRS Frequency 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 Frequency Enter Frequency kHz e.g. 145050 144390 <0k> <Cancel>

Finish Port Configuration

File Edit View Search Terminal Help						
ACOKQ bpq-config version 1.0						
Set Parameter	Configure	port				
Set Parameter						
	Туре	APRS				
	Device Type	Serial				
	Frequency	144390				
	Digipeat	Yes				
	Power	40 50				
	Gain	6				
	sets	Einisha				
		SI CITOSIIZ				
Node Page Update



APRS Main Page

14 S BPQ32 W ×	8080/aprs/all.hi	:ml							Q						
Home All Stations	I	N0SZ-14's BPQ32 APRS Web Server													
RF Stations	All Stations														
All WX Stations	The last	(This page will automatically refresh every five minutes)													
RF WX Stations		(This page will automatically fellesit every live initiates)													
All Mobile Stations	1	he followin	g is a list (of all the stat	on the inte	in the past	120 minute	s,							
RF Mobile Stations	-		T												
All Objects		click a	callsion to	re are 21 call	signs in th	ge for that	station.								
RF Objects		enen u	eunsign e	o get un mitor	mation pu	50 for that	Station	_							
Information	AC0VP-10	BVILLE	KB0USF	KC0D	KC0D-6	KC0WUV	KD0SQA-4	NOEB							
Node Pages	NOLNE	N0SZ-14	<u>N0SZ-2</u>	N0WGM-3	N1GEP-1	<u>N7GN-5</u>	W0JAW	W0JRL-15							
	WA0GEH	WB5PJB-B	WD4IXD	WD4IXD-10	<u>WQ8M-9</u>										

APRS RF Stations

🔊 🗇 🗊 🛛 NOSZ-14's BPQ32 Web Server - Chromium

NOSZ-14's BPQ32 W ×

🗋 192.168.11.114:8080/aprs/allrf.html

Home
All Stations
RF Stations
All WX Stations
RF WX Stations
All Mobile Stations
RF Mobile Stations
All Objects
RF Objects
Information
Node Pages

N0SZ-14's BPQ32 APRS Web Server

1

२☆ =

RF Stations

(This page will automatically refresh every five minutes)

The following is a list of all the stations heard on RF in the past 120 minutes.

'*' after a callsign means that it was heard via a digi

The list only includes callsigns heard on RF, direct or via digipeaters. It does not include callsigns heard on the internet, or heard as third-party RF traffic via IGATEs.

There are 8 callsigns in the list, click a callsign to get an information page for that station.

Callsign	Symbol	Location	Miles	Bearing	Last heard		
KC0D	No. Digi	39°22.20'N 104°40.76'W	37.2	106	02:17:57		
KC0D-6*	WX Station	39°18.13'N 104°41.32'W	38.3	113	02:20:18		
KD0SQA-4*	Digi	39°40.14'N 104°55.46'W	25.0	65	02:16:58		
NOEB	XAPRS	39°53.56'N 104°58.15'W	32.9	38	02:21:22		
<u>N0SZ-2*</u>	Car	40°07.90'N 104°55.73'W	47.9	28	02:19:20		
N0WGM-3*	WX Station	40°48.92'N 104°47.64'W	94.3	18	02:20:59		
NIGEP-1*	Rover	39°40.36'N 104°45.90'W	32.9	71	02:18:02		
<u>N7GN-5*</u>	WX Station	40°32.73'N 105°05.53'W	72.3	11	02:19:50		

APRS Station Map

🕒 💿 🛛 N0SZ-14's BPQ32 Web Server - Chromium

[₽] N0SZ-14's BPQ32 W ×

192.168.11.114:8080/aprs/find.cgi?call=N0SZ-2

Home
All Stations
RF Stations
All WX Stations
RF WX Stations
All Mobile Stations
RF Mobile Stations
All Objects
RF Objects
Information
Node Pages

N0SZ-14's BPQ32 APRS Web Server

1

요☆ =

(This page will automatically refresh every five minutes)

Information about <u>N0SZ-2</u> Click the callsign to look it up on qrz.com Location: 40°07.90'N 104°55.73'W The bearing from N0SZ-14 to N0SZ-2 is 028 degrees, the distance is 47.9 Miles

Last posit: TPPWYP,W0UPS-5,WIDE1,KC0D,WIDE2*

Status: Last heard 00:05:11 ago



Report on aprs.fi



Data graph on aprs.fi

See Station	ation statistics for I	NOSZ-14 – Google Ma	aps APRS - Chromium			(±)
<>C	🗋 aprs.fi/info/gra	phs/a/N0SZ-14				☆ =
Station info -	map view · info · telem	etry · weather · raw · st	atus • beacons • messages •	bulletins · browse · i	moving · my account	
Callsign or sh	ip name: N0SZ-14	Search Clear	Completed generating	statistics (took 0.0	064 s).	
	▶ AdChoices	► Satellite	Google Maps	► ISS	Space Station	
Station sta	tistics for NOSZ-14 🧃	- info				
Packets tran packets / hour 12.5 10.0 7.5 5.0	smitted by N0SZ-14: 2	016-05-07 07:00:00 ->	2016-05-09 07:24:43 MDT			
2.5						
May 7 8:00	May 7 16:00	May 8 0:00 May	8 8:00 May 8 16:00	May 9 0:00		

New positions for N0SZ-14: 2016-05-07 07:00:00 -> 2016-05-09 07:24:43 MDT

Adding device ports

- Beaglebone has 5 serial ports
 - Stack 4 TNC-Blacks
 - Attach external devices via headers
- Raspberry Pi has 1 serial port
 - Access TNC-Pi via I2C bus
 - Requires reprogramming of TNC-Pi

Reprogramming TNC

- Disable BPQ to have exclusive access to the TNC device
 - systemctl disable bpq.service
 - systemctl stop bpq.service
- Turn off power between steps
- Enable BPQ when done
 - systemctl enable bpq.service
 - systemctl start bpq.service

Enable I2C kernel modules

⊗● willem@aid2: ~

File Edit View Search Terminal Help

A1 Overscan	You may need to configure oversca 1
A2 Hostname	Set the visible name for this Pi
A3 Memory Split	Change the amount of memory made
A4 SSH	Enable/Disable remote command lin
A5 Device Tree	Enable/Disable the use of Device
A6 SPI	Enable/Disable automatic loading
A7 I2C	Enable/Disable automatic loading
A8 Serial	Enable/Disable shell and kernel m
A9 Audio	Force audio out through HDMI or 3
AA GL Driver	Enable/Disable experimental deskt ↓

<Select>

<Back>

Check current parameters

🖸 🗐 🗊 willem@aid2: ~/BPQ File Edit View Search Terminal Help willem@aid2:~/BPQ sudo ./pitnc_getparams 0 0 Using Serial port /dev/ttyAMA0 PIC Software Version 1 01 TXDelay - Zero means use ADC 40 02 Persistance 64 03 Slottime (in 10 mS) 10 04 TXTail 0 05 Full Duplex - Not used 0 06 Our Channel (Hex) 00 07 I2C Address (0 = async) Hex 00 ADC Value 69 8 1 28 40 a 0 0 0 0 45 2e c0 sum 0 willem@aid2:~/BPO \$

Set I2C address to 16 (0x10)

🕲 🖨 🔲 willem@aid2: ~/BPQ		
File Edit View Search Terminal Help		
<pre>willem@aid2:~/@0 \$ sudo ./pitnc</pre>	_setparams 0 0 7 16	
PIC Software Version	1	
01 TXDelay - Zero means use ADC	40	
02 Persistance	64	
03 Slottime (in 10 mS)	10	
04 TXTail	0	
05 Full Duplex - Not used	0	
06 Our Channel (Hex)	00	
07 I2C Address (0 = async) Hex	10	
ADC Value	69	
8 1 28 40 a 0 0 0 10_45 3e c0 su	m O	
willem@aid2:~/BPQ \$		

Power off&on and check

🗙 🖨 🔲 willem@aid2: ~																					
File	Edi	tν	'iew	Sea	arch	Ter	min	al F	Ielp												
will	lem(jai	d2:	~\$	suc	lo i	i2co	dete	ect	- y	1										
	0	1	2	3	4	5	6	7	8	9	а	ь	С	d	e	f					
00:																					
10:	10																				
20:																					
30:																					
40:																					
50:																					
60:																					
70:																					
will	lem(ai	d2:	~ \$																	

Check parameters

params 1 16	
1	
40	
64	
10	
0	
0	
00	
10	
69	
m 0	
	params 1 16 1 40 64 10 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0

Adding a Second RF Port

- Must use I2C since rPi has only one serial port
- Convert first TNC to I2C before mounting second TNC
- Test it to make sure it works
- Add second TNC
- Power down between steps

Set I2C addres for 2nd TNC

😢 🕒 willem@aid2: ~	
File Edit View Search Terminal Help	
<pre>willem@aid2: sudo ./pitnc_set</pre>	params 0 0 7 17
DIG Goffware Warden	
PIC Software Version	1
01 TXDelay - Zero means use ADC	40
02 Persistance	64
03 Slottime (in 10 mS)	10
04 TXTail	0
05 Full Duplex - Not used	0
06 Our Channel (Hex)	00
07 I2C Address (0 = async) Hex	11
ADC Value	62
8 1 28 40 a 0 0 <u>0</u> 11 3e 44 c0 su	m O
willem@aid2:~ \$	

Reboot and check

8	••	w	ille	m@a	aid2	: ~/B	BPQ													
File	Edi	t V	iew	Sea	arch	Ter	min	al H	Help											
wil	lem(aid	2:	~/BF	PQ (sı	obu	i20	cdet	tect	t - 1	y 1	>							
	0	1	2	3	4	5	6	1	8	9	а	Ь	C	d	e	f				
00:																				
10:	10	11																		
20:																				
30:																				
40:																				
50:																				
60:																				
70:																				
wil	lem@	aid	2:	~/B	PQ \$	5														

BPQ Port 1

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 Port Configuration Select port to 1 Add port 2 Delete port 3 Port 1 4 Port 2 <Select> <Finish>

Port 1 is for BBS/RMS

File Edit View Search Terminal Hel	P		
AC0KQ bpq-config version 1.0			
	Configure		
Set Parameter	,		
	Туре	Packet	
	Device Type	Serial	
	Device Number	1	
	Frequency	145050	
		10	
	Height	50	
	Gain	6	
<set></set>		<finish></finish>	

BPQ Port 2

File Edit View Search Terminal Help AC0KQ bpq-config version 1.0 Port Configuration Select port to 1 Add port 2 Delete port 3 Port 1 4 Port 2 <Select> <Finish>

Port 2 is for APRS

File Edit View Search Terminal AC0KQ bpq-config version 1.	Help .0		
Set Parameter	Configure	port	
	Type Device Type Device Number Frequency Digipeat Power Height Gain	APRS Serial 2 144390 Yes 50 50 6	
<	Set>	<finish></finish>	

BPQ Ports Page



← → C ① 192.168.11.88:8008/Node/Ports.html

BPQ32 Node N0SZ-7

☆

÷

Routes Nodes Ports Links Users Stats Terminal Driver Windows Stream Status APRS Pages Mail Server Pages SYSOP Signin Edit Config

Ports

Port	Driver	ID	Beacons
1	ASYNC	145.050 MHz 1200 bps	Beacons
2	ASYNC	144.390 MHz 1200 bps	Beacons
3	TELNET	Telnet Server	
4	BPQAXIP	AX/IP/UDP	Beacons

Advanced Configuration

				1
^в ро 192.168	3.11.88:8008/ ×			4
\leftrightarrow \Rightarrow C (① 192.168.11.88:8008/Node/EditCfg.html		\$:
	; RMH BBS & RMS & APRS iGate config File SIMPLE defaults NODECALL=N0SZ-7 LOCATOR=DM79hm LINMAIL IDINTERVAL=10 IDMSG: Rocky Mountain Ham Radio BBS & RMS & APRS iGate. ***	<pre>; This set a whole load of paramters to reasonable ; Default node callsign ; Defailt node location ; Enable BBS ; UI broadcast interval (minutes) ; UI broadcast text Connect to N0SZ-1 & N0SZ-10. ; Connect Message</pre>	X	•
	Welcome to the Rocky Mountain Ham Radio BPQ32 Noo NOSZ> BBS RMS CONNECT BYE INFO NODES ROUTES PORTS *** BTINTERVAL=10 BTEXT: Rocky Mountain Ham Radio BBS & RMS & APRS iGate. *** INFOMSG: This is the BPQ32 Node for the Rocky Mountain Ham	de. 5 USERS MHEARD ; Beacon interval (minutes) ; Beacon text Connect to N0SZ-1 & N0SZ-10. ; Text for INFO command m Radio.		

Save Cancel

Adding a new service

- BPQ adds new services via TCP/IP
- BPQ connects to local port
- Received stream piped to stdin
- Transmits output from stdout
- First line is connected station call

Monitor service

- Written in Perl
- Interprets commands
- Used to get system time and disk
- Bye to exit
- Mapped to N0SZ-2 and port 8004

Command Port

C 192.168.11.114:8080/Node/EditCfg.ht	ml	Q th
ENDPORT		•
PORT ID=Telnet Server DRIVER=TELNET CONFIG LOGGING=1 DisconnectOnClose=1 TCPPORT=8010 FBBPORT=8011 HTTPPORT=8080 CMDPORT=8080 CMDPORT=8080 CMDPORT=8080 CMDPORT=source LOCALECHO=N0 MAXSESSIONS=10 CTEXT=AID2 BPQ32 Telnet Server\nEnf USER=chris,XYZ123,KD0ZYF,,SYSOP USER=willem,ABC123,AC0KQ USER=john,ABC789,W0VG CMS=1 CMSCALL=N0SZ CMSPASS=secret ENDPORT	PORTS command text TCP/IP connection Driver specific configuration from here to ENDPORT Log all connections Disconnect on close Port for telnet connections Port for FBB protocol BBS connections Port for monitor Telnet login prompt Telnet login prompt Telnet login prompt Do not echo input Maxmimum simultaneous connections ter ? for list of commands\n\n ; Telnet connect message Telnet user Telnet user Telnet user Enable WinLink CMS connection Callsign for WinLink Password for WinLink	

Application

192 168 11 114:8080/Node/Edit	Fa btml	Θ.2	5 =
7 C 192.100.11.114.8080/140de/Edic	crg.num	42	5 =
PORT ID=AX/IP/UDP DRIVER=BPQAXIP QUALITY=220 MINQUAL=165 MAXFRAME=5 FRACK=3000 RESPTIME=1000 RETRIES=5 PACLEN=236 CONFIG MHEARD UDP 10093 AUTOADDMAP BROADCAST NODES MAP K0NTS argon.schreuder.us MAP N4ATA n4ata.dyndns.org MAP KD0DPX 192.168.11.88 ENDPORT APPLICATION 1,BBS,,N0SZ-1,AID2BB APPLICATION 2,RMS.C 3 CMS.N0SZ-1 APPLICATION 3,MON,C 3 HOST 0,N0S APPLICATION 32,TALK,,N0SZ	<pre>; Displayed by PORTS command ; Uses BPQAXIP ; Quality factor applied to node broadcasts heard on ; Entries in the nodes table with qualities greater or ; Max outstanding frames (1 thru 7) ; Level 2 timeout in milliseconds ; Level 2 delayed ack timer in milliseconds ; Level 2 delayed ack timer in milliseconds ; Level 2 maximum retry value ; Maximum packet length ; Driver specific configuration from here to ENDPORT ; Keep heard stats ; UDP port ; Automatically add new connections ; Broadcast UDP 10093 B ; AXIP to KONTS UDP 10093 B ; AXIP to N4ATA UDP 10093 B ; AXIP to KDODPX S,255 ; BBS Application 0.AID2RMS.255 ; CMS Application ; INC Application ; INC Application</pre>		

Save Cancel

systemd Socket Service

/lib/system/systemd/mon.socket /lib/system/systemd/mon@.service

[Unit] Description=MON socket

[Socket] ListenStream=8004 Accept=yes

[Install] WantedBy=sockets.targ et [Unit] Description=MON server

[Service] ExecStart=/home/willem/BPQ/mon. pl StandardInput=socket

mon.pl

```
#!/usr/bin/perl -w -T
# Monitor server
# Willem ACOKO
use strict;
SENV{PATH} = '/bin';
# Set autoflush
my Sold fh = select(STDOUT);
| = 1;
select($old fh);
# Read callsign of connecting station
my $call = <STDIN>;
$call =~ s/^\s*//;
$call =~ s/\s*$//;
#
   Match command
#
sub match
{
   my ($cmd,$pat) = @_;
   $pat = substr($pat,0,length($cmd));
   return (Spat eq Scmd);
}
# Welcome message
print "NOSZ Monitor\nConnect from 'Scall'\n> ";
```

```
# Read lines
while(my $line = <STDIN>)
   # Split on whitespace
  my (Scmd,@line) = split(' ',Sline);
   $cmd = defined($cmd) ? lc $cmd : '';
   # Do nothing
   if (Scmd eq '')
   {
   }
   # Help
   elsif(Scmd eq '?')
   £
      print "Commands: time disk bye\n";
   }
   # Bye
   elsif (match($cmd, 'bye'))
   {
      die "73 $call\n";
   }
   # Print time
   elsif (match($cmd, 'time'))
   {
      print "Time ".localtime(),"\n";
   }
   # Print disk usage
   elsif (match($cmd,'disk'))
   {
     my @disk = `df -kh /`;
     my (undef, $size, $used, $avail, $pct) = split(' ', $disk[1]);
      print "Disk size=$size used=$used ($pct) available=$avail\n";
   }
   else
   # Unknown command
   {
      print "Unknown command $cmd args @line\n";
   }
   # Print command prompt
   print "NOSZ> ";
```

Enable the service

Enable and start the service

- sudo systemctl enable mon.socket
- sudo systemctl start mon.socket

```
🕄 🗐 🕕 willem@bashful: ~
File Edit View Search Terminal Help
cmd c NOSZ-2
cmd:*** CONNECTED to NOSZ-2
Connected to
NOSZ Monitor
Connect from 'ACOKQ'
> ?
Commands: time disk bye
NOSZ> t
Time Sun May 8 17:48:49 2016
NOSZ> d
Disk size=15G used=3.5G (26%) available=11G
NOSZ> b
73 ACOKO
*** DISCONNECTED
cmd:
```

Time

- rPi and BBB does not have a real time clock, sets time using NTP
- If network does not recover after power failure, messages may be purged
- Add DS1307 RTC from Adafruit or similar device



Power Backup

- With a 6600 mAh LiPo battery the PowerCape will run a BB and TNC for more than a day
- Controlled shutdown on low battery



Beaglebone Notes

- The BB configuration is similar except that up to 4 TNC can be run as /dev/ttyO1 -/dev/ttyO5
- *mkbpq* puts web configuration on port 8008 since 8080 is used

What breaks BPQ

- Things that mess with serial and I2C
 - Raspberry Pi 3 (bluetooth, CPU freq)
 - getty on rPi
 - Debian 8 on Beaglebone
- Use Isof and i2c-tools to debug
 - If BPQ receives (stations in *mh*) but no transmit, a device clash is likely
- Run sudo ./pilinbpq from command line

Updating BPQ

- BPQ is updated regularly
- bpq-config Download will dowload the latest version of executables and the matching HTML pages
- After downloading restart BPQ

BPQ with external TNC

- BPQ supports Pactor modems including channel steering
- Attach via serial port
- Configure in BPQ
 - DRIVER=SCSpactor
 - **RIGCONTROL** to steer

About bpq-config

- bpq-config is designed to get you started
 - It covers most installations, but not all
- It keeps its on configuration file .bpqconfig
 - Easier to parse
 - Hand edits are lost when using bpq-config
 - Version 1.1 may parse bpq32.cfg instead
- This is new software
 - Bug reports and improvements are welcome
 - Patches are even more welcome
Part 3 AllStarLink Repeater

What is AllStarLink?

- Asterisk VOIP software for radio
- Interfaces with radio via URIx
 - CM119 USB audio chip
 - DB25 connector
- Can roll your own with equivalent fob





Installing AllStarLink

- Download from www.hamviop.com
 - Burn image to SD card
- Program your radio/repeater
 - Set radio to encode/decode CTCSS
 - On Motorola set accessories to output COS & PL on pin 8
- Tune a receiver to to the radio frequency
- Power up rPi
 - Allison will announce the IP address

Initial Login (password is root)

🛚 🕒 🔲 🖉 willem@bashful: ~

File Edit View Search Terminal Help

willem@bashful:~\$ ssh -p 222 root@192.168.100.237 root@192.168.100.237's password: RPi2-3 Version 1.02beta Allstar - March 26, 2016 - WA3DSP, KB4FXC, W0AMN

It appears that this is the first time this system has been booted. It would be prudent to change a few key settings now for the sake of security and convenience. Once this information is entered, the system will reboot and the next time the system boots, this message will not re-appear.

Enter new UNIX password: Retype new UNIX password: passwd: password updated successfully Enter Node Number: 40552

Set Time Zone 1

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Time Zone Configuration

By default, the time zone is set to:

Time zone: American/Eastern

A correct time zone entry will allow the system clock to report the correct time.

Do you want to change the default time zone (American/Eastern) ([y],n) ? 🗌

CW or Voice ID

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Asterisk can use either voice or CW id for FCC identfication. If you select voice id a simple gsm voice ID audio file will be generated. This file is located at "/etc/asterisk/local/" and is called "node_id.gsm".

If you select "y" to voice id, then a voice id will be created. If you select "n", then the default CW id will be used.

Do you want to use voice id ([n],y): ?

Network Port

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Port 4569 is the default iax protocol port. If you are using just one server on your public IP address, then you can skip this step by hitting return to select the default value.

Enter Bind Port [4569]:

Duplex

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Duplex setting

This setting setups up the different duplex modes for your allstar node. Here are the values and their meaning:

- 0 = half duplex (telemetry and courtesy tones do not transmit)
- 1 = semi-half duplex (telemetry and courtesy tones transmit, but not repeated audio (Default)
- 2 = normal full-duplex mode)
- 3 = full-duplex mode, without repeated audio from main input source
- 4 Normal except no main repeat audio during autopatch only

Normally for a simplex node, you would choose "1". For a repeater, you would choose "2".

If you want a "silent" simplex node (no courtesy tones or telemetry), you would choose "0".

Enter the desired duplex mode [1]:

Node Password

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

The node password is the password that is assigned with your node number. If you don't have this handy it can be retrieved by logging into your account at allstarlink.org and checking node 40552 password. The password is a 6 digit number.

Enter Node password for node 40552 []:



🛚 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Asterisk Allstar has the capability to receive connections from a Windows computer using a program called iaxRpt. In order to do this you need to specify a password which will be used to confirm connections from that program. You would then use this same password to configure a iaxRpt account on a Windows computer. Information on how to configure iaxRpt can be found at the hamvoip.org website.

Do you want to configure the password for an iaxrpt connection ([y],n): ? n

Simple USB Configuration 1

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

You now will need to review and configure simpleusb.conf. In particular the 'carrier from' needs to be set to match your radios COS polarity. See the configuration howto on the hamvoip.org web page for more info on configuring simpleusb and setting audio levels.

Do you want to configure Simple USB settings now: ([n],y): 🛛 y

Simple USB Configuration 2

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

[Introduction of script] This script will create the configuration file for the simple usb device.

During each setting, you will see the currently defined setting followed by a description of the values. You will be prompted with a simple yes or no question.

NOTE, you can run this script as many times as required. It will remember the last setting used. If it's run for the first time, you will be prompted for a radio selection which will load its default settings. Please review these settings when you are prompted and change if necessary.

```
Do you wish to continue: ([n],y): ? y
```

Select Radio

800	willem@bashful: ~
File Edit	View Search Terminal Help
0 - GM30 1 - GM30 2 - Dorg 3 - Alin 4 - Baon 5 - defa If radio	00_cos_invert 00_cos_noninvert ji_Transceiver_Module nco_DRx35 feng_ba-666 ault o type is not shown above, select 'default'
Enter nu	umber from above to select radio type: 5

EEPROM on URI



URI Type

Willem@bashful:~
File Edit View Search Terminal Help
Hardware Type setting
hdwtype=0
; USB Sound Adapter Hardware Type
; Set to 0 for DMK Eng. URI, or USB sound adapaters
; modified using the instructions from usbfob.pdf.
; Set to 1 for DingTel/W9SH modified usb adapters.
(To be removed, use default hdwtype=0, only option for bbb is hdwtype=0)
Answer "n" to this question, if using a URI or modified FOB.
Are you using a Dingotel/Shp interface ([n],y): ? []

Audio Boost

Willem@bashful: ~
File Edit View Search Terminal Help
Reciever Audio Boost
rxboost=1
; Rx Audio Boost
; 0 = 20db attenuator inserted,
; 1= 20db attenuator removed
; Set to 1 for additonal gain if using a low-level
; receiver output.
Answer "y" if you are using a low-level receiver output.
Should the receive audio be boosted (attenuator removed) ([y],n): ? []

Carrier Detect (COR or COS)

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Carrier Detection carrierfrom=usbinvert

> ; Options - no,usb,usbinvert ; no - no carrier detection at all ; usb - via USB radio adapter COR connection ; usbinvert - same as above but inverted polarity.

Normally, you will be using this option. This is the COS (carrier detection) which indicates that a carrier is present. This signal comes for the radio to the modified FOB or URI. This supports the option to invert the detected signal which depends on the radio.

Do you want to use carrier detection ([y],n): ?

Does the COR line need to be inverted ([y],n): ?

CTCSS Decode

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

CTCSS Decoding ctcssfrom=no

> ; CTCSS Decoder Source ; Options = no,usb,dsp ; no - CTCSS decoding, system will be carrier squelch ; usb - CTCSS decoding using input from USB adapter ; usbinvert - same as above but inverted polarity.

> >

Some radios use the CTCSS signal to indicate that a CTCSS signale is preset, like COS, it provides a method of signal detection and indicates that a carrier is present. This signal comes for the radio to the modified FOB or URI. This supports the option to invert the detected signal which depends on the radio.

Do you want to use CTCSS decoding ([n],y): ?

Transmit Left Channel

🗴 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

TX Mixer A

txmixa=voice

; Tx Mix Output Channel A (Left) Output Type ; Options = no,voice,tone,composite,auxvoice ; no - Do not output anything ; voice - output voice only ; tone - CTCSS tone only ; tone - CTCSS tone only ; composite - voice and tone ; auxvoice - voice output for monitoring ; Left channel output: no,voice,tone,composite,auxvoice

; no - Do not output anything

; voice - output voice only

The current value for this parameter is: voice. Nomally, this is set for "composite".

Do you want to change the TX Mix A setting ([n],y): ? 🗌

Transmit Right Channel

🗴 🗖 🗉 🛛 willem@bashful: ~

File Edit View Search Terminal Help

```
Transmit Mixer B
txmixb=no
```

; Tx Mix Output Channel B (Left) Output Type ; Options = no,voice,tone,composite,auxvoice ; no - Do not output anything ; voice - output voice only ; tone - CTCSS tone only ; composite - voice and tone ; auxvoice - voice output for monitoring

The current value for this parameter is: no. Nomally, this is set for "no".

Do you want to change the TX Mix B setting ([n],y): ?

PTT
SOO willem@bashful:~ File Edit View Search Terminal Help
PTT Setting invertptt=0
; Invert PTT 0 = ground to transmit, 1 = open to transmit ; This is the collector lead of the 2n4401 on the modified ; usb sound fob.
Please refer to the howto for the procedure to do this.
Should the PTT be grounded to transmit ([y],n): ? []

Filter CTCSS

🗴 🗖 🗊 willem@bashful: ~
File Edit View Search Terminal Help
PL Filter Setting plfilter=yes ; enable PL filter ; yes, enabled ; no, disabled
Only use if necessary for your installation Some radios require addtional filtering the the PL tones, this will help attenuate this signal from the receiver.
Should the plfilter be enabled ([y],n): ? []

Flat or Speaker Audio



Flat or Mic Audio



Audio Delay

🗴 🗖 🗊 willem@bashful: ~
File Edit View Search Terminal Help
rxaudiodelay parameter rxaudiodelay=0 ; default value is 0 ; Squelch tail delay in 20ms frames. Values are 0 ; (no delay) to 24 (480ms delay) ; Typical values would range from 3-12 (60-240ms)
Please refer to the documentation prior to changing from the default value.
Enter the value of rxaudiodelay [0] :

Set Audio Levels

😮 🗖 🔲 willem@bashful: ~

File Edit View Search Terminal Help

Audio Levels

If you know the audio values for your node setup, you can modify them now. If not, please run "simpleusb-tune-menu" program at the Linux prompt to properly set your sound levels.

Do you want to set your audio levels for your node now ([n],y): ? y

Receive Audio Levels

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

RX Mixer Value rxmixerset=500

This value sets the Receiver Audio Levels or incoming audio levels "from" the node radio.

Enter the new value for the RX Mixer Level [500]:

Transmit Left Audio Levels

🛚 🕒 🔲 willem@bashful: ~

File Edit View Search Terminal Help

TX Mixer A Value txmixaset=500

This value sets the Transmit Audio Levels or outgoing audio on the A output side "to" the node radio.

Enter the new value for the TX Mixer A Level [500]:

Transmit Right Audio Levels

😕 🗖 🔲 🛛 willem@bashful: ~

File Edit View Search Terminal Help

TX Mixer B Value txmixbset=500

This value sets the Transmit Audio Levels or outgoing audio on the B output side "to" the node radio.

Enter the new value for the TX Mixer B Level [500]:



File Edit View Search Terminal Help
(final info)
After any simpleusb.conf changes you should do an Asterisk restart. This
will restart and reload the Asterisk modules. These simpleusb changes will
not take effect until Asterisk is restarted.
If needed, please run "simpleusb-tune-menu" program at the Linux prompt to set
your sound levels.
Do you want to restart Asterisk to enable selections: ([y],n): ?
Restarting Asterisk..
[root@pi40552 ~]#]

Make it Transmit

🗴 🗖 🗊 root@pi40552:~

File Edit View Search Terminal Help

- -- <DAHDI/pseudo-917589702> Playing 'digits/2' (language 'en')
- -- <DAHDI/pseudo-917589702> Playing 'digits/20' (language 'en')
- -- <DAHDI/pseudo-917589702> Playing 'digits/p-m' (language 'en')
- -- Hungup_'DAHDI/pseudo-917589702'

pi40552*CLI>

Set Levels

🗴 🗖 🗊 root@pi40552:/etc/asterisk		
File Edit View Search Terminal Help		
[root@pi40552 asterisk]# simpleusb-tune-menu		
active (command) USB Radio device is [usb] 1) Select USB device 2) Set Rx Voice Level (using display) 3) Set Transmit A Level		
 4) Set Transmit B Level E) Toggle Echo Mode (currently Disabled) F) Flash (Toggle PTT and Tone output several times) P) Print Current Parameter Values S) Swap Current USB device with another USB device T) Toggle Transmit Test Tone/Keying (currently Disabled) W) Write (Save) Current Parameter Values 		
0) Exit Menu Please enter your selection now:		

Set Receive Levels



/etc/asterisk/simpleusb.conf

Configuration for Motorola SM50

[usb] eeprom=0 hdwtype=0 rxboost=1 carrierfrom=usb ctcssfrom=usb txmixa=voice txmixb=no invertptt=0 duplex=0 plfilter=yes deemphasis=no preemphasis=yes rxaudiodelay=0



Update /srv/httpd/index.html

<html> <head> <title>40552</title> </head> <body> Node 40552
AllMon
<a href=cgi-bin/lsnodes web?node=40552>lsnodes </body> </html>

Edit AllMon Files

- Edit /srv/httpd/allmon2/allmon.ini.php
 - Change XXXXX to node number
 - Change passwd
- Edit /etc/asterisk/manager.conf
 - Add the same password to secret =
- Restart allstar
 - astres.sh
AllMon2

Allmon 40552 - Chromiu	m				
Pi40552/allmon2/link.php?nodes=40552					위 ☆ I
• Monitor World One Node at a	II Time		2	AIIS	tar nk
52 Login					
No	de <u>40552</u> -	ubble Chart			
		100010000	Contraction of the second		Constant Constant Constant
	Allmon 40552 - Chromit on 40 × 10552/allmon2/link.php?r Morid One Node at a 552 Login	Allmon 40552 - Chromium on 40 × 10552/allmon2/link.php?nodes=40552 Monitor II World One Node at a Time 552 Login Node <u>40552</u> -	Allmon 40552 - Chromium on 40 × 10552/allmon2/link.php?nodes=40552 • Monitor II World One Node at a Time 552 Login Node <u>40552</u> - <u>Bubble Chart</u>	Allmon 40552 - Chromium on 40 × 10552/allmon2/link.php?nodes=40552 Monitor II World One Node at a Time 552 Login Node <u>40552</u> - <u>Bubble chart</u>	Allmon 40552 - Chromium on 40 × 10552/allmon2/link.php?nodes=40552 Monitor II World One Node at a Time 552 Login Node <u>40552</u> - <u>Bubble Chart</u>

Set AllMon Login

- Set AllMon2 user name(s) and password(s)
 - cd /srv/http/allmon2
 - htpasswd -cd .htpasswd admin
 - htpasswd -d .htpasswd <userid>
- Password can only contain A-Z a-z 0-9
 - If you want to use aditional characters change login.php line 28 from if(!ctype_alnum(\$pass)){

if(preg_match("[^A-Za-z0-9\.\!\\$]",\$pass)){ including all the characters you want to allow

Base Access

🛞 🗐 🗊 40552 - Chromium
□ 40552 ×
Node 40552 AllMon
Isnodes

Isnode

🙉 🖨 🗊 🛛 Allstar Connected Nodes and Status - Chromium

Allstar Connected N ×

C pi40552/cgi-bin/lsnodes_web?node=40552

Status for AC0KQ - Node 40552 Last update - 05/11/2016 20:04:14 My IP - 66.109.219.132

View this Node Graphically Search/Command another Node

Selected system state	0
Signal on Input	NO
System	ENABLED
Parrot Mode	DISABLED
Scheduler	ENABLED
Tail Time	STANDARD
Time out timer	ENABLED
Incoming connections	ENABLED
Time out timer state	RESET
Time outs since system initialization	0
Identifier state	CLEAN
Kerchunks today	7
Kerchunks since system initialization	7
Keyups today	12
Keyups since system initialization	12
DTMF commands today	1
DTMF commands since system initialization	1
Last DTMF command executed	81
TX time today	00:00:44211
TX time since system initialization	00:00:44211
Uptime	01:25:06
Nodes currently connected to us	
Autopatch	ENABLED
Autopatch state	DOWN
Autopatch called number	N/A
Reverse patch/IAXRPT connected	DOWN
User linking commands	ENABLED
User functions	ENABLED

Node 40552	NodeCallDescription40552ACOKQ446.200		Description 446.200	on <u>Location</u> portable		
Node	Peer	Reconnects	Direction	Connect Time	Connect State	
Host 67.215.	233.178:4	4569	Node 40552	State Registered		

1

Ξ

53

AllMon2

 PI40552 Allmon 4 × ← → C □ pi40552/allmon2/link.php?nodes=40552 Allstar Monitor II Monitoring the World One Node at a Time About 40552 Logout 	r☆ : ar
 ← → C □ pi40552/allmon2/link.php?nodes=40552 Allstar Monitor II Monitoring the World One Node at a Time About 40552 Logout 	r ☆ : ar
Allstar Monitor II Monitoring the World One Node at a Time About 40552 Logout	ar
	K
29571 Permanent	
Connect Disconnect Monitor Local Monitor Control Panel	
Node 40552 - ACOKQ 446.200 portable Bubble Chart	
Node Node Information Received Link Direction Connected Mode	
No connections.	

Connect to node 29571

800	PI40552 Al	llmon 40552 - Chromiur	n					
D PI	40552 Allmon	4 ×						<u> </u>
$\leftarrow \Rightarrow$	C 🗅 pi4055	2/allmon2/link.php?nodes=	40552					┦☆ :
Al	Istar toring the Wo	Monitor] orld One Node at a Tin	ne				2Å	IIStar Link
	About 40552	Logout						
29571		Permanent 🗆						
Connec	ct Disconnect	Monitor Local Monitor C	Control Panel					
	N	ode <u>40552</u> - AC	0KQ 446.	200 port	able Bubb	ole Chart		
			Received	Link	Direction	Connected	Mode	
Node	N	ode Information			(C)			

Incoming Audio



Example Control Panel Display



Observations

- By default the node list is updated daily via a cron job
- The rPi uses simpleusb due to limited CPU performance
- AllStar uses ArchLinux
- There is no need to expand the OS to fill the SD card (image size 4GB)

Part 4 Control and Monitoring

Raspberry Pi Header



Pins are multiplexed

- Pins configured for different uses
- GPIO 14&15 <=> UART TxD/RxD
- GPIO 2&3 <=> I²C SDA&SCL
- GPIO 7&8&9&10&11 <=> SPI MOSI&MISO&SCL&CE0&CE1
- GPIO 18&19 <=> PWM 0&1
- 16-26 GPIO pins

Raspberry Pi Serial

- Single serial port
 - /dev/ttyAMA0
- Speeds up to 115200 bps
- TTL level signals
- By default connected to getty

Raspberry Pi I²C

- Inter-Integrated Circuit
 - Serial bus (a.k.a SMBus)
- Default speed 400,000 bps
- rPi has single external I²C bus
 - 127 devices
- Control lines
 - SDA (data)
 - SCL (clock)



Enable I²C with raspi-config 1

pi@raspberrypi: ~

- 🗆 🗙

File Edit View Search Terminal Help

Raspberry Pi Software Co	nfiguration Tool (raspi-config)
1 Expand Filesystem	Ensures that all of the SD card s
2 Change User Password	Change password for the default u
3 Boot Options	Choose whether to boot into a des
4 Wait for Network at Boot	Choose whether to wait for networ
5 Internationalisation Options	Set up language and regional sett
6 Enable Camera	Enable this Pi to work with the R
7 Add to Rastrack	Add this Pi to the online Raspber
8 Overclock	Configure overclocking for your P
9 Advanced Options	Configure advanced settings
0 About raspi-config	Information about this configurat

<Select>

<Finish>

Enable I²C with raspi-config 2

⊗● willem@aid2: ~

File Edit View Search Terminal Help

Raspberry Pi Software Configuration Tool (raspi-config)

A1 Overscan	You may need to configure oversca 1
A2 Hostname	Set the visible name for this Pi
A3 Memory Split	Change the amount of memory made
A4 SSH	Enable/Disable remote command lin
A5 Device Tree	Enable/Disable the use of Device
A6 SPI	Enable/Disable automatic loading
A7 I2C	Enable/Disable automatic loading
A8 Serial	Enable/Disable shell and kernel m
A9 Audio	Force audio out through HDMI or 3
AA GL Driver	Enable/Disable experimental deskt ↓

<Select>

<Back>

Viewing the Bus

🗴 🗖 🔲 willem@aid2: ~
File Edit View Search Terminal Help
willem@aid2:< \$ sudo apt-get install i2c-tools
Reading package lists Done
Building dependency tree
Reading state information Done
i2c-tools is already the newest version.
0 upgraded, 0 newly installed. 0 to remove and 2 not upgraded.
willem@aid2: 🥿 sudo i2cdetect -y 1 📂
0123456789abcdef
00:
10:
20:
30:
40:
50:
60:
70:
willem@aid2:~ \$

i2cdetect outputs

- Scans bus looking for devices
 - No Device answered
 - **UU** Device in use by a driver
 - dd Slave found (dd hex adress)
- Watch for devices in use from user space (e.g. BPQ)
 - can corrupt data

I²C devices

- TNC-Pi
- INA219 current sensor
- Temperature/pressure/RH sensors
- LCD displays
- Accelerometers
- Digitial I/O pins
- Analog<>Digital I/P pins

SPI bus

- Serial Peripheral Interface
- Signals (supports 2 slaves)
 - MasterOutSlaveIn
 - MasterInSlaveOut
 - Clock
 - CE0 (SS1)
 - CE1 (SS2)
- Speeds up to 250 MHz



raspi-config enable SPI

🛚 🖨 🔲 willem@aid2: /sys/bus/i2c/drivers/stmpe-i2c

File Edit View Search Terminal Help

Raspberry Pi Software Configuration Tool (raspi-config)

A2 Hostname Set the visible name for this Pi	
A3 Memory Split Change the amount of memory made	
A4 SSH Enable/Disable remote command lin	
A5 Device Tree Enable/Disable the use of Device	
A6 SPI Enable/Disable automatic loading	
A7 I2C Enable/Disable automatic loading	
A8 Serial Enable/Disable shell and kernel m	
A9 Audio Force audio out through HDMI or 3	
AA GL Driver Enable/Disable experimental deskt	Ť

<Select>

<Back>

SPI Devices

- Faster than I²C, but uses more pins
- Same devices as I²C, but adds
 - GPS
 - Ethernet/WiFi/Bluetooth/RFID
 - Memory
- Full duplex

Beagle Bone Black

Cape Expansion Headers

	1	5	
DGND	1	2	DGND
VDD_3V3	з	4	VDD_3V3
VDD_5V	5	6	VDD_5V
SYS_5V	7	8	SYS_5V
PWR_BUT	9	10	SYS_RESETN
UART4_RXD	11	12	GPIO_60
UART4_TXD	13	14	EHRPWM1A
GPIO_48	15	16	EHRPWM1B
SPI0_CS0	17	18	SPIO_D1
I2C2_SCL	19	20	I2C2_SDA
SPI0_DO	21	22	SPI0_SCLK
GPIO_49	23	24	UART1_TXD
GPIO_117	25	26	UART1_RXD
GPIO_115	27	28	SPI1_CS0
SPI1_D0	29	30	GPIO_112
SPI1_SCLK	31	32	VDD_ADC
AIN4	33	34	GNDA_ADC
AIN6	35	36	AIN5
AIN2	37	38	AIN3
AINO	39	40	AIN1
GPIO_20	41	42	ECAPPWMO
DGND	43	44	DGND
DGND	45	46	DGND

DQ

	5V	Ĩ	24	9M.000			
	1001		dd-)	13886	10		1991
	00: #-	- in the second	107180 E	theroat	E COMPANY		
8		ar at					
	514 715 917	ಜಾ ಚಾರ್ಚ್ಯ	165			.	
	ीं= स	::			[二] 則.e.		
	rer Lu			222	See.		
	<u>.</u> 0		dS12000			(Lapite)	
Ę.		е ака	P ains :				
			¶. ₩				
	4	11	ž o ⁱ	Misres	Care	2	

LEGEND
Power/Ground/Reset
AVAILABLE DIGITAL
AVAILABLE PWM
SHARED I2C BUS
RECONFIGURABLE DIGITAL
ANALOG INPUTS (1.8V)

	-	-	
DGND	1	2	DGND
MMC1_DAT6	з	4	MMC1_DAT7
MMC1_DAT2	5	6	MMC1_DAT3
GPIO_66	7	8	GPIO_67
GPIO_69	9	10	GPIO_68
GPIO_45	11	12	GPIO_44
EHRPWM2B	13	14	GPIO_26
GPIO_47	15	16	GPIO_46
GPIO_27	17	18	GPIO_65
EHRPWM2A	19	20	MMC1_CMD
MMC1_CLK	21	22	MMC1_DAT5
MMC1_DAT4	23	24	MMC1_DAT1
MMC1_DATO	25	26	GPIO_61
LCD_VSYNC	27	28	LCD_PCLK
LCD_HSYNC	29	30	LCD_AC_BIAS
LCD_DATA14	31	32	LCD_DATA15
LCD_DATA13	33	34	LCD_DATA11
LCD_DATA12	35	36	LCD_DATA10
LCD_DATA8	37	38	LCD_DATA9
LCD_DATA6	39	40	LCD_DATA7
LCD_DATA4	41	42	LCD_DATA5
LCD_DATA2	43	44	LCD_DATA3
LCD DATAO	45	46	LCD DATA1

P8

Pins are multiplexed

- Default configuration
 - Power&Reset Buttons
 - 4 serial ports
 - 8 analog inputs (1.8V max)
 - 1 external I²C bus (127 devices)
 - 19-128 GPIO pins
 - Switched 5V/3.3V DC

Limitations

- Pins connect directly to CPU
 - Long wires are CPU antennas!
- rPi & BBB GPIO Pins are 3.3 V
 - Max current 16 mA in or out
 - Max combined output current 50 mA
- BB Analog In Pins are 1.8V

Device Tree

- Unix: Everything is a File
- Isys maps to hardware
 - In kernel virtual file system
- Get status by reading
- Set status by writing

Reading analog pins on BBB

- Enable analog pins in device tree echo cape-boneiio>/sys/devices/bone_capemgr.*/slots
- Read value of pin AIN0 in mV cat /sys/devices/ocp.*/helper.*/AIN0 580
- Voltage on pin AIN0 is 0.580V

Show pin voltages in Python 1

#!/usr/bin/python

for i in range(0,8):

- # Snarf file
- fd = open("/sys/devices/ocp.3/helper.16/AIN%d" % i)
 text = fd.read()
- fd.close()
- # Decode voltage
- V = float(text)/1000
- # Print voltage
- print "AIN%d = %5.3fV" % (i,V)

Show pin voltages in Python 2

.laread AINO = 1.740VAIN1 = 1.481VAIN2 = 1.645VAIN3 = 0.867VAIN4 = 0.589VAIN5 = 0.709VAIN6 = 0.852VAIN7 = 1.678V

Limitations

- Maximum voltage is 1.8V
- Use a voltage divider to increase
 - Use 1% or better resistors
 - Max 1 kohm for lower leg
- No analog in on rPi
 - use MCP3008 or similar and SPI

Assigning pins to GPIO

- /sys/class/gpio/export
 - Maps pin to GPIO
 - echo 18 > /sys/class/gpio/export
- /sys/class/gpio/unexport
 - Removes pin from GPIO map
 - echo 18 > /sys/class/gpio/unexport
- Root access required

Manipulating GPIO

- When mapped to GPIO, a new directory is created for that pin
 - /sys/class/gpio/gpioXX
- Files in this directory controls pin
 - direction = in or out
 - value = 0 or 1

Checking pin value

- In or out?
 - cat /sys/class/gpio/gpio18/direction
- High or low?
 - cat /sys/class/gpio/gpio18/value

Changing the GPIO direction

- Set pin for input
 - echo in > /sys/class/gpio/gpio18/direction
- Set pin for output

– echo out > /sys/class/gpio/gpio18/direction

Changing the GPIO value

- Set pin voltage high
 - echo 1 > /sys/class/gpio/gpio18/value
- Set pin for output

- echo 0 > /sys/class/gpio/gpio18/value

Setting pins at boot

- Edit /etc/rc.local
 - Runs at boot time as root
 - Enable pin 18 for output and set high echo 18 > /sys/class/gpio/export echo out > /sys/class/gpio/gpio18/direction echo 1 > /sys/class/gpio18/value
 - Before this runs, values are unpredictable
Setting many pins at boot

Edit /etc/rc.local

 Set ping 18, 23, 24 and 25 for output and high **# Set GPIO ports to out** for n in 18 23 24 25; do echo \$n > /sys/class/gpio/export echo "out" > /sys/class/gpio/gpio\$n/direction echo 1 > /sys/class/gpio/gpio\$n/value done

Turn on pin 5 minutes per hour

Edit /etc/crontab

- # This line turns on pin 18 at *:0
- 0 * * * * root echo 1 > /sys/class/gpio/gpio18/value
- # This line turns off pin 18 at *:5
- 5 * * * * root echo 0 > /sys/class/gpio/gpio18/value

python access to pins

- Import the GPIO package import Rpi.GPIO as GPIO
- Name the pins by their GPIO# GPIO.setmode(GPIO.BCM)
- Name pins by their board number GPIO.setmode(GPIO.BOARD)

python set pins for in/out

- Set pin 18 for output GPIO.setup(18,GPIO.OUT)
- Set pins 18,23,24&25 for output GPIO.setup([18,23,24,25],GPIO.OUT)
- Set ping 18 for input GPIO.setup(18,GPIO.IN)

python set/get pin value

- Set pin 18 high GPIO.output(18,1)
- Set pin 18 low
 GPIO.output(18,0)
- Read ping 18 value
 p18 = GPIO.input(18)

Input pin status

- Set ping 23 to input with pull up
- GPIO.setup(24,GPIO.IN,pull_up_down=GPIO.PUD_UP)
 - ground to activate
- Set pin 24 to input with pull down
- GPIO.setup(24,GPIO.IN,pull_up_down=GPIO.PUD_DOWN)
 Pull up to 3.3V
- A 1k series resistor is typically a good idea

Important Limitations

- GPIO pins are 3.3 V
- Current limited to 16mA
- Opto-isolate relays



I²C Example: Voltage&Current

- TI INA219 I²C high side monitor
- Max 26V
- Current Sense 40-320mV shunt
- Chip \$2.50
- Adafruit \$10



Adafruit Breakout

- I²C address 0x40 0x41 0x42 0x43
 - solder jumpers
- 0.1 ohm shunt reads to 3.2A



Python Usage

import Subfact_INA219 as INA219
ina = INA219()
V = ina.getBusVoltage_V()
mA = ina.getCurrent_mA()

Digging deeper

- Subfact_INA219 imports Adafruit_I2C
- Adafruit_I2C imports smbus

Reading 1wire Temperatures

- 1wire uses a single data bus
- Each device has unique address
- DS18S20 is a TO-92 temperature sensor with 0.5C resolution for \$2.50
- Can use parasite power (but not on rPi) Use 4k7 pullup



Building the Device Tree 1

/dts-v1/; /plugin/;

```
/ {
    compatible = "ti,beaglebone", "ti,beaglebone-black", "ti,beaglebone-green";
    part-number = "BB-W1";
    version = "00A0";
```

```
exclusive-use = "P9.23";
```

```
fragment@0
```

```
target = <&am33xx_pinmux>;
____overlay___
```

```
bb_w1_pins: pinmux_bb_w1_pins
```

```
pinctrl-single,pins = <0x68 0x37>; /* gpio1_17,
OMAP_PIN_INPUT_PULLUP|OMAP_MUX_MODE7 */
```

};

Building the Device Tree 2

gpios = <&gpio2 17 0>;
};
};

};

Building the Device Tree 3

- Edit w1.dts as shown above
- Compile with device tree compiler dtc -O dtb -o w1-00A0.dtbo -b 0 -@ w1.dts mv w1-00A0.dtbo /lib/firmware
- Enable

echo w1 > /sys/devices/bone_capemgr.9/slots

Getting 1wire output

Is /sys/bus/w1/devices

10-000802fba50d 10-000802fbe2f6 10-000802fbf0f9 w1_bus_master1

 10 means it is a DS18S20 temp, the test is a unique serial number

Getting the Data

cat /sys/bus/w1/devices/w1_bus_master1/w1_master_slaves

- **10-000802fbe2f6**
- **10-000802fbf0f9**
- 10-000802fba50d

cat /sys/bus/w1/devices/10-000802fbe2f6/w1_slave

- 2c 00 4b 46 ff ff 0e 10 17 : crc=17 YES
- 2c 00 4b 46 ff ff 0e 10 17 t=21875

Temperature of first sensor is 21.875 °C

Reading Temps in Python 1

Snarf the slave list file fd=open("/sys/bus/w1/devices/w1_bus_master1/w1_master_slaves") text = fd.read() fd.close() # Split text on line breaks slaves = filter(None,text.split("\n")) # Sort so that order is predictable slaves.sort()

Reading Temps in Python 2

Blank dictionary temps = $\{\}$ **# Loop over devices** for slave in slaves: if slave=="": continue # Snarf device file fd = open("/sys/bus/w1/devices/"+slave+"/w1 slave") text = fd.read() fd.close() **#** Split lines lines = text.split("\n") words = lines[1].split(" ") # Get temperature C = float(words[9][2:])/1000F = 9*C/5+32# Add result to dictionary temps[slave] = "%.1fF" % F

Observations

- Temperature conversion occurs when you cat the file
 - About 700mS per device
- Temperature reads are best done using a separate thread
- rPi 1wire support in raspi-config

Part 5 Software Defined Receiver

ADSB SDR Receiver

- Receiver based on RTL2832 USB
- About \$20 on Amazon
- Also used in many ham related SDR projects





Software Build

Build and install rtl-sdr module and software

git clone git://git.osmocom.org/rtl-sdr.git cd rtl-sdr mkdir build cd build cmake ../ -DINSTALL_UDEV_RULES=ON make

cd ..

/usr/local/bin/rtl_tcp is a TCP server for remote monitoring

dump1090 Build

Build and install dump1090 and related software

git clone git://github.com/MalcolmRobb/dump1090.git cd dump1090 make cd ..

Command line interface

./view1019

🛚 🕒 🔲 willem@adsb: /usr/local/bin											
File Edit	: View	Search	Terminal H	Ielp							
Hex	Mode	Sqwk	Flight	Alt	Spd	Hdg	Lat	Long	Sig	Msgs	Ti/
Δ1B3FF	5	1455	740	18025	331	036	39,419	-105.146	20	134	
ACF600	s	1455	740	33975	551	050	55.415	105.140	12	27	5
A50119	S	2406	UAL1881	34025					15	172	5

Running web interface

./dump1090 --net --lon -105 --lat 39
-net enables web interface port 8080
-lon and -lat sets location
Run at boot from rc.local

Running



Building a high gain antenna Colinear made from coax



Installation

- Mount the receiver as close to the antenna as possible
 - RTL-SDR is not weather proof
 - 18" N to micro-UHF jumper
- Run long USB cable to rPi

Other SDR Projects

- The rPi 3 is a 1.2GHz 64 bit quad core machine with 1GB memory
 - Processing power to do cool stuff
- Adafruit
 Freq Show
- GNU radio Eric Schneider RMHAM U April 15, 2017



RasHAWK

Custom User Interface Spectrum Displays ACT 2014 11 1402 (2373 1406 CT WHERE BEEL TOWNER Command & Control (C2) without the state of the second ndwarm Hell (256000 Laptop 442 0115 105 Chr 2 sheeth For iPhone Hotspot (tether to GPS Internet) REDHAWK Location Mapping on Tablet Domain Manager Control & Streaming Data WiFi Router SSID: rashawk wlan

RasHawk Sensors



REDHAWK Device Nodes Raspberry Pi with Antenna Switch



Transmitter Node



REDHAWK Device Node

SDR TCP server

- Start rtl_tcp as root
 - rtl_tcp -a <ipaddress>
 - Default port is 1234 (set with -p)
- Connect to it with an SDR program such as SDR# or GNU Radio on a device with enough power to process the data

SDR# Screenshot

SDR# v1.0.0.1331 - IQ Imbalance: Gain = 1.000 Phase = 0.000°



Part 6 Other Projects

rPi / TNC-Pi / screen / xastir



SmokePi (SmokePing rPi)

SmokePing Latency Page for - Chromium 1 SmokePing Latency | × radon.schreuder.us/smokeping/smokeping.fcgi?hierarchy=sites;target=Conifer 52 Ξ Logged in as Conifer AllStar 147.225 Bridge Guest 30 Seconds 20 SmokePing 10 m Targets: 0 00:00 02:00 04:00 06:00 08:00 med RTT 27.5 ms av md 1.0 % av ls 1.6 ms av sd 17.1 am/as Hierarchy: Fri May 13 08:22:09 2016 CRA Sites ۳ Conifer Router Filter: 30 m Seconds 20 m 10 m 0 - ACOKQ 00:00 02:00 04:00 06:00 08:00 - Cheyeni med RTT 27.7 ms av md 0.5 % av ls 1.5 ms av sd 18.4 am/as Conifer AllSta Fri May 13 08:22:09 2016 Conifer Router - Skybeam - W0CRA Skybeam Conifer Principia - Squaw - WA1JHK Seconds 10 0 00:00 02:00 04:00 06:00 08:00 med RTT 10.8 ms av md 0.9 % av ls 3.9 ms av sd 2.8 am/as Fri May 13 08:22:09 2016 Maintained by Willem AC0KO WOCRA Web Server Seconds Running on 10 m SmokePing-2.6.11 by Tobi Oetiker and 0 00:00 02:00 04:00 06:00 08:00 Niko Tyni 3.7 ms av sd med RTT 10.8 ms av md 0.5 % av ls 2.9 am/as Fri May 13 08:22:09 2016 smoke



logging & graphir
SmokePi = Bad Idea

- SD storage not suitable for database applications
 - Lots of writes wears out flash
- SmokePi generates lots of graphs
 - SD slow compared to disk
 - Lots of writes wears out flash
- USB-mSATA hat allows adding a hard disk
 - With a SSD drive this becomes feasible

Pizza!