

# S-COM Controller Technical Training

Dave Maciorowski 12 February 2017 (Note: aligned with Release 1.6)

© Copyright 2014, SCOM, LLC

# **Getting These Slides**

http://www.scomcontrollers.com/new/?q=7330doc



# Agenda

#### Introduction

• Who is S-COM?

#### The Basics

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- Testing Your Results

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

### File Management

Introducing SBOOT

#### **PC-Based Utilities**

S-COM Custom Audio Utility

#### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



# Agenda

#### Introduction

• Who is S-COM?

#### **The Basics**

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 4 CTresting You Results

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

### File Management

Introducing SBOOT

### **PC-Based Utilities**

S-COM Custom Audio Utility

### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



## Introduction

Who Is S-COM?

### Bob Schmid, WA9FBO

### Founder and Owner of S-COM, LLC

Bob's first controller was a SWTPC 6800 microcomputer, assembled from a kit in 1976 and used to control WR9AIN, a Quintron repeater in New Holstein, WI. Wire-wrapped versions were followed by the "Big Board" controller introduced in 1982.

The MRC-100 came out in 1984, followed by the 5K (1987), the 7K (1989), the 6K (1990), and the 7330 (2007), a total of about 4900 units. There are also customized controllers in commercial use, as well as air-to-ground interconnects for the airline industry.

S-COM continues to ship 7330s and is busy defining the next generation of repeater controllers and accessories.



## Dave Maciorowski, WA1JHK

### Hardware and Firmware Engineer

Dave saw his first repeater in 1972 and was hooked on developing repeaters and repeater controllers. He built his first microprocessor-based controller in 1979. Dave began working with Bob and S-COM on 7K firmware in 1995 adding the Doug Hall RBI-1 support and continued adding features.

As a member of the 7330 development team, Dave specified many of the 7330 features and developed most of the 7330 firmware. He continues to support and enhance the 7330 while working on future controller architecture.

# Agenda

#### Introduction

• Who is S-COM?

#### The Basics

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 5 CTESTING YOUM RESults

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

### File Management

Introducing SBOOT

### **PC-Based Utilities**

• S-COM Custom Audio Utility

### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



Ant

Repeater Building Blocks

- Receiver
- Pre-Amplifier
- Transmitter
- Power Amplifier
- Isolator
- Controller
- Duplexer
- Antenna
- Feedline
- Lightning Suppressor
- Power Supply





Repeater Building Blocks

- Receiver
- Pre-Amplifier
- Transmitter
- Power Amplifier
- Isolator
- Controller
- Duplexer
- Antenna
- Feedline
- Lightning Suppressor
- Power Supply





- Key a Transmitter In The Presence of a Valid Signal In a Receiver
  - Keying signal to Transmitter.
  - Valid Signal Presence signal from the receiver.





- Key a Transmitter In The Presence of a Valid Signal In a Receiver
  - Keying signal to Transmitter.
  - Valid Signal Presence signal from the receiver.
- Pass Audio from the Receiver to the Transmitter
  - Match the level, Perform filtering, if required.
  - Gate the audio





- Key a Transmitter In The Presence of a Valid Signal In a Receiver
  - Keying signal to Transmitter.
  - Valid Signal Presence signal from the receiver.
- Pass Audio from the Receiver to the Transmitter
  - Match the level, Perform filtering, if required.
  - Gate the audio
- Modulate the Transmitter with an ID Message
  - Key the transmitter during the message.
  - Send the message in CW or speech.





- Key a Transmitter In The Presence of a Valid Signal In a Receiver
  - Keying signal to Transmitter.
  - Valid Signal Presence signal from the receiver.
- Pass Audio from the Receiver to the Transmitter
  - Match the level, Perform filtering, if required.
  - Gate the audio
- Modulate the Transmitter with an ID Message
  - Key the transmitter during the message.
  - Send the message in CW or speech.
- Transmitter Control Point
  - Local or remote control of the transmitter.





- Key a Transmitter In The Presence of a Valid Signal In a Receiver
  - Keying signal to Transmitter.
  - Valid Signal Presence signal from the receiver.
- Pass Audio from the Receiver to the Transmitter
  - Match the level, Perform filtering, if required.
  - Gate the audio
- Modulate the Transmitter with an ID Message
  - Key the transmitter during the message.
  - Send the message in CW or speech.
- Transmitter Control Point
  - Local or remote control of the transmitter.
- Timeout Timer
  - Prevent a received signal from keying the transmitter longer than some maximum time.





### Common Terms

## COR

- Carrier-Operated Relay

## cos

- Carrier-Operated Switch

## PTT

- Push-To-Talk

## CTCSS

- Continuous Tone-Coded Squelch System
- PL, Private Line®
  - Motorola's name for CTCSS
- CG, Channel Guard®
  - General Electric's name for CTCSS

### Reverse Burst®

 Motorola name for squelch tail elimination

### DCS

- Digital Code Squelch
  - Continuous Digital Code Squelch System
- DPL®
  - Motorola's name for DCS
- DCG®
  - General Electric's name for CTCSS

### Transmitter Hang Timer

- Time transmitter is on after received signal becomes not present.
- Transmitter Tail

### Audio Gate

 Switch that turns off the receiver-totransmitter audio path when received signal not present.

### **Chicken Burst**

- Technique to emulate Reverse Burst





- 3 Radio Ports
  - DTMF Decoder
  - Dual-Tone Generator with Remote Level Adjust
  - Real Speech Player with Remote Level Adjust
  - CTCSS Encoder with Reverse Burst
  - Digital Audio Delay
  - Path Any Receiver to Any Transmitter
  - Configurable Access Modes

- 4 Logic Inputs
- 8 Logic Outputs
- 3 Analog-to-Digital Inputs
- Time-of-Day Clock, Battery Backed, TCXO with 1 Minute Per Year Stability
- 13 Minutes of Custom Audio
- Firmware Updates via RS-232
- Custom Audio Loaded via RS-232
- 100 Setpoint Scheduler
- 300 Custom Macros



- 3 Radio Ports
  - -DE9S
- Power
  - Locking 2-pin terminal strip connector
- INIT and RESET buttons

- I/O
  - DB25S
- Serial, RS-232
  - DE9S, DCE
  - DE9P, DTE
- Mating Connectors
  Included











# Agenda

#### Introduction

• Who is S-COM?

#### **The Basics**

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 19 CTresting Your Results

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

### File Management

Introducing SBOOT

### **PC-Based Utilities**

S-COM Custom Audio Utility

### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



### 7330 Connectors – Radio Port

Pin	Name	Туре	]
1	Receiver Audio	Audio Input	
2	Receiver COR	Logic Input	
3	Receiver CTCSS Decode	Logic Input	] ← 01000 B00000
4	Transmitter PTT	Logic Output	]
5	Transmitter Audio	Audio Output	]
6	Ground for Receiver Audio	Ground	]   PTT ,
7	Ground for CTCSS Audio	Ground	Audio
o	Transmitter CTCSS Audio or	Analog Output or	CTCSS Encode
0	CTCSS Logic Output	Logic Output	
9	Ground for Transmitter Audio	Ground	



7330 Connectors – I/O

Signal	Primary Use	Alternate	
Logic Input	Logic Input		
Analog-to-Digital	Analog Readings	Logic Input	
Logic Output	Logic Output		

### I/O Connector

Pin	Name
1	Logic Output 1
2	Logic Output 2
3	Logic Output 3
4	Logic Output 4
5	Logic Output 5
6	Logic Output 6
7	A/D Input 3
8	A/D Input 2
9	A/D Input 1
10	Logic Input 1
11	Logic Input 2
12	Logic Input 3
13	Logic Input 4
14	Logic Output 7
15	Logic Output 8
16	Ground
17	Ground
18	Ground
19	Ground
20	Ground
21	Ground
22	Ground
23	Ground
24	Ground
25	Ground



7330 Connectors, Jumpers and Pots



I/O Radio Port 1 Radio Port 2 Radio Port 3







Power Considerations

- Reverse Polarity Protected
- Factory-Replaceable Internal Fuse
- Recommend Fuse Externally In Plus Lead





Logic Input Signals

Signal	Primary Use	Alternate
COR	Receiver	Logic Input
CTCSS	Receiver	Logic Input
Logic Input	Logic Input	

### **Radio Port Connector**

Pin	Name	Туре	
1	Receiver Audio	Audio Input	
2	Receiver COR	Logic Input	
3	Receiver CTCSS Decode	Logic Input	
4	Transmitter PTT	Logic Output	
5	Transmitter Audio	Audio Output	
6	Ground for Receiver Audio	Ground	
7	Ground for CTCSS Audio	Ground	
	Transmitter CTCSS Audio or	Analog Output or	
8	CTCSS Logic Output	Logic Output	
9	Ground for Transmitter Audio	Ground	

### I/O Connector

Pin Name		
1	Logic Output 1	
2	Logic Output 2	
3	Logic Output 3	
4	Logic Output 4	
5	Logic Output 5	
6	Logic Output 6	
7	A/D Input 3	
8	A/D Input 2	
9	A/D Input 1	
10	Logic Input 1	
11	Logic Input 2	
12	Logic Input 3	
13	Logic Input 4	
14	Logic Output 7	
15	Logic Output 8	
16	Ground	
17	Ground	
18	Ground	
19	Ground	
20	Ground	
21	Ground	
22	Ground	
23	Ground	
0.4	Cround	
24	Ground	



Input Logic Signals

### Inputs

- COR, CTCSS, Logic Input
  - 48V Maximum with Pullup Jumper Out
  - 16V Maximum with Pullup Jumper In
  - Switching Threshold Set To 2.1V





### Wiring It Up 7330 Logic Input +5V +3.3V 4.7K Input Logic Signals 10K Jumper **Device Driver** Input <Output 10K 4.7K

### **Driver Considerations**

- Pullup Required Insert Jumper
  - Open Collector
  - Open Drain
  - Relay Contact or Switch









### Pullup jumpers For Logic, COR, CTCSS Input Pullups



I/O Radio Port 1 Radio Port 2 Radio Port 3



Inversion Jumpers for COR, CTCSS



I/O Radio Port 1 Radio Port 2 Radio Port 3



**Output Logic Signals** 

Signal	Primary Use	Alternate
PTT	Transmitter	
CTCSS	Transmitter	Logic Output
Logic Outputs	Logic Output	

### **Radio Port Connector**

	Pin	Name	Туре	
	1	Receiver Audio	Audio Input	
	2	Receiver COR	Logic Input	
	3	Receiver CTCSS Decode	Logic Input	
<	4	Transmitter PTT	Logic Output	$\square$
	5	Transmitter Audio	Audio Output	
	6	Ground for Receiver Audio	Ground	
	7	Ground for CTCSS Audio	Ground	
<	8	Transmitter CTCSS Audio or	Analog Output or	$\sum$
		CICSS Logic Output	Logic Output	
	9	Ground for Transmitter Audio	Ground	

### I/O Connector

	Pin	Name	
	1	Logic Output 1	
	2	Logic Output 2	
	3	Logic Output 3	
	4	Logic Output 4	
$\mathbf{X}$	5	Logic Output 5	
	6	Logic Output 8	
	7	A/D Input 3	
	8	A/D Input 2	
	9	A/D Input 1	
	10	Logic Input 1	
	11	Logic Input 2	
	12	Logic Input 3	
	13	Logic Input 4	
	14	Logic Output 7	
	15	Logic Output 8	
	16	Ground	
	17	Ground	
	18	Ground	
	19	Ground	
	20	Ground	
	21	Ground	
	22	Ground	
	23	Ground	
	24	Ground	
	25	Ground	



**Output Logic Signals** 

### 7330 PTT and Logic Outputs



### **Outputs**

- PTT, Logic Output
  - Not Keyed, 50V Maximum
  - Keyed, 150-ma Current Sink
- Socketed "Just In Case"
  - Easy recovery from damaged driver component



**Output Logic Signals** 

7330 PTT and Logic Outputs



### **Driver Considerations**

 Device Must Have a Pullup Resistor or Other Load





### **PTT Inversion Jumpers**



I/O Radio Port 1 Radio Port 2 Radio Port 3



### Audio Input Signal

Signal	Use
Receiver Audio	Audio

#### Radio Port Connector

	Pin	Name	Туре	
$\bigtriangledown$	1	Receiver Audio	Audio Input	
	2	Receiver COR	Logic Input	
	3	Receiver CTCSS Decode	Logic Input	
	4	Transmitter PTT	Logic Output	
	5	Transmitter Audio	Audio Output	
	6	Ground for Receiver Audio	Ground	
	7	Ground for CTCSS Audio	Ground	
		Transmitter CTCSS Audio or	Analog Output or	
	8	CTCSS Logic Output	Logic Output	
	9	Ground for Transmitter Audio	Ground	



Audio





### Passband

- Analog FM radios only transmit and receive audio between 250 – 3500 Hz.
- Below 250 Hz is reserved for signaling and data.
- Above 3500 Hz is not needed for mobile communications.



Audio



### Passband

- Analog FM radios only transmit and receive audio between 250 – 3500 Hz.
- Below 250 Hz is reserved for signaling and data.
- Above 3500 Hz is not needed for mobile communications.

### **Pre-emphasis and De-emphasis**

- Pre-emphasis at +6dB / Octave is applied to a FM signal being transmitted.
- De-emphasis of -6dB / Octave is applied to the signal being received.
- Why? To reduce unwanted noise.






Audio Input

### **Audio Source Connection**

- Impedance, 25K ohms or greater
- DC Load

7330 Audio Input R30 C1 C18 IuF 50K RX1 IuF

GND



### Audio Input

### **Audio Source Connection**

- Impedance, 25K ohms or greater
- DC Load

### **Audio Processing**

- Optional De-emphasis Filter
  - Jumper: DE-EMP or FLAT
- Selectable Gain Range
  - Jumper: HIGH for gain of 6.3x
  - Jumper: NORM for gain of 2x
- Audio Delay
  - Jumper: Delay or No-Delay
  - Pot Adjustable 30 to 250 mS





### Audio Input

### **Audio Source Connection**

- Impedance, 25K ohms or greater
- DC Load

### **Audio Processing**

- Optional De-emphasis Filter
  - Jumper: DE-EMP or FLAT
- Selectable Gain Range
  - Jumper: HIGH for gain of 6.3x
  - Jumper: NORM for gain of 2x
- Audio Delay
  - Jumper: Delay or No-Delay
  - Pot Adjustable 30 to 250 mS

### Where to Get Receiver Audio?

• High side of the volume control



Signaling Tones Must Be Filtered Before Reaching The Controller



Jumpers and Pots for Audio Input



I/O Radio Port 1 Radio Port 2 Radio Port 3



### Audio Output Signal

Signal	Use
Transmitter Audio	Audio

#### **Radio Port Connector**

	Pin	Name	Туре	
	1	Receiver Audio	Audio Input	
	2	Receiver COR	Logic Input	
	3	Receiver CTCSS Decode	Logic Input	
	4	Transmitter PTT	Logic Output	
$\sim$	5	Transmitter Audio	Audio Output	$\wedge$
	6	Ground for Receiver Audio	Ground	
	7	Ground for CTCSS Audio	Ground	
		Transmitter CTCSS Audio or	Analog Output or	
	0	CTCSS Logic Output	Logic Output	
	9	Ground for Transmitter Audio	Ground	





- 600 Ohms
- DC Load





- Low Impedance
  - 600 Ohms
  - DC Load

- Selectable Gain Range
  - Jumper: NORM
    - Driving >10K Ohm Load, 0-to-2Vpp (700mV rms)

GND

- Driving 600 Ohm Load, 0-to-1Vpp (350mV rms)
- Jumper: LOW
  - Driving >10K Ohm Load, 0-to-0.5Vpp (175mV rms)
  - Driving 600 Ohm Load, 0-to-0.25Vpp (88mV rms)



GND



### **Audio Connection**

- Low Impedance
  - 600 Ohms
  - DC Load

### Where to Connect Transmitter Audio Input?

• Mic Input, May Require **External Attenuation** 

#### ine Input

#### Audio Processing

- Selectable Gain Range
  - Jumper: NORM
    - Driving >10K Ohm Load, 0-to-2Vpp (700mV rms)

GND

- Driving 600 Ohm Load, 0-to-1Vpp (350mV rms)
- Jumper: LOW
  - Driving >10K Ohm Load, 0-to-0.5Vpp (175mV rms)
  - Driving 600 Ohm Load, 0-to-0.25Vpp (88mV rms)



GND

Jumpers and Pots for Audio Output



I/O Radio Port 1 Radio Port 2 Radio Port 3



### **CTCSS Encoder Audio Output**

Signal	Primary Use	Alternate Use
Transmitter CTCSS Encoder	Audio	Logic Output

#### **Radio Port Connector**

Pin	Name	Туре	
1	Receiver Audio	Audio Input	
2	Receiver COR	Logic Input	
3	Receiver CTCSS Decode	Logic Input	
4	Transmitter PTT	Logic Output	
5	Transmitter Audio	Audio Output	
6	Ground for Receiver Audio	Ground	
7	Ground for CTCSS Audio	Ground	
8	Transmitter CTCSS Audio or	Analog Output or	
0	CTCSS Logic Output	Logic Output	
9	Ground for Transmitter Audio	Ground	



**CTCSS Encoder Considerations** 

### Internal CTCSS Encoder

- 7330 Generates the CTCSS Encoder Audio
- Complete Control of CTCSS Tone
   and Timing
- Must Be Driven Into Transmitter CTCSS Input





**CTCSS Encoder Considerations** 

### Internal CTCSS Encoder

- 7330 Generates the CTCSS Encoder Audio
- Complete Control of CTCSS Tone and Timing
- Must Be Driven Into Transmitter CTCSS Input

### **External CTCSS Encoder**

- Encoder Installed Inside Transmitter
  - E.g. Comm-Spec TS64
  - Vendor-Provided Encoder
- Controller Can Control a Logic Output Used to Disable the CTCSS Encoder
  - Only Works On Equipped Encoders
  - Used for "Chicken Burst"







### **CTCSS Encoder Audio Output**



I/O Radio Port 1 Radio Port 2 Radio Port 3



A-to-D Input Signals

Signal	Primary Use	Alternate
Analog-to-Digital	Analog Readings	Logic Input

#### I/O Connector

Pin	Name	
1	Logic Output 1	
2	Logic Output 2	
3	Logic Output 3	
4	Logic Output 4	
5	Logic Output 5	
6	Logic Output 6	
7	A/D Input 3	
8	A/D Input 2	
9	A/D Input 1	
10	Logic Input 1	
11	Logic Input 2	
12	Logic Input 3	
13	Logic Input 4	
14	Logic Output 7	
15	Logic Output 8	
16	Ground	
17	Ground	
18	Ground	
19	Ground	
20	Ground	
21	Ground	
22	Ground	
23	Ground	
24	Ground	
25	Ground	



Analog-to-Digital Input



### Input for Reading Analog Voltages

- Two Ranges
  - 0 thru 5 volt
  - 0 thru 25 volt (Factory Default)
  - Set Range By Jumper



### Jumper for A-to-D Range



I/O Radio Port 1 Radio Port 2 Radio Port 3



### Setting Audio Levels





Setting Audio Levels

#### Overview

Align your audio levels within the system using the following 4 steps:

- Set all receivers to the same voltage at the testpoint provided inside the controller for each receiver. (S-COM 7330 uses 1 volt Peak-to-Peak (350mV rms).)
- 2. Set all transmitters such that they deviate a maximum of 5 KHz deviation.
- 3. Set your CTCSS encode tone to 600-750 Hz deviation.
- 4. Set your controller audio processing to have flat audio.



Step 1 - Setting audio input levels

- Generate a strong RF signal on the input of each receiver.
- Signal should be a 1 kHz tone with 5 kHz of deviation.
- Set the controller RX audio input level adjust for 1 Vpp (350 V rms).
- Remember to adjust for any CTCSS tones.
- Repeat for all receivers connected to the controller







I/O Radio Port 1 Radio Port 2 Radio Port 3



Step 2 - Setting Transmitter Limiters

- Generate a strong RF signal on the input to a receiver.
- Signal should be a 1 kHz tone with 6-7 kHz of deviation.
- Set the repeater TX deviation control for a maximum of 5 kHz deviation.





Step 3 - Setting CTCSS level

- Generate a strong RF signal on the input to a receiver. Or you can just PTT the transmitter if local control is possible.
- Signal should be a 0 kHz tone with 0 kHz of deviation. (dead carrier)
- Set the repeater TX CTCSS deviation control for
   500 – 750 Hz deviation.
- Repeat for all transmitters which use CTCSS encode.





Step 4 - Setting for Flat Audio

- Generate a strong RF signal on the input to a receiver.
- Signal should be a 1 kHz tone with 3 kHz of deviation.
- Set the Controller TX Audio level adjust for 3 kHz deviation on the repeater output.
- Assure that any links have equal and flat audio across the controller.
- Remember to adjust for any CTCSS tones.

59





## Agenda

#### Introduction

• Who is S-COM?

#### The Basics

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 60 Testing Your Results

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

#### **File Management**

• Introducing SBOOT

#### **PC-Based Utilities**

• S-COM Custom Audio Utility

#### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



Testing On The Bench

### What does it take?

- Bench Power Source 9-36V DC >190ma
- Toggle Switches on COR and CTCSS
  - Pair for Each Radio Port
- Powered Computer Speakers
  - A Speaker Per Port
- LED for PTT
  - Optional, can use built-in LED
- DTMF Keypad
  - Optional, for testing DTMF commands
  - Commands can be entered on serial port
- Serial Port Cable to PC/Terminal
  - For Programming, Firmware Updates, and loading Custom Audio Libraries.





Testing On The Bench

### **Radio Port LEDs**

- COR, CTCSS Logic Inputs
- PTT, CTCSS Encode Outputs
- DTMF Digit Valid





Testing On The Bench

### **Radio Port LEDs**

- COR, CTCSS Logic Inputs
- PTT, CTCSS Encode Outputs
- DTMF Digit Valid

### Logic I/O LEDs

- Logic Inputs
- Logic Outputs







"Initializing" A Controller

### **Powerup Reset**

- Applying Power is the same as pressing RESET
- Also called a Warm Start
- No change to programming





"Initializing" A Controller

### **Powerup Reset**

- Applying Power is the same as pressing RESET
- Also called a Warm Start
- No change to programming

### **Erase Programming**

- Also called a Cold Start
- Changes all repeater configuration options to factory defaults
- Can be performed from Serial Console
- Exceptions
  - · Console serial port and baudrate unchanged





S-COM Command Formats

Example

**DTMF Commands** 

<password><root><parameters><terminator>



S-COM Command Formats

### **DTMF Commands**

<password><root><parameters><terminator>

- Password
  - MPW, CPW, RBPW

Example

**99 63 0100 1 \*** 

99 Password, default is 99



S-COM Command Formats

### **DTMF Commands**

<password><root><parameters><terminator>

- Password
  - MPW, CPW, RBPW
- Root
  - Command number
    - 63, Set or Clear Software Switch
    - 09, Set Timer Reload Value

Example

- 99 Password, default is 99
- 63 Root number, Set/Clear Software Switch





S-COM Command Formats

### **DTMF Commands**

<password><root><parameters><terminator>

- Password
  - MPW, CPW, RBPW
- Root
  - Command number
    - 63, Set or Clear Software Switch
    - 09, Set Timer Reload Value
- Parameters
  - Identifier for Resource
  - Value to set resource to
    - Software Switch Number
    - Timer Number

### Example

- 99 Password, default is 99
- 63 Root number, Set/Clear Software Switch
- 0100 Switch Number
- 1 Parameter



S-COM Command Formats

### **DTMF Commands**

<password><root><parameters><terminator>

- Password
  - MPW, CPW, RBPW
- Root
  - Command number
    - 63, Set or Clear Software Switch
    - 09, Set Timer Reload Value
- Parameters
  - Identifier for Resource
  - Value to set resource to
    - Software Switch Number
    - Timer Number
- Terminator
  - Asterisk, \*

### Example

- 99 Password, default is 99
- 63 Root number, Set/Clear Software Switch
- 0100 Switch Number
- 1 Parameter
- \* Terminator



S-COM Command Formats

### **DTMF Commands**

<password><root><parameters><terminator>

- Password
  - MPW, CPW, RBPW
- Root
  - Command number
    - 63, Set or Clear Software Switch
    - 09, Set Timer Reload Value
- Parameters
  - Identifier for Resource
  - Value to set resource to
    - Software Switch Number
    - Timer Number
- Terminator
  - ASTERISK, \*
- Enter at Serial Console or via DTMF

### Example

**99 63 0100 1 \*** 

- 99 Password, default is 99
- 63 Root number, Set/Clear Software Switch
- 0100 Switch Number
- 1 Parameter
- \* Terminator

Note: Commands Usually Written With Space Between Command Elements For Readability.



S-COM Command Formats – DTMF Decoder Entry

### Valid DTMF Timing

- DTMF Digit ON at least 50 milliseconds
- DTMF digit OFF at least 50
  milliseconds


S-COM Command Formats – DTMF Decoder Entry

### Valid DTMF Timing

- DTMF Digit ON at least 50
  milliseconds
- DTMF digit OFF at least 50
  milliseconds

## **Special Keys**

- ASTERISK
  - Think of it as Enter
- POUND SIGN
  - Think of it as Clear Buffer





S-COM Command Formats – DTMF Decoder Entry

### Valid DTMF Timing

- DTMF Digit ON at least 50 milliseconds
- DTMF digit OFF at least 50 milliseconds

## **Special Keys**

- ASTERISK
  - Think of it as Enter
- POUND SIGN
  - Think of it as Clear Buffer

## **DTMF Interdigit Timing**

- Clears the command buffer when a command is not completed by an ASTERISK before it expires
- Defaults to 5.00 seconds
  - Think of it as automatic
     Clear Buffer or Enter



S-COM Command Formats – DTMF Decoder Entry

### Valid DTMF Timing

- DTMF Digit ON at least 50
  milliseconds
- DTMF digit OFF at least 50
  milliseconds

## **Special Keys**

- ASTERISK
  - Think of it as Enter
- POUND SIGN
  - Think of it as Clear Buffer

## **DTMF Interdigit Timing**

- Clears the command buffer when a command is not completed by an ASTERISK before it expires
- Defaults to 5.00 seconds
  - Think of it as automatic
     Clear Buffer or Enter

## **Customization Options**

- Execute on Interdigit Timer
- Execute on End-of-Transmission
- Execute on 4<sup>th</sup> Digit



S-COM Command Formats – Serial Console Entry

Serial Console Input	Example
<ul> <li>Console Prompt</li> </ul>	
<ul> <li>DTMF Command Format</li> </ul>	7330> <mark>996301001</mark> *
	OK 7330>99 63 0100 1 * ; Set Switch
	ОК
	7330>
	99 Password, default is 99
	63 Root number, Set/Clear Software

0100 Switch Number

Switch

- 1 Parameter
- \* Terminator

Serial Console Input	Example
Console Prompt	
<ul> <li>DTMF Command Format</li> </ul>	7330> <mark>9963</mark> 01001*
<ul> <li>Special Keys</li> <li>ASTERISK</li> <li>Optional On Serial Console</li> </ul>	OK 7330>99 63 0100 1 * ; Set Switch OK 7330>

- 99 Password, default is 99
- 63 Root number, Set/Clear Software Switch
- 0100 Switch Number
- 1 Parameter
- \* Terminator

Serial Console Input	Example
<ul> <li>Console Prompt</li> </ul>	
<ul> <li>DTMF Command Format</li> </ul>	7330> <mark>996301001</mark> *
<ul> <li>Special Keys</li> <li>ASTERISK <ul> <li>Optional On Serial Console</li> </ul> </li> <li>BACKSPACE</li> </ul>	OK 7330>99 63 0100 1 * ; Set Switch OK 7330>
<ul> <li>For Line Editing</li> </ul>	99 Password, default is 99

- 63 Root number, Set/Clear Software Switch
- 0100 Switch Number
- 1 Parameter
- \* Terminator

Serial Console Input	Example
<ul> <li>Console Prompt</li> </ul>	
<ul> <li>DTMF Command Format</li> </ul>	7330> <mark>996301001</mark> *
Special Keys <ul> <li>ASTERISK</li> <li>Optional On Serial Console</li> </ul>	OK 7330>99 63 0100 1 * ; Set Switch OK
<ul> <li>BACKSPACE</li> <li>For Line Editing</li> </ul>	7330>
• SPACE	99 Password, default is 99
<ul><li>Ignored</li><li>Add for Readability</li></ul>	63 Root number, Set/Clear Software Switch
	0100 Switch Number

- 1 Parameter
- \* Terminator



rest of line ignored

80

Serial Console Input	Example
<ul> <li>Console Prompt</li> </ul>	
<ul> <li>DTMF Command Format</li> </ul>	7330> <mark>9963</mark> 01001*
Special Keys	OK
<ul> <li>ASTERISK</li> </ul>	7330>99 63 0100 1 * ; Set Switch
<ul> <li>Optional On Serial Console</li> </ul>	OK
• BACKSPACE	7330>
<ul> <li>For Line Editing</li> </ul>	
• SPACE	99 Password, default is 99
<ul> <li>Ignored</li> </ul>	63 Root number, Set/Clear Software
<ul> <li>Add for Readability</li> </ul>	Switch
SEMICOLON	0100 Switch Number
- Optional	1 Parameter
<ul> <li>Starts a Comment</li> </ul>	* Terminator
<ul> <li>Semicolon and</li> </ul>	



### S-COM Command Formats – Responses

CW Response	Serial Port Response	
ОК	OK	
? err 1	Error: Wrong number of digits	
? err 2	Error: Incorrect digits	
? not found	Error: Macro name not found	
? dir full	Error: Macro directory full	
? too big	Error: Macro exceeds 200 digits	
? name used	Error: Macro name already exists	
?last	Error: Macro, cannot delete last command	
	Error: Line too long	
	Error: Invalid DTMF character	
	Error: Serial input overflow or receive error	

### **DTMF Responses**

- Returned in CW by Default
- Common Ones Can Be Changed

### S-COM Command Formats – Responses

CW Response	Serial Port Response	
ОК	OK	
? err 1	Error: Wrong number of digits	
? err 2	Error: Incorrect digits	
? not found	Error: Macro name not found	
? dir full	Error: Macro directory full	
? too big	Error: Macro exceeds 200 digits	
? name used	Error: Macro name already exists	
?last	Error: Macro, cannot delete last command	
	Error: Line too long	
	Error: Invalid DTMF character	
	Error: Serial input overflow or receive error	

### **DTMF Responses**

- Returned in CW by Default
- Common Ones Can Be Changed

## **Serial Responses**

- Text Responses
  - OK
  - Error: Followed By Reason



## Security

- Master Password
  - MPW
  - Can execute all root commands



## Security

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands



## Security

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands
- Macro-Only Password
  - Always digits "DD"
  - Can only be used within a macro
  - Must be enabled by software switch



## Security

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands
- Macro-Only Password
  - Always digits "DD"
  - Can only be used within a macro
  - Must be enabled by software switch
- Remote Base Password
  - RBPW
  - Used to control remote base radios
- " Note: coming in a future 7330 release



## Security

## Passwords

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands
- Macro-Only Password
  - Always digits "DD"
  - Can only be used within a macro
  - Must be enabled by software switch
- Remote Base Password
  - RBPW
  - Used to control remote base radios
- " Note: coming in a future 7330 release

# Valid Passwords

- 2, 4, or 6 digits long
- Digits 0 thru 9 and A thru D.



# Security

## Passwords

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands
- Macro-Only Password
  - Always digits "DD"
  - Can only be used within a macro
  - Must be enabled by software switch
- Remote Base Password
  - RBPW
  - Used to control remote base radios
- " Note: coming in a future 7330 release

# Valid Passwords

- 2, 4, or 6 digits long
- Digits 0 thru 9 and A thru D.

## **Defaults**

- Master Password
  - 99
- Control Operator Password
  - Not Set



## Security

## Passwords

- Master Password
  - MPW
  - Can execute all root commands
- Control Operator Password
  - CPW
  - Can be restricted to subset of root commands
- Macro-Only Password
  - Always digits "DD"
  - Can only be used within a macro
  - Must be enabled by software switch
- Remote Base Password
  - RBPW
  - Used to control remote base radios
- " Note: coming in a future 7330 release

# Valid Passwords

- 2, 4, or 6 digits long
- Digits 0 thru 9 and A thru D.

## **Defaults**

- Master Password
  - 99
- Control Operator Password
  - Not Set

# **Other Security Info**

- Autopatch Password
  - APW
  - User password to make a phone call
  - Note: previously used in S-COM MRC-100, 6K and 7K. Not available in 7330.



## Data Types

## **Basic/Simple Types**

- Software Switch
- Counter
- Timer
- Message
- Macro
- Event-Triggered Macro
- Booleans
- Logic Inputs
- Logic Outputs



## Data Types

## **Basic/Simple Types**

- Software Switch
- Counter
- Timer
- Message
- Macro
- Event-Triggered Macro
- Booleans
- Logic Inputs
- Logic Outputs

# **Complex Types**

- User Timer
- Activity Timer/Counter/Event-Triggered Macro
- Time-of-Day
- Scheduler Setpoint
- Analog Data Collection



## Data Types

**Type Number** 

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer



## Data Types

**Type Number** 

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

• Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.



Data Types

**Type Number** 

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

• Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.

## **Resource Number**



# Data Types

# **Type Number**

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

• Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.

# **Resource Number**

- R, Resolution
  - Timers:
    - 0 = 10 millisecond
    - 1 = 100 millisecond
    - 2 = 1000 millisecond, 1 Second
  - All Others set to zero



# Data Types

# **Type Number**

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

# **Resource Number**

- R, Resolution
  - Timers:
    - 0 = 10 millisecond
    - 1 = 100 millisecond
    - 2 = 1000 millisecond, 1 Second
  - All Others set to zero
- P, Port
  - 1 thru 3, Radio Ports
  - 9, Serial Port
- Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.



# Data Types

# **Type Number**

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

• Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.

# **Resource Number**

- R, Resolution
  - Timers:
    - 0 = 10 millisecond
    - 1 = 100 millisecond
    - 2 = 1000 millisecond, 1 Second
  - All Others set to zero
- P, Port
  - 1 thru 3, Radio Ports
  - 9, Serial Port
- XX, Number 0 thru 99



# Data Types

# **Type Number**

Type Number	Type Name
00	Timers
03	Software Switch
04	Boolean
05	Scheduler Setpoint
06	User Timer

• Note: This numbering is initially being used only in the If-Then-Else command. Future commands will also use it.

# **Resource Number**

- R, Resolution
  - Timers:
    - 0 = 10 millisecond
    - 1 = 100 millisecond
    - 2 = 1000 millisecond, 1 Second
  - All Others set to zero
- P, Port
  - 1 thru 3, Radio Ports
  - 9, Serial Port
- XX, Number 0 thru 99
- Note: Resource number currently used on Timers, Software Switches, Booleans, Event-Triggered Macros, Messages, Counters



### Data Types

Messages By Number				
	Assign with (FW) 31 (number) (message contents) * Review with (FW) 34 (number) *			
Page	Number	Description	Default	
Port-Specific Messages Replace the "r" with the Receiver Number Replace the "t" with the Transmitter Number				
9-27	0100	Path 1t (RX1-TX) Courtesy Message	Single-Tone Beep	
9-27	0101	Path 2t (RX2-TX) Courtesy Message	Single-Tone Beep	
9-27	0102	Path 3t (RX3-TX) Courtesy Message	Single-Tone Beep	
9-21	0103	Path 1t (RX1-TX) Timeout Message	TO in CW	
9-21	0t04	Path 2t (RX2-TX) Timeout Message	10 in CW	
9-21	0105	Path 3t (RX3-TX) Timeout Message	10 in CW	
9-22	0t06	Path 1t (RX1-TX) Timeout End Message	TO in CW	
9-22	0107	Path 2t (RX2-TX) Timeout End Message	10 in CW	
9-22	0108	Path 3t (RX3-TX) Timeout End Message	10 in CW	
12-5	0t09	TX Initial ID Message	ID in CW	
12-5	0010	TX Normal ID Message	ID in CW	
12-5	0(11	TX Impolite ID Message	ID in CW	
11-12	0(12	TX Dropout Message	None	

## Data Types

Messages By Number				
	Assign with (PW) 31 (number) (message contents) * Review with (PW) 34 (number) *			
Page	Number	Description	Default	
Port-Specific Messages Replace the "r" with the Receiver Number Replace the "t" with the Transmitter Number				
9-27	0100	Path 1t (RX1-TX) Courtesy Message	Single-Tone Beep	
9-27	0101	Path 2t (RX2-TX) Courtesy Message	Single-Tone Beep	
9-27	0102	Path 3t (RX3-TX) Courtesy Message	Single-Tone Beep	
9-21	0103	Path 1t (RX1-TX) Timeout Message	TO in CW	
9-21	0t04	Path 2t (RX2-TX) Timeout Message	10 in CW	
9-21	0105	Path 3t (RX3-TX) Timeout Message	10 in CW	
9-22	0t06	Path 1t (RX1-TX) Timeout End Message	TO in CW	
9-22	0107	Path 2t (RX2-TX) Timeout End Message	10 in CW	
9-22	0108	Path 3t (RX3-TX) Timeout End Message	TO in CW	
12-5	0109	TX Initial ID Message	ID in CW	
12-5	0110	TX Normal ID Message	ID in CW	
12-5	0(11	TX Impolite ID Message	ID in CW	
11-12	0112	TX Dropout Message	None	

General Purpose Switches			
Number	Page Description		
0000	4-6	Front Panel Enable	
0001	22-2	Scheduler Enable	
0002	21-9	Daylight Savings Time (USA) Enable	
0003	5-8	Macro Erase Command Returns OK Enable	
0004	5-17	Macro-Only Password Decoding Enable	
0011	15-6	Logic Output Inversion 1	
0012	15-6	Logic Output Inversion 2	
0013	15-6	Logic Output Inversion 3	
0014	15-6	Logic Output Inversion 4	
0015	15-6	Logic Output Inversion 5	



### Data Types

Messages By Number					
	Assign with (PW) 31 (number) (message contents) * Review with (PW) 34 (number) *				
Page	Number	Description	Default		
		Port-Specific Messages Replace the "r" with the Receiver Number Replace the "t" with the Transmitter Number			
9-27	0t00	Path 1t (RX1-TX) Courtesy Message	Single-Tone Beep		
9-27	0:01	Path 2t (RX2-TX) Courtesy Message	Single-Tone Beep		
9-27	0102	Path 3t (RX3-TX) Courtesy Message	Single-Tone Beep		
9-21	0t03	Path 1t (RX1-TX) Timeout Message	TO in CW		
9-21	0t04	Path 2t (RX2-TX) Timeout Message	10 in CW		
9-21	0105	Path 3t (RX3-TX) Timeout Message	10 in CW		
9-22	0t06	Path 1t (RX1-TX) Timeout End Message	TO in CW		
9-22	0t07	Path 2t (RX2-TX) Timeout End Message	10 in CW		
9-22	0108	Path 3t (RX3-TX) Timeout End Message	TO IN CW		
12-5	0109	TX Initial ID Message	ID in CW		
12-5	0010	TX Normal ID Message	ID in CW		
12-5	0(11	TX Impolite ID Message	ID in CW		
11-12	0(12	TX Dropout Message	None		

General Purpose Switches		
Number	Page Description	
0000	4-6	Front Panel Enable
0001	22-2	Scheduler Enable
0002	21-9	Daylight Savings Time (USA) Enable
0003	5-8	Macro Erase Command Returns OK Enable
0004	5-17	Macro-Only Password Decoding Enable
0011	15-6	Logic Output Inversion 1
0012	15-6	Logic Output Inversion 2
0013	15-6	Logic Output Inversion 3
0014	15-6	Logic Output Inversion 4
0015	15-6	Logic Output Inversion 5

#### Port-Specific Counters Replace the 'r' with the Receiver Number

Replace the "r" with the Receiver Number Replace the "t" with the Transmitter Number

Number	Page	Description
0t00	11-21	TX End-of-ActivityCounter
0t01	9-32	Path 1t End-of-ActivityCounter
0t02	9-32	Path 2t End-of-ActivityCounter
0t03	9-32	Path 3t End-of-Activity Counter



### Data Types

	Messages By Number			
	Assign with (PW) 31 (number) (message contents) * Review with (PW) 34 (number) *			
Page	Number	Description	Default	
		Port-Specific Messages Replace the "r" with the Receiver Number Replace the "t" with the Transmitter Number		
9-27	0t00	Path 1t (RX1-TX) Courtesy Message	Single-Tone Beep	
9-27	0:01	Path 2t (RX2-TX) Courtesy Message	Single-Tone Beep	
9-27	0102	Path 3t (RX3-TX) Courtesy Message	Single-Tone Beep	
9-21	0t03	Path 1t (RX1-TX) Timeout Message	TO in CW	
9-21	0104	Path 2t (RX2-TX) Timeout Message	TO IN CW	
9-21	0t05	Path 3t (RX3-TX) Timeout Message	10 in CW	
9-22	0t06	Path 1t (RX1-TX) Timeout End Message	TO in CW	
9-22	0107	Path 2t (RX2-TX) Timeout End Message	10 in CW	
9-22	0108	Path 3t (RX3-TX) Timeout End Message	10 in CW	
12-5	0t09	TX Initial ID Message	ID in CW	
12-5	0t10	TX Normal ID Message	ID in CW	
12-5	0(11	TX Impolite ID Message	ID in CW	
11-12	0(12	TX Dropout Message	None	

General Purpose Switches		
Number	Number Page Description	
0000	4-6	Front Panel Enable
0001	22-2	Scheduler Enable
0002	21-9	Daylight Savings Time (USA) Enable
0003	5-8	Macro Erase Command Returns OK Enable
0004	5-17	Macro-Only Password Decoding Enable
0011	15-6	Logic Output Inversion 1
0012	15-6	Logic Output Inversion 2
0013	15-6	Logic Output Inversion 3
0014	15-6	Logic Output Inversion 4
0015	15-6	Logic Output Inversion 5

# Port-Specific Counters Replace the 'r' with the Receiver Number

Replace the "t" with the Transmitter Number

Number	Page	Description
0t00	11-21	TX End-of-ActivityCounter
0t01	9-32	Path 1t End-of-ActivityCounter
0t02	9-32	Path 2t End-of-ActivityCounter
0t03	9-32	Path 3t End-of-Activity Counter

### 10ms Timers By Number

Assign with (PW) 09 (number) (value) Test with (PW) 76 00 (number) (nonzero macro) (zero macro) \*

Port-Specific Timers Replace the "r" with the Receiver/DTMF Decoder Number Replace the "t" with the Transmitter Number

Number	Page	Description
0t00	11-6	TX Courtesy Delay
0t01	11-10	TX Dropout Delay
0t02	11-17	TX PTT Minimum Unkey Delay
0t03	11-4	TX Turn-On Message Delay Value
0r04	7-9	DTMF Decoder Interdigit Time
0r05	7-22	DTMF Decoder Mute Hang Time, First Digit
0r06	7-23	DTMF Decoder Mute Hang Time, Other Digits
0r07	7-18	DTMF Decoder Disconnect Time
80r0	7-7	DTMF Decoder Anti-Falsing Time
60r0	10-9	COR Anti-Kerchunker Key-Up Delay
0r10	10-25	COR Pulse-Triggered Macro Minimum Pulse Duration
0r11	10-26	COR Pulse-Triggered Macro Maximum Gap Duration
0r12	10-4	COR Filter Delay
0r13	10-6	CTCSS Filter Delay
0t14	6-40	Message Handler Inter-Page Delay Value
0t15	13-7	CTCSS Encoder Time Value
0t16	13-8	CTCSS Encoder Reverse Burst Time Value
0r17	10-15	RX Audio Gate Delay Timer Value
0r18	10-13	RX Flutter Filter Timer Value

### Introduction to Owner Manual Pages

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

I Command Form:				
Comma	nd	F	orm	Data Digit
Select F	X1-TX1 Access Mode	(	PW) 57 11 x*	
Select F	X2-TX1 Access Mode	(	PW) 57 21 x*	1
Select F	X3-TX1 Access Mode	(	PW) 57 31 x*	
Select F	RX1-TX2 Access Mode	(	PW) 57 12 x*	
Select F	RX2-TX2 Access Mode	(	PW) 57 22 x *	(see table below)
Select F	RX3-TX2 Access Mode	(	PW) 57 32 x *	
Select F	RX1-TX3 Access Mode	(	PW) 57 13 x*	
Select F	RX2-TX3 Access Mode	(	PW) 57 23 x *	
Select F	RX3-TX3 Access Mode	(	PW) 57 33 x *	
Path Ac	ccess Modes:	<b>F 1 6</b>		
Mode	Access	Explanation		
0	No Access	The receiv	er does not keythetra	ansmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.		
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.		
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.		
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.		
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive		
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input		

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered



### Introduction to Owner Manual Pages

### Description

#### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path, Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

#### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	1

#### Path Access Modes:

Mode	Access	Explanation	
0	No Access	The receiver does not key the transmitter.	
1	Carrier	The receiver keys the transmitter when the COR input is active.	
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.	
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.	
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.	
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.	
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.	

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning	
?err1	wrong number of digits entered	
?err2	illegal digit entered	



### Introduction to Owner Manual Pages

### Description

#### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

## Syntax

Select RX1-TX2 Access Mode	(PW) 57 12 x*
Select RX2-TX2 Access Mode	(PW) 57 22 x*

(see table below)

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

#### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

#### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning	
?err1	wrong number of digits entered	
?err2	illegal digit entered	



### Introduction to Owner Manual Pages

### Description

#### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### **Syntax**

Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see ta

see table below)

### **Parameters**

#### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
		The receiver keys the transmitter when the CTCSS

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

#### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

#### Path Access Modes:

Mode	Access	Explanation	
0	No Access	The receiver does not key the transmitter.	
1	Carrier	The receiver keys the transmitter when the COR input is active.	
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.	
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.	
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.	
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.	
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.	

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
? err2	illegal digit entered





### Introduction to Owner Manual Pages

### Description

#### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### **Syntax**

Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see ta

see table below)

### Parameters

#### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
		The receiver keys the transmitter when the CTCSS

### Responses

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

#### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

#### Path Access Modes:

Mode	Access	Explanation	
0	No Access	The receiver does not key the transmitter.	
1	Carrier	The receiver keys the transmitter when the COR input is active.	
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.	
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.	
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COF input or the CTCSS input is active.	
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.	
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input	

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered



### Introduction to Owner Manual Pages

### Description

#### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

## Syntax

Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see ta

(see table below)

### Parameters

#### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
		The receiver keys the transmitter when the CTCSS

### Responses

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered

### Defaults

Default: All paths are in access mode 1 (Carrier).

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path, Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

#### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

#### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.

#### Acknowledgment: Sends OK message

#### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered
	-


Setting Time and Date

### Set Clock and Calendar

### Sets the clock and calendar.

- Enter all parameters shown below each time that you set the Clock and Calendar. Seconds are optional.
- All parameters consist of two digits except the day-of-week, which is one digit.
- The year parameter is needed for leap year correction.
- The clock and calendar is set when you release the (\*) button.
- Seconds are automatically set to 00 if not entered.

Command Form:		
Command	Form	Data Digit
Set Clock and Calendar	(PW) 25 (year, month, day-of-month, day-of-week, hour, minute, second)*	from table below
Data Digit	Explanation	
00-99	year	
01-12 (January is 01)	month	
01-31	day-of-month	
0-б (Sunday is 0)	day-of-week	
00-23 (24-hour format)	hour	
00-59	minute	
00-59	second (optional)	
Acknowledgment: Sends OK Errors:		
Error	Meaning	
?err 1	wrong number of digits	entered
? err 2	illegal parameter: any lettered key; month = 00 or greater tt day-of-month = 0 or gre day-of-week greater tha hour greater than 23; minute or second great	han 12; eater than 31; an 6; er than 59.

Default Condition: 00:00:00 on Sunday, January 1, 2006. Note that the clock and calendar are only initialized if not running during a *Cold Start*.



Setting Time and Date

## **Clock/Calendar**

- Used by
  - Automatic Daylight Saving Time
  - Speaking the Date and Time
  - Scheduling Events

### Set Clock and Calendar

Sets the clock and calendar.

- Enter all parameters shown below each time that you set the Clock and Calendar. Seconds are optional.
- All parameters consist of two digits except the day-of-week, which is one digit.
- The year parameter is needed for leap year correction.
- The clock and calendar is set when you release the (\*) button.
- Seconds are automatically set to 00 if not entered.

Command	Form	Data Digit	
Set Clock and Calendar	(PW) 25 (year,	from table below	
	month, day-of-month,		
	minute second)*		
	minute, secondy		
Data Digit	Explanation		
00-99	year		
01-12 (January is 01)	month		
01-31	day-of-month		
0-6 (Sunday is 0)	day-of-week		
00-23 (24-hour format)	hour		
00-59	minute	minute	
00-59	second (optional)	second (optional)	
Acknowledgment: Sends	OK		
Errors: Error			
Errors: Error ?err 1	wrong number of digits	entered	

Default Condition: 00:00:00 on Sunday, January 1, 2006. Note that the clock and calendar are only initialized if not running during a Cold Start.



Setting Time and Date

## **Clock/Calendar**

- Used by
  - Automatic Daylight Saving Time
  - Speaking the Date and Time
  - Scheduling Events

### 99 25 14 02 22 6 09 26 00 \*

Set	Clock	and	Calendar

Sets the clock and calendar.

- Enter all parameters shown below each time that you set the Clock and Calendar. Seconds are optional.
- All parameters consist of two digits except the day-of-week, which is one digit.
- The year parameter is needed for leap year correction.
- The clock and calendar is set when you release the (\*) button.
- Seconds are automatically set to 00 if not entered.

ommand	Form Data Digit	
at Clock and Calendar	(PW) 25 (year, from table	belov
	month, day-of-month,	
	day-of-week, hour,	
	minute, second)*	
Data Digit	Explanation	
0.09	year	
)1-12 (January is 01)	month	
01-31	day-of-month	
0-6 (Sunday is 0)	day-of-week	
0-23 (24-hour format)	hour	
00-59	minute	
0	second (optional)	
cknowledgment: Sends O rrors:	K	
cknowledgment: Sends O rrors: rror	Meaning	
cknowledgment: Sends O rrors: irror 'err 1	Meaning wrong number of digits entered	
cknowledgment: Sends O rrors: err 1 'err 2	Meaning wrong number of digits entered illegal parameter:	
cknowledgment: Sends O rrors: err 1 err 2	Meaning wrong number of digits entered illegal parameter: any lettered key;	
cknowledgment: Sends O rrors: Error ? err 1 ? err 2	Meaning wrong number of digits entered illegal parameter: any lettered key; month = 00 or greater than 12; day, of month = 0 or greater than 21	
cknowledgment: Sends O rrors: Fror ?err 1 ?err 2	Meaning wrong number of digits entered illegal parameter: any lettered key; month = 00 or greater than 12; day-of-month = 0 or greater than 31 day-of-week oreater than 6;	:
cknowledgment: Sends O rrors: Error ? err 1 ? err 2	Meaning wrong number of digits entered illegal parameter: any lettered key; month = 00 or greater than 12; day-of-month = 0 or greater than 31 day-of-week greater than 6; hour oreater than 23;	:

Default Condition: 00:00:00 on Sunday, January 1, 2006. Note that the clock and calendar are only initialized if not running during a Cold Start.



### Accessing the Repeater

## Path Access Modes:

Mode	Access	
0	No Access	
1	Carrier	
2	CTCSS	
3	Carrier AND CTCSS	_
4	Carrier OR CTCSS	
5	Anti-CTCSS	
6	Always On	

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

#### Path Access Modes: Mode Access Explanation No Access The receiver /

	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input

### Acknowledgment: Sends OK message

Errors:	
Frror	

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered





### Accessing the Repeater

### Path Access Modes:

Mode	Access	
0	No Access	
1	Carrier	
2	CTCSS	
3	Carrier AND CTCSS	
4	Carrier OR CTCSS	
5	Anti-CTCSS	
6	Always On	

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input

### Acknowledgment: Sends OK message

Errors:	
Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered



Accessing the Repeater

## Set the Access Mode for each Path

- 9 Paths Connect All Rx to All Tx
- Unique Path for Each

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

Mode	Access	Explanation
2	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COF input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.

Acknowledgment: Sends OK message

### Errors:

Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered



Accessing the Repeater

## Set the Access Mode for each Path

- 9 Paths Connect All Rx to All Tx
- Unique Path for Each



### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Command Form:

Command	Form	Data Digit
Select RX1-TX1 Access Mode	(PW) 57 11 x*	
Select RX2-TX1 Access Mode	(PW) 57 21 x*	
Select RX3-TX1 Access Mode	(PW) 57 31 x*	
Select RX1-TX2 Access Mode	(PW) 57 12 x*	
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select RX3-TX2 Access Mode	(PW) 57 32 x*	
Select RX1-TX3 Access Mode	(PW) 57 13 x*	
Select RX2-TX3 Access Mode	(PW) 57 23 x*	
Select RX3-TX3 Access Mode	(PW) 57 33 x*	

### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR input and the CTCSS input are active.
4	Carrier OR CTCSS	The receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.

### Acknowledgment: Sends OK message

Errors:	
Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered





Accessing the Repeater

## Set the Access Mode for each Path

- 9 Paths Connect All Rx to All Tx
- Unique Path for Each

99 57 11 3 \*



### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

### Command Form:

Command	Form	Data Digit	
Select RX1-TX1 Access Mode	(PW) 57 11 x*		
Select RX2-TX1 Access Mode	(PW) 57 21 x*		
Select RX3-TX1 Access Mode	(PW) 57 31 x*		
Select RX1-TX2 Access Mode	(PW) 57 12 x*		
Select RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)	
Select RX3-TX2 Access Mode	(PW) 57 32 x*		
Select RX1-TX3 Access Mode	(PW) 57 13 x*		
Select RX2-TX3 Access Mode	(PW) 57 23 x*		
Select RX3-TX3 Access Mode	(PW) 57 33 x*		

### Path Access Modes:

Mode	Access	Explanation
0	No Access	The receiver does not key the transmitter.
1	Carrier	The receiver keys the transmitter when the COR input is active.
2	CTCSS	The receiver keys the transmitter when the CTCSS input is active.
3	Carrier AND CTCSS	The receiver keys the transmitter when both the COR
0	00110111001000	input and the CTCSS input are active.
4	Carrier OR CTCSS	Ine receiver keys the transmitter when either the COR input or the CTCSS input is active.
5	Anti-CTCSS	The receiver keys the transmitter when the COR input is active and the CTCSS input is inactive.
6	Always On	The receiver keys the transmitter regardless of the COR input and the CTCSS input.

### Acknowledgment: Sends OK message

Errors:	
Error	Meaning
?err1	wrong number of digits entered
?err2	illegal digit entered



## **Transmitter Tail Timing**



## From Beginning of Courtesy Delay Until Transmitter Drops Is Tail Time

Defaults Appropriate for a Repeater

- Courtesy Delay
  - 0.50 second, default
- Dropout Delay
  - 3.00 second, default
- PTT Minimum Unkey Delay
  - 0.10 second, default
- CTCSS Reverse Burst Delay
  - OFF, default



Transmitter Tail Timing

• Set Courtesy Delay to 0.50 Second

99 09 0100 050 \*

Select Courtesy Delay	

Programs the Courtesy Delay time value.

• Enter the password, the two-digit root number, the four-digit timer number and one to five digits from 0 to 65535 to set the delay to 0.00 to 655.35 seconds.

### **Command Form:**

Command	Form	Data Digit
Select TX1 Courtesy Delay	(PW) 09 0100 xxxxx *	CEEDE -
Select TX2 Courtesy Delay	(PW) 09 0200 xxxxx *	0.655.25 accords
Select TX3 Courtesy Delay	(PW) 09 0300 xxxxx *	0-655.35 seconds

### Acknowledgment: Sends OK message

Errors:	
Error	Meaning
? err 1	wrong number of digits entered
? err 2	illegal digit entered

Default: The Courtesy Delay is 0.50 seconds.

### Examples:

To select a 1.5-second TX3 Courtesy Delay, enter:

(PW) 09 0300 150 \*

To eliminate the TX2 Courtesy Delay, enter:

(PW) 09 0200 0 \*



**Transmitter Tail Timing** 

• Set Dropout Delay to 3.00 Seconds

99 09 0101 300 \*

Select	Dropout Delay			
Programs the Dropout De	elay time value.			
<ul> <li>Enter the password, the two-digit root number, the four-digit timer number and one to five digits from 0 to 65535 to set the delay to 0.00 to 655.35 seconds.</li> <li>To disable the delay, set its value to 0.</li> </ul>				
Command Form:				
Command	Form	Data Digit		
Select TX1 Dropout Delay	(PM0.09.0101 vvvvv *			
Select IXT Diopout Delay	(144) 05 0101 22222	- xxxxx = 0.65523 =		
Select TX2 Dropout Delay Select TX2 Dropout Delay Select TX3 Dropout Delay	(PW) 09 0301 xxxxx * (PW) 09 0301 xxxxx *	xxxxx = 0.65533 = 0-655.35 seconds		
Select TX2 Dropout Delay Select TX3 Dropout Delay Acknowledgment: Sends Of	(FW) 09 0201 xxxxx * (FW) 09 0301 xxxxx *	xxxxx = 0.65595 = 0-655.35 seconds		
Select TX2 Dropout Delay Select TX3 Dropout Delay Acknowledgment: Sends O/ Errors:	(PW) 09 0201 xxxxx* (PW) 09 0301 xxxxx* (PW) 09 0301 xxxxx*	xxxxx = 0.65533 = 0-655.35 seconds		
Select TX2 Dropout Delay Select TX3 Dropout Delay Acknowledgment: Sends O/ Errors: Error	(PW) 09 0201 xxxxx * (PW) 09 0301 xxxxx * K message Meaning	xxxx = 0.65535 = 0-655.35 seconds		
Select TX2 Dropout Delay Select TX2 Dropout Delay Acknowledgment: Sends Of Errors: Error ? err 1	(PW) 09 0201 xxxxx * (PW) 09 0301 xxxxx * (PW) 09 0301 xxxxx * K message Meaning wrong number of digi	xxxx = 0.65533 = 0-655.35 seconds		
Select TX2 Dropout Delay Select TX2 Dropout Delay Acknowledgment: Sends O/ Errors: Error ? err 1 ? err 2	(PW) 09 0201 xxxxx * (PW) 09 0301 xxxxx * (PW) 09 0301 xxxxx * K message Meaning wrong number of digi illegal digit entered	xxxx = 0.65535 = 0-655.35 seconds ts entered		
Select TX3 Dropout Delay Select TX3 Dropout Delay Acknowledgment: Sends O/ Errors: Error ? err 1 ? err 2 Default: Dropout Delay is 3.0	(PW) 09 0201 xxxxx * (PW) 09 0301 xxxxx * K message Meaning wrong number of digi illegal digit entered seconds	ts entered		
Select TX2 Dropout Delay Select TX2 Dropout Delay Acknowledgment: Sends O/ Errors: Error ? err 1 ? err 2 Default: Dropout Delay is 3.0 Examples: To set TX1's Dropout Delay to	(PW) 09 0201 xxxxx* (PW) 09 0301 xxxxx* K message Meaning wrong number of digi illegal digit entered seconds	xxxx = 0.65535 = 0-655.35 seconds ts entered		
Select TX2 Dropout Delay Select TX2 Dropout Delay Acknowledgment: Sends O/ Errors: Error ? err 1 ? err 2 Default: Dropout Delay is 3.0 Examples: To set TX1's Dropout Delay to (PW) 09 0101 250 *	(PW) 09 0201 xxxxx* (PW) 09 0301 xxxxx* K message Meaning wrong number of digi illegal digit entered seconds	ts entered		
Select TX2 Dropout Delay Select TX2 Dropout Delay Acknowledgment: Sends O/ Errors: Error ? err 1 ? err 2 Default: Dropout Delay is 3.0 Examples: To set TX1's Dropout Delay to (PW) 09 0101 250 *	(PW) 09 0201 xxxxx* (PW) 09 0301 xxxxx* K message Meaning wrong number of digi illegal digit entered seconds 0 2.5 seconds, enter:	ts entered		



**Transmitter Tail Timing** 

 Set PTT Minimum Unkey Delay to 0.75 Second

99 09 0102 75 \*

### Select Transmitter PTT Minimum Unkey Delay

Programs the minimum amount of time for a transmitter PTT to be keyed before unkeying.

- Enter the password, the two-digit root number, the four-digit timer number, and one to five digits from 0 to 65535 to set the delay to 0.00 to 655.35 seconds.
- To disable the delay, set the timer to zero.

Command Form:		
Command	Form	Data Digit
Select TX1 Minimum Unkey Delay	(PW) 09 0102 xxxxx *	
Select TX2 Minimum Unkey Delay	(PW) 09 0202 XXXXX *	0-655.35 seconds
Select TX3 Minimum Unkey Delay	(PW) 09 0302 xxxxx *	

Acknowledgment: Sends OK message

Meaning
wrong number of digits entered
invalid timer or seconds parameter

Default: The Minimum Unkey Delay is 0.10 second.

### Example:

To set the TX2 Minimum Unkey Delay to 0.20 seconds, enter:

(PW) 09 0202 20 \*



## **Transmitter Tail Timing**



### From Beginning of Courtesy Delay Until Transmitter Drops Is Tail Time

Defaults Appropriate for a Repeater

- Courtesy Delay
  - 0.50 second, default
- Dropout Delay
  - 3.00 second, default
- PTT Minimum Unkey Delay
  - 0.10 second, default
- CTCSS Reverse Burst Delay
  - OFF, default



**Introducing Messages** 

### Message Format

<type><characters>

- Type Identified by Message Control Characters
- A Message is Processed Left to Right An Even Number of Digits At a Time

Example:

9900 32 10 01 19 17 20 38 27

Sends in CW: WA1JHK/R

## **Message Control Characters**

Control Character	Definition	Page
97xx	Message Routing characters follow	6-4
9900	CW characters follow	6-13
9901	CW Primary characters follow	6-13
9902	CW Secondary characters follow	6-13
9903	CW Speed Change characters follow	6-15
9904	CW Frequency Change characters follow	6-15
9905	CW Message Level characters follow	6-14
9910	Single-Tone Beep characters follow	6-21
9911	Single-Tone Beep Primary characters follow	6-21
9912	Single-Tone Beep Secondary characters follow	6-21
9913	Single-Tone Beep Message Level characters follow	6-22
9915	Dual-Tone Beep characters follow	6-31
9916	Dual-Tone Beep Primary characters follow	6-31
9917	Dual-Tone Beep Secondary characters follow	6-31
9918	Dual-Tone Beep Message Level characters follow	6-32
9920	Single-Tone page follows	6-38
9930	Two-Tone Sequential page follows	6-40
9940	5/6-Tone page follows	6-42
9950	DTMF page follows	6-44
9955	SELCAL page follows	6-52
9960	Speech characters follow	6-54
9961	Speech Primary characters follow	6-54
9962	Speech Secondary characters follow	6-54
9963	Speech Message Level characters follow	6-55
9991	Mixed Audio Allowed	6-6
9992	Non-Mixed Audio Only	6-6
9993	Pause characters follow	6-7
9999	Execute the macro that follows	6-8



Identifier Message

## **CW Messages**

Starts With Type

- 9900

- Followed By Pairs Of Digits
  - Each digit-pair is a CW Character

9900 32 10 01 19 17 20 38 27

Sends in CW: WA1JHK/R

## CW Alphanumeric Characters

Control Character 9900/9901/9902

Characte	Code	Characte	Code
r		r	
0	00		18
1	01	J	19
2	02	K	20
3	03	L	21
4	04	М	22
5	05	N	23
6	06	0	24
7	07	Р	25
8	08	Q	26
9	09	R	27
A	10	S	28
В	11	Т	29
С	12	U	30
D	13	V	31
E	14	W	32
F	15	Х	33
G	16	Y	34
H	17	Z	35



### Identifier Message

### **Programming the Normal Identifier Message**

- Message Commands
  - Define A Message
  - Review A Message
  - Play A Message
- To Set An Identifier Message

**99** 31 0110 9900 32 10 01 19 17 20 38 27 \*

• To Review An Identifier Message

### Select/Review Identifier Messages

Define the Initial ID, Normal ID, and Impolite ID Messages for each transmitter.

- To change a message: enter the password, the 2-digit root number and 4digit message number shown, followed by the desired message.
- Any message may be a combination of message types including CW, beeps, page tones, speech, etc.
- The maximum size of any message is 50 bytes (50 2-digit codes). You
  must count the control characters. Therefore, any message could have 46
  CW characters, 23 synthesized speech words, etc.
- To delete a message, enter the password, the 4-digit root number, and the (\*); do not enter any message.
- If an Initial ID Message is not programmed, the Normal ID Message is sent.
- If an Impolite ID Message is not programmed, the Normal ID Message is sent.
- If the Initial, Normal, and Impolite messages for a transmitter are all deleted, the Identifier is disabled for that transmitter.

### Command Form:

<

Command	Form	Default
Select Initial ID Message for TX1	(PW) 31 0109 (message) *	ID in CW, 587 Hz
Select Normal ID Message for TX1	(PW) 31 0110 (message) *	10 M CW, 587 Hz
Select Impolite ID Message for TX1	(PW) 31 0111 (message) *	none
Select Initial ID Message for TX2	(PW) 31 0209 (message) *	ID in CW, 698 Hz
Select Normal ID Message for TX2	(PW) 31 0210 (message) *	ID in CW, 698 Hz
Select Impolite ID Message for TX2	(PW) 31 0211 (message) *	none
Select Initial ID Message for TX3	(PW) 31 0309 (message) *	ID in CW, 1046 Hz
Select Normal ID Message for TX3	(PW) 31 0310 (message) *	ID in CW, 1046 Hz
Select Impolite ID Message for TX3	(PW) 31 0311 (message) *	none
Review Initial ID Message for TX1	(PW) 34 0109*	none
Review Normal ID Message for TX1	(PW) 34 0110 *	1100-2
Review Impolite ID Message for TX1	(PW) 34 0111 *	none
Review Initial ID Message for TX2	(PW) 34 0209 *	none
Review Normal ID Message for TX2	(PW) 34 0210 *	none
Review Impolite ID Message for TX2	(PW) 34 0211 *	none
Review Initial ID Message for TX3	(PW) 34 0309 *	none
Review Normal ID Message for TX3	(PW) 34 0310 *	none
Review Impolite ID Message for TX3	(PW) 34 0311 *	none





Testing Your Results on the Bench

## How Do We Know It Works?

- Test Access Mode of COR-Only
  - 1. Program Identifier Message
  - 2. Review Identifier Message
  - 3. Close COR Switch
  - 4. See COR LED ON
  - 5. See PTT LED ON
  - 6. Open COR Switch
  - 7. See COR LED OFF
  - 8. Hear Courtesy Beep
  - 9. Hear CW Identifier
  - 10. See PTT LED OFF after Tx Tail Time





Customizing Your Courtesy Message

### **Message Format**

<type><characters>

- Type Identified by Message Control Characters
- A Message is Processed Left to Right An Even Number of Digits At a Time

Example:

9910 65 74 24 24

Sends Two 1000Hz Beeps Separated by 80 ms.

## Message Control Characters

Control Character	Definition	
97xx	Message Routing characters follow	6-4
9900	CW characters follow	6-13
9901	CW Primary characters follow	6-13
9902	CW Secondary characters follow	6-13
9903	CW Speed Change characters follow	6-15
9904	CW Frequency Change characters follow	6-15
9905	CW Message Level characters follow	6-14
9910	Single-Tone Beep characters follow	6-21
9911	Single-Tone Beep Primary characters follow	6-21
9912	Single-Tone Beep Secondary characters follow	6-21
9913	Single-Tone Beep Message Level characters follow	6-22
9915	Dual-Tone Beep characters follow	6-31
9916	Dual-Tone Beep Primary characters follow	6-31
9917	Dual-Tone Beep Secondary characters follow	6-31
9918	Dual-Tone Beep Message Level characters follow	6-32
9920	Single-Tone page follows	6-38
9930	Two-Tone Sequential page follows	6-40
9940	5/6-Tone page follows	6-42
9950	DTMF page follows	6-44
9955	SELCAL page follows	6-52
9960	Speech characters follow	6-54
9961	Speech Primary characters follow	6-54
9962	Speech Secondary characters follow	6-54
9963	Speech Message Level characters follow	6-55
9991	Mixed Audio Allowed	6-6
9992	Non-Mixed Audio Only	6-6
9993	Pause characters follow	6-7
9999	Execute the macro that follows	6-8



Customizing Your Courtesy Message

## Single-Tone Beep Messages

Start With Type

- 9910

- Followed by Pairs of Digits
  - Beeps
  - Gaps
  - Durations

Example:

9910 65 74 24 24

Factory-Fixed Frequency Beeps								
			Control Ch	aracter 9910/	9901/9902			
Freq	Freq Note Beep Freq Note Beep Freq Note Beep							
262Hz	C3	00	659Hz	E4	16	1661Hz	G#5	32
277Hz	C#3	01	698Hz	F4	17	1760Hz	A5	33
294Hz	D3	02	740Hz	F#4	18	1865Hz	A#5	34
311Hz	D#3	03	784Hz	G4	19	1976Hz	B5	35
330Hz	E3	04	831Hz	G#4	20	2093Hz	C6	36
349Hz	F3	05	880Hz	A4	21	2217Hz	C#6	37
370Hz	F#3	06	932Hz	A#4	22	2349Hz	D6	38
392Hz	G3	07	988Hz	B4	23	2489Hz	D#6	39
415Hz	G#3	08 🤇	1046Hz	C5	24	2637Hz	E6	40
440Hz	A3	09	1109Hz	C#5	25	2794Hz	F6	41
466Hz	A#3	10	1175Hz	D5	26	2960Hz	F#6	42
494Hz	B3	11	1244Hz	D#5	27	3136Hz	G6	43
523Hz	C4	12	1319Hz	E5	28	3322Hz	G#6	44
554Hz	C#4	13	1397Hz	F5	29	3520Hz	A6	45
587Hz	D4	14	1480Hz	F#5	30	3729Hz	A#6	46
622Hz	D#4	15	1568Hz	G5	31	3951Hz	B6	47



**Customizing Your Courtesy Message** 

## Single-Tone Beep Messages

• Start With Type

- 9910

- Followed by Pairs of Digits
  - Beeps
  - Gaps
  - Durations

Example:

9910 65 74 24 24

## Single-Tone Beep Gap Change Characters

	Control Character 9910/9911/9912				
	Beep Gap Change	Code			
	10mS	60			
	20mS	61			
	30mS	62			
	40mS	63			
	60mS	64			
1	80mS	65			
	120mS	66			
	160mS	67			
	240mS	68			
	320mS	69			

**Customizing Your Courtesy Message** 

## Single-Tone Beep Messages

• Start With Type

- 9910

- Followed by Pairs of Digits
  - Beeps
  - Gaps
  - Durations

Example: 9910 65 74 24 24

## Single-Tone Beep Duration Change Characters

Beep Duration ChangeCode10mS7020mS7130mS7240mS7360mS7480mS75120mS76160mS77240mS78320mS79		Control Characte	er 9910/9911/9912
10mS       70         20mS       71         30mS       72         40mS       73         60mS       74         80mS       75         120mS       76         160mS       77         240mS       78         320mS       79		Beep Duration Change	Code
20mS       71         30mS       72         40mS       73         60mS       74         80mS       75         120mS       76         160mS       77         240mS       78         320mS       79		10mS	70
30mS       72         40mS       73         60mS       74         80mS       75         120mS       76         160mS       77         240mS       78         320mS       79		20mS	71
40mS       73         60mS       74         80mS       75         120mS       76         160mS       77         240mS       78         320mS       79		30mS	72
60mS       74         80mS       75         120mS       76         160mS       77         240mS       78         320mS       79		40mS	73
80mS       75         120mS       76         160mS       77         240mS       78         320mS       79	$\triangleleft$	60mS	74
120mS       76         160mS       77         240mS       78         320mS       79		80mS	75
160mS       77         240mS       78         320mS       79		120mS	76
240mS         78           320mS         79		160mS	77
320mS 79		240mS	78
		320mS	79



Courtesy Message

## Programming a Courtesy Message

- Message Commands
  - Define a Message
  - Review a Message
- To Set a Courtesy Message
   99 31 0100 9910 65 74 24
   24 \*
- To Review a Courtesy Message
   99 34 0100 \*

### Select/Review Path Courtesy Message

Program or review the Path Courtesy Msessage that is sent when the Path Courtesy Timer expires.

- To program a message, enter the password, the two-digit root number, the four-digit message number, and the message.
- To delete a message, enter the command but omit the message.
- To review a message, enter the password, the two-digit root number, and the four-digit message number.

### **Command Form:**

	Command	Form	Default
<	Select RX1-TX1 Courtesy Message	(PW) 31 0100 (message) *	523Hz, 60 ms
	Select RX2-TX1 Courtesy Message	(PW) 31 0101 (message) *	659 Hz, 60 ms
	Select RX3-TX1 Courtesy Message	(PW) 31 0102 (message) *	784 Hz, 60 ms
	Select RX1-TX2 Courtesy Message	(PW) 31 0200 (message) *	988 Hz, 60 ms
	Select RX2-TX2 Courtesy Message	(PW) 31 0201 (message) *	1175 Hz, 60 ms
	Select RX3-TX2 Courtesy Message	(PW) 31 0202 (message) *	1397 Hz, 60 ms
	Select RX1-TX3 Courtesy Message	(PW) 31 0300 (message) *	1568 Hz, 60 ms
	Select RX2-TX3 Courtesy Message	(PW) 31 0301 (message) *	1760 Hz, 60 ms
	Select RX3-TX3 Courtesy Message	(PW) 31 0302 (message) *	1976 Hz, 60 ms
<	Review RX1-TX1 Courtesy Message	(PW) 34 0100 *	Ν
	Review RX2-TX1 Courtesy Message	(PW) 34 0101 *	
	Review RX3-TX1 Courtesy Message	(PW) 34 0102 *	
	Review RX1-TX2 Courtesy Message	(PW) 34 0200 *	
	Review RX2-TX2 Courtesy Message	(PW) 34 0201 *	
	Review RX3-TX2 Courtesy Message	(PW) 34 0202 *	
	Review RX1-TX3 Courtesy Message	(PW) 34 0300 *	
	Review RX2-TX3 Courtesy Message	(PW) 34 0301 *	
-	Review RX3-TX3 Courtesy Message	(PW) 34 0302 *	



Testing Your Results on the Bench

## How Do We Know It Works?

- Courtesy Beep
  - 1. Program Courtesy Message
  - 2. Review Courtesy Message
  - 3. Close COR Switch
  - 4. See COR LED ON
  - 5. See PTT LED ON
  - 6. Open COR Switch
  - 7. See COR LED OFF
  - 8. Hear Courtesy Message
  - 9. See PTT LED OFF after Tx Tail Time



**Introducing Messages** 

### Message Format

<type><characters>

- Type Identified by Message Control Characters
- A Message is Processed Left to Right An Even Number of Digits At a Time

Example:

# **9960** 0067 0045 0001 0054 0052 0055

Sends in Speech: WA1JHK/R

## **Message Control Characters**

Control Character	Definition	Page
97xx	Message Routing characters follow	6-4
9900	CW characters follow	6-13
9901	CW Primary characters follow	6-13
9902	CW Secondary characters follow	6-13
9903	CW Speed Change characters follow	6-15
9904	CW Frequency Change characters follow	6-15
9905	CW Message Level characters follow	6-14
9910	Single-Tone Beep characters follow	6-21
9911	Single-Tone Beep Primary characters follow	6-21
9912	Single-Tone Beep Secondary characters follow	6-21
9913	Single-Tone Beep Message Level characters follow	6-22
9915	Dual-Tone Beep characters follow	6-31
9916	Dual-Tone Beep Primary characters follow	6-31
9917	Dual-Tone Beep Secondary characters follow	6-31
9918	Dual-Tone Beep Message Level characters follow	6-32
9920	Single-Tone page follows	6-38
9930	Two-Tone Sequential page follows	6-40
9940	5/6-Tone page follows	6-42
9950	DTMF page follows	6-44
9955	SELCAL page follows	6-52
9960	Speech characters follow	6-54
9961	Speech Primary characters follow	6-54
9962	Speech Secondary characters follow	6-54
9963	Speech Message Level characters follow	6-55
9991	Mixed Audio Allowed	6-6
9992	Non-Mixed Audio Only	6-6
9993	Pause characters follow	6-7
9999	Execute the macro that follows	6-8



### **Identifier Message**

	Letters							
	Word	Code	Word	Code	Word	Code	Word	Code
$\triangleleft$	А	0045	ж	0052	A	0059	U	0065
	В	0046		0053	Р	0060	V	0066
	С	004ズ	J	0054	A	006	W	0067
	D	0048	К	0055	A	0062	Х	0068
	E	0049	L	0056	S	0063	Y	0069
	F	0050	Μ	0057	Т	0064	Z	0070
	G	0051	Ν	0058				

### **Speech Messages**

• Starts With Type

### - 9960

- Followed By Pairs Of Digits
  - Each 4-digits is a Speech Word

### **9960** 0067 0045 0001 0054 0052 0055

Sends in Speech: WA1JHK

	Word	Code	V
	zero	0000	sixtł
V	one	0001	seve
	first	0002	seve
	two	0003	eigh



Speech Identifier Message

### Programming the Initial Identifier Message

- Message Commands
  - Define A Message
  - Review A Message
- To Set an Initial Identifier Message as Speech
  99 31 0109 9960 0067 0045 0001 0054 0052 0055 \*
- To Review an Initial Identifier Message
   99 34 0109 \*

### Select/Review Identifier Messages

Define the Initial ID, Normal ID, and Impolite ID Messages for each transmitter.

- To change a message: enter the password, the 2-digit root number and 4digit message number shown, followed by the desired message.
- Any message may be a combination of message types including CW, beeps, page tones, speech, etc.
- The maximum size of any message is 50 bytes (50 2-digit codes). You
  must count the control characters. Therefore, any message could have 46
  CW characters, 23 synthesized speech words, etc.
- To delete a message, enter the password, the 4-digit root number, and the (\*); do not enter any message.
- If an Initial ID Message is not programmed, the Normal ID Message is sent.
- If an Impolite ID Message is not programmed, the Normal ID Message is sent.
- If the Initial, Normal, and Impolite messages for a transmitter are all deleted, the Identifier is disabled for that transmitter.

Command	Form	Default
Select Initial ID Message for TX1	(PW) 31 0109 (message) *	ID in 2W, 587 Hz
Select Normal ID Message for TX1	(PW) 31 0110 (message) *	ID in CW, 587 Hz
Select Impolite ID Message for TX1	(PW) 31 0111 (message) *	none
Select Initial ID Message for TX2	(PW) 31 0209 (message) *	ID in CW, 698 Hz
Select Normal ID Message for TX2	(PW) 31 0210 (message) *	ID in CW, 698 Hz
Select Impolite ID Message for TX2	(PW) 31 0211 (message) *	none
Select Initial ID Message for TX3	(PW) 31 0309 (message) *	ID in CW, 1046 Hz
Select Normal ID Message for TX3	(PW) 31 0310 (message) *	ID in CW, 1046 Hz
Select Impolite ID Message for TX3	(PW) 31 0311 (message) *	none
Review Initial ID Message for TX1	(PW) 34 0109*	TODA -
Review Normal ID Message for TX1	(PW) 34 0110 *	none
Review Impolite ID Message for TX1	(PW) 34 0111 *	none
Review Initial ID Message for TX2	(PW) 34 0209 *	none
Review Normal ID Message for TX2	(PW) 34 0210 *	none
Review Impolite ID Message for TX2	(PW) 34 0211 *	none
Review Initial ID Message for TX3	(PW) 34 0309 *	none
Review Normal ID Message for TX3	(PW) 34 0310 *	none
Review Impolite ID Message for TX3	(PW) 34 0311 *	none



Testing Your Results on the Bench

## How Do We Know It Works?

- Test Access Mode of COR-Only
  - 1. Program Identifier Message
  - 2. Review Identifier Message
  - 3. Close COR Switch
  - 4. See COR LED ON
  - 5. See PTT LED ON
  - 6. Open COR Switch
  - 7. See COR LED OFF
  - 8. Hear Courtesy Beep
  - 9. Hear Speech Identifier
  - 10. See PTT LED OFF after Tx Tail Time





# Agenda

### Introduction

• Who is S-COM?

### The Basics

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 136 CTRESTING YOUM RESults

### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

### File Management

Introducing SBOOT

### **PC-Based Utilities**

• S-COM Custom Audio Utility

### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



Introduction to Ports and Paths



- Timers
- Software Switches
- Event-Triggered Macros



Introduction to Ports and Paths

## **Transmitter Port**

- Audio Summing
- Dual-Tone Generator
- Programmable Tone and Speech Levels
- Speech Generator
- Gain
- Timers
- Software Switches
- Event-Triggered
   Macros
- Messages





Introduction To Ports and Paths

## Paths

- Connect from any RX to any TX
   Example #1
- 3 Standalone Repeaters
  - RX1 to TX1
  - RX2 to TX2
  - RX3 to TX3
- ALL other paths OFF

## Example #2

- 2 Linked Repeaters
  - RX1 to TX1
  - RX1 to TX2, RX2 to TX2
  - RX2 to TX1
- 1 Standalone Repeaters
  - RX3 to TX3
- ALL other paths OFF





Introduction To Ports and Paths

### **Paths**

- Connect from any RX to any TX
- Set Access Mode by Path
- Enable/Disable by Path
- Enable/Disable by Receiver



## Path Access Modes

### **Access Modes**

Unique Access Mode By Path

- No Access
- COR Only
- CTCSS Only
- COR AND CTCSS
- COR OR CTCSS
- Anti-CTCSS
  - COR AND NOT CTCSS
- Always On

### Select Path Access Mode

Selects the access mode for each receiver-to-transmitter path.

- Programming the Path Access Mode does not affect the Path Enable/Disable Software Switch (see page 9-6).
- Enter the password, the two-digit root number, the two-digit path number, and a one-digit mode number.

Comma	IP S	Form	Data Digit
Select	RX1-TX1 Access Mode	(PW) 57 11 x*	
Select I	RX2-TX1 Access Mode	(PW) 57 21 x*	
Select	RX3-TX1 Access Mode	(PW) 57 31 x*	
Select	RX1-TX2 Access Mode	(PW) 57 12 x*	
Select	RX2-TX2 Access Mode	(PW) 57 22 x*	(see table below)
Select	RX3-TX2 Access Mode	(PW) 57 32 x*	
Select	RX1-TX3 Access Mode	(PW) 57 13 x*	
Select	RX2-TX3 Access Mode	(PW) 57 23 x*	
Select	RX3-TX3 Access Mode	(PW) 57 33 x*	
Mode	Access	Explanation	
Mode )	Access No Access	Explanation The receiver does not key the	e transmitter.
Mode ) 1	Access No Access Carrier	Explanation The receiver does not key the The receiver keys the transm is active.	e transmitter. nitter when the COR input
Mode	Access No Access Carrier CTCSS	Explanation The receiver does not key th The receiver keys the transm is active. The receiver keys the transm input is active.	e transmitter. nitter when the COR input nitter when the CTCSS
Mode D 1 2 3	Access No Access Carrier CTCSS Carrier AND CTCSS	Explanation The receiver does not keyth The receiver keys the transm is active. The receiver keys the transm input is active. The receiver keys the transm input and the CTCSS input a	e transmitter. nitter when the COR insur nitter when the CTCSS nitter when both the COR re active.
Mode 0 1 2 3 4	Access No Access Carrier CTCSS Carrier AND CTCSS Carrier OR CTCSS	Explanation The receiver does not keyth The receiver keys the transm is active. The receiver keys the transm input is active. The receiver keys the transm input and the CTCSS input a The receiver keys the transm input or the CTCSS input is a	e transmitter. nitter when the COR input nitter when the CTCSS nitter when both the COR re active. nitter when either the COP notive.
Mode 0 1 2 3 4 5	Access No Access Carrier CTCSS Carrier AND CTCSS Carrier OR CTCSS Anti-CTCSS	Explanation The receiver does not keyth The receiver keys the transm is active. The receiver keys the transm input is active. The receiver keys the transm input and the CTCSS input a The receiver keys the transm input or the CTCSS inputs a The receiver keys the transm is active and the CTCSS inputs	e transmitter. nitter when the COR input nitter when the CTCSS nitter when both the COR re active. nitter when either the COI ictive. nitter when the COR input ut is in active.

### Errors:

Error	Meaning
?err1	wrong number of digits entered
? err2	illegal digit entered



## Path Control

## **Enable/Disable by Path**

Complete Control

## **Examples**

- Repeater
  - Path on Same Port ON
  - (Repeat Path ON)
- Linked Repeater
  - Paths Between Ports ON
- Simplex/Remote Base
  - Path on Same Port OFF
  - (Repeat Path OFF)

## Control Receiver

All Paths OFF

### Enable/Disable Path

Turns ON or OFF a specific path.

- Enabling or disabling a path does not change the programmed Path Access Mode for that path (see page 9-7).
- Enter the password, the two-digit root number, the four-digit software switch number, and one digit (0 to disable the path, 1 to enable it).

e e i i i e i i e i e i e i e i e i e i	Form	Data Digit		
Enable/Disable RX1-TX1 Path	(PW) 63 0141 x *			
Enable/Disable RX2-TX1 Path	(PW) 63 0142 x *			
Enable/Disable RX3-TX1 Path	(PW) 63 0143 x *			
Enable/Disable RX1-TX2 Path	(PW) 63 0241 x *			
Enable/Disable RX2-TX2 Path	(PW) 63 0242 x *	U = OFF (disabled)		
Enable/Disable RX3-TX2 Path	(PW) 63 0243 x *	T = ON (enabled)		
Enable/Disable RX1-TX3 Path	(PW) 63 0341 x *			
Enable/Disable RX2-TX3 Path	(PW) 63 0342 x *			
Enable/Disable RX3-TX3 Path	(PW) 63 0343 x *			
Acknowledgment: Sends OK m	essage			
Errors:		Meaning		
Errors:	Meaning			
Errors: Error ? err 1	Meaning wrong number of dig	its entered		



Configure Values by Path

## **Timeout Timer**

- Set Timeout Time
- Set Timeout Penalty Time
- Set Message to Play
- Set Macro to Execute
- Reset Timeout Timer Command

### **Courtesy Message**

- Set Courtesy Message
- Set Courtesy Macro

## Activity Timer/Counter/Macro

- Set Timer
- Set Counter
- Set Macro

Select Fath	rimeout value			
Controls the maximum amount of time a path can be active.				
<ul> <li>Enter the password, the two-diand one to five digits from 0 to 65535 seconds.</li> <li>Set the timeout value to zero to be the timeout value to zero</li></ul>	igit root number, the four- 65535 to set the path tin o disable the Path Timeo	digit timer number neout timer to 0 to ut Timer.		
Command Form:		_		
Command	Form	Data Digit		
Select RX1-TX1 Timeout Value	(PW) 09 2100 xxxxx *			
Select RX2-TX1 Timeout Value	(PW) 09 2101 XXXXX *			
Select RX3-TX1 Timeout Value	(PW) 09 2102 xxxxx *			
Select RX1-TX2 Timeout Value	(PW) 09 2200 xxxxx *	- 0 CEE2E -		
Select RX2-TX2 Timeout Value	(PW) 09 2201 xxxxx *	XXXXX = 0-00000 =		
Select RX3-TX2 Timeout Value	(PW) 09 2202 xxxxx *	0-00000 seconds		
Select RX1-TX3 Timeout Value	(PW) 09 2300 xxxxx *			
Select RX2-TX3 Timeout Value	(PW) 09 2301 xxxxx *			
Select RX3-TX3 Timeout Value	(PW) 09 2302 xxxxx *			
Acknowledgment: Sends OK me Errors:	essage			
Error	Meaning			
? err 1	wrong number of digits	entered		
? err 2	illegal digit entered			
Default: All Path Timeout Timers	default to 180 seconds (3	3 minutes).		

(PW) 09 2100 270 \*

seconds/minute to get 270 seconds. Enter:

To set the RX2-TX1 timeout timer to 10 minutes (600 seconds), enter:

(PW) 09 2101 600 \*



## More About Messages

### Message Format

### <type><characters>

- Message Control Characters
  - Define A Message Type

### Examples:

- CW, 9900 32 10 01 19 17 20 38 27
- Single-Tone Beep, 9910 23
- Dual-Tone Beep, 9915 05 09
- Single-Tone Page, 9920 0158 80
- 5/6-Tone Page, 9940 1136570
- DTMF Page, 9950 01 02 03
- SELCAL Page, 9955 0158 80
- Two-Tone Sequential Page, 9930 0018 10 0035 30
- Speech, 9960 0000 0001 0002 0003

	Message Control Characters						
	Control Character	Definition	Page				
	97xx	Message Routing characters follow	6-4				
<	9900	CW characters follow	6-13				
	9901	CW Primary characters follow	6-13				
	9902	CW Secondary characters follow	6-13				
	9903	CW Speed Change characters follow	6-15				
	9904	CW Frequency Change characters follow	6-15				
	9905	CW Message Level characters follow	6-14				
<	9910	Single-Tone Beep characters follow	6-21				
	9911	Single-Tone Beep Primary characters follow	6-21				
	9912	Single-Tone Beep Secondary characters follow	6-21				
	9913	Single-Tone Beep Message Level characters follow	6-22				
$\leq$	9915	Dual-Tone Beep characters follow	6-31				
	9916	Dual-Tone Beep Primary characters follow	6-31				
	9917	Dual-Tone Beep Secondary characters follow	6-31				
	9918	Dual-Tone Beep Message Level characters follow	6-32				
	9920	Single-Tone page follows	6.39				
	9930	Two-Tone Sequential page follows	6-40				
(	9940	5/6-Tone page follows	6-42				
	9950	DTMF page follows	6-44				
	9955	SELCAL page follows	0-52				
	9960	Speech characters follow	6-54				
	9961	Speech Primary characters follow	6-54				
	9962	Speech Secondary characters follow	6-54				
	9963	Speech Message Level characters follow	6-55				
	9991	Mixed Audio Allowed	6-6				
	9992	Non-Mixed Audio Only	6-6				
	9993	Pause characters follow	6-7				
	9999	Execute the macro that follows	6-8				


#### **Interruptable Messages**

- Primary Characters replaced by secondary characters when a path is active
  - e.g. Replace Speech by CW
- Applies to these types
  - CW, Single-Tone Beep, Dual-Tone Beep, Speech
- How to read the table
  - CW, 9900 Always Plays
  - CW, 9901, Primary, Interruptable
  - CW, 9902, Secondary, Replaces Primary when active
- Example Message, CW Replaces Speech

**9961** 0067 0045 0001 0054 0052 0055 **9902** 32 10 01 19 17 20 38 27

Example Command, Program Normal Identifier TX1

**99** 31 **0110 9961** 0067 0045 0001 0054 0052 0055 **9902** 32 10 01 19 17 20 38 27 \*

9993

9999

Pause characters follow

Execute the macro that follows

	Message Control Characters							
	Control Character	Definition	Page					
	97xx	Message Routing characters follow	6-4					
	9900	CW characters follow	0-13					
	9901	CW Primary characters follow	6-13					
	9902	CW Secondary characters follow	6-13					
	9903	CW Speed Change characters follow	6-15					
	9904	CW Frequency Change characters follow	6-15					
	9905	CW Message Level characters follow	6-14					
	9910	Single-Tone Beep characters follow	0-21					
$\boldsymbol{\subset}$	9911	Single-Tone Beep Primary characters follow	6-21					
	0912	Single-Tone Beep Secondary characters follow	6-21					
	9913	Single-Tone Beep Message Level characters follow	6-22					
_	3915	Dual-Tone Beep characters follow	0-31					
$\boldsymbol{\mathcal{C}}$	9916	Dual-Tone Beep Primary characters follow	6-31					
	9917	Dual-Tone Beep Secondary characters follow	6-31					
	9918	Dual-Tone Beep Message Level characters follow	6-32					
	9920	Single-Tone page follows	6-38					
	9930	Two-Tone Sequential page follows	6-40					
	9940	5/6-Tone page follows	6-42					
	9950	DTMF page follows	6-44					
	9955	SELCAL page follows	6-52					
	9960	Speech characters follow	6-54					
$\boldsymbol{\mathcal{C}}$	9961	Speech Primary characters follow	6-54	$\mathbf{>}$				
	9962	Speech Secondary characters follow	6.54					
	9963	Speech Message Level characters follow	6-55					
	9991	Mixed Audio Allowed	6-6					
	9992	Non-Mixed Audio Only	6-6					



6-7

6-8

Message Levels

### Programmable

- Set Within a Message
- Default Level Set By Type

Message Type	Default Level
CW Level	12 (-6dB)
Single-Tone Beep Level	12 (-6dB)
Dual-Tone Beep Level	12 (-6dB)
Single-Tone Page Level	06 (-3dB)
Two-Tone Page Level	06 (-3dB)
Five-Six Tone Page Level	06 (-3dB)
DTMF Page Level	06 (-3dB)
SELCAL Page Level	06 (-3dB)
Speech Playback Level	00 (0dB)

Message Levels											
(PW) 10 <message type=""> <level> * (see page 6-10)</level></message>											
Level	Value dB	Level	Value dB	Level	Value dB	Level	Value dB	Level	Value dB		
00	0.0	20	-10.0	40	-20.0	60	-30.0	80	-40.0		
01	-0.5	21	-10.5	41	-20.5	61	-30.5	81	-40.5		
02	-1.0	22	-11.0	42	-21.0	62	-31.0	82	-41.0		
03	-1.5	23	-11.5	43	-21.5	63	-31.5	83	-41.5		
04	-2.0	24	-12.0	44	-22.0	64	-32.0	84	-42.0		
05	-2.5	25	-12.5	45	-22.5	65	-32.5	85	-42.5		
06	-3.0	26	-13.0	46	-23.0	66	-33.0	86	-43.0		
07	-3.5	27	-13.5	47	-23.5	67	-33.5	87	-43.5		
08	-4.0	28	-14.0	48	-24.0	68	-34.0	88	-44.0		
09	-4.5	29	-14.5	49	-24.5	69	-34.5	89	-44.5		
10	-5.0	30	-15.0	50	-25.0	70	-35.0	90	-45.0		
11	-5.5	31	-15.5	51	-25.5	71	-35.5	91	-45.5		
12	-6.0	32	-16.0	52	-26.0	72	-36.0	92	-46.0		
13	-6.5	33	-16.5	53	-26.5	73	-36.5	93	-46.5		
14	-7.0	34	-17.0	54	-27.0	74	-37.0	94	-47.0		
15	-7.5	35	-17.5	55	-27.5	75	-37.5	95	-47.5		
16	-8.0	36	-18.0	56	-28.0	76	-38.0	96	-48.0		
17	-8.5	37	-18.5	57	-28.5	77	-38.5	97	-48.5		
18	-9.0	38	-19.0	58	-29.0	78	-39.0	98	-49.0		
19	-9.5	39	-19.5	59	-29.5	79	-39.5				

### Example, CW Message Lower Than Default 9905 20 9900 32 10 01 19 17 20 38 27



Messages – Routing

### Route a Message to 1 or more Ports

- Route to a Single Port
  - 97 x0
  - Example: Route to port 2
    - 9720 9910 16
- Route to 2 Ports
  - 97 xy
  - Example: Route to ports 1 and 3
    - 9713 9910 16
- Route to 3 Ports
  - 97 xy z0
  - Example: Route to all 3 ports
    - 971230 9910 16
- Remember the rule: always pairs of digits

Message Control Characters								
Control Character	Definition	Page						
97xx	Message Routing characters follow	6-4						
9900	CW characters follow	6-13						
9901	CW Primary characters follow	6-13						
9902	CW Secondary characters follow	6-13						
9903	CW Speed Change characters follow	6-15						
9904	CW Frequency Change characters follow	6-15						
9905	CW Message Level characters follow	6-14						
9910	Single-Tone Beep characters follow	6-21						
9911	Single-Tone Beep Primary characters follow	6-21						
9912	Single-Tone Beep Secondary characters follow	6-21						
9913	Single-Tone Beep Message Level characters follow	6-22						
9915	Dual-Tone Beep characters follow	6-31						
9916	Dual-Tone Beep Primary characters follow	6-31						
9917	Dual-Tone Beep Secondary characters follow	6-31						
9918	Dual-Tone Beep Message Level characters follow	6-32						
9920	Single-Tone page follows	6-38						
9930	Two-Tone Sequential page follows	6-40						
9940	5/6-Tone page follows	6-42						
9950	DTMF page follows	6-44						
9955	SELCAL page follows	6-52						
9960	Speech characters follow	6-54						
9961	Speech Primary characters follow	6-54						
9962	Speech Secondary characters follow	6-54						
9963	Speech Message Level characters follow	6-55						
9991	Mixed Audio Allowed	6-6						
9992	Non-Mixed Audio Only	6-6						
9993	Pause characters follow	6-7						
9999	Execute the macro that follows	6-8						



Messages – Mix/No-Mix

### **Control User Audio Mute During Message**

- Mixed Audio
  - Mix Message With User Audio
  - 9991
    - Example: Speech

9991 9960 3000

- Non-Mixed Audio
  - Do NOT Mix Message With User Audio
  - Normally Used with Paging Tones
  - 9992
    - Example: Single-Tone Page 9992 9920 0158 80
    - Example: DTMF Page 9992 9950 01 02 03

#### **Message Control Characters**

	Control Character	Definition	Page
	97xx	Message Routing characters follow	6-4
	9900	CW characters follow	6-13
	9901	CW Primary characters follow	6-13
	9902	CW Secondary characters follow	6-13
Α	9903	CW Speed Change characters follow	6-15
	9904	CW Frequency Change characters follow	6-15
	9905	CW Message Level characters follow	6-14
	9910	Single-Tone Beep characters follow	6-21
	9911	Single-Tone Beep Primary characters follow	6-21
	9912	Single-Tone Beep Secondary characters follow	6-21
	9913	Single-Tone Beep Message Level characters follow	6-22
	9915	Dual-Tone Beep characters follow	6-31
	9916	Dual-Tone Beep Primary characters follow	6-31
	9917	Dual-Tone Beep Secondary characters follow	6-31
	9918	Dual-Tone Beep Message Level characters follow	6-32
	9920	Single-Tone page follows	6-38
	9930	Two-Tone Sequential page follows	6-40
	9940	5/6-Tone page follows	6-42
	9950	DTMF page follows	6-44
	9955	SELCAL page follows	6-52
	9960	Speech characters follow	6-54
	9961	Speech Primary characters follow	6-54
	9962	Speech Secondary characters follow	6-54
	9963	Speech Message Level characters follow	6-55
-	9991	Mixed Audio Allowed	0-0
	9992	Non-Mixed Audio Only	6-6
	9993	Pause characters follow	6-7
	9999	Execute the macro that follows	6-8



Messages – Pause

### Pause Within A Message

- 0.1 Second Steps 0.1 thru 9.9 Seconds
  9993xx
- Pause Before A Message
  - Example: Pause 1.2 Seconds Before Message
    - 999312 9910 16
- Pause Within A Message
  - Example: Pause 0.8 Seconds Within A Message
    - 9910 16 **999308** 9910 16
- Pause After A Message
  - Example: Pause 2.0 Seconds After A Message
    - 9910 16 999320
- Remember the rule: always pairs of digits

#### Message Control Characters

	Control Character	Definition	Page
	97xx	Message Routing characters follow	6-4
	9900	CW characters follow	6-13
	9901	CW Primary characters follow	6-13
	9902	CW Secondary characters follow	6-13
	9903	CW Speed Change characters follow	6-15
	9904	CW Frequency Change characters follow	6-15
	9905	CW Message Level characters follow	6-14
	9910	Single-Tone Beep characters follow	6-21
	9911	Single-Tone Beep Primary characters follow	6-21
	9912	Single-Tone Beep Secondary characters follow	6-21
	9913	Single-Tone Beep Message Level characters follow	6-22
	9915	Dual-Tone Beep characters follow	6-31
	9916	Dual-Tone Beep Primary characters follow	6-31
	9917	Dual-Tone Beep Secondary characters follow	6-31
	9918	Dual-Tone Beep Message Level characters follow	6-32
	9920	Single-Tone page follows	6-38
	9930	Two-Tone Sequential page follows	6-40
	9940	5/6-Tone page follows	6-42
	9950	DTMF page follows	6-44
	9955	SELCAL page follows	6-52
	9960	Speech characters follow	6-54
	9961	Speech Primary characters follow	6-54
	9962	Speech Secondary characters follow	6-54
	9963	Speech Message Level characters follow	6-55
	9991	Mixed Audio Allowed	6-6
	9992	Non-Mixed Audio Only	6-6
<	9993	Pause characters follow	6-7
	9999	Execute the macro that follows	6-8



Messages -- CW

### **CW Messages**

- Starts With Type
  - 9900
- Followed By Pairs Of Digits
  - Each digit-pair is a CW Character
- Always and Interruptable Versions
- Full CW Character Set
- In-Message Parameter Changes
  - Frequency Change
  - Speed Change
- Commands to set default Frequency and Speed

9900 32 10 01 19 17 20 38 27

Sends in CW:

WA1JHK/R

	0	Conv	right	2017	SCOM	
150		COPY	nyni	2017,	300IVI,	LLU

Control Character 9900/9901/9902								
Character	Code	Character	Code	Character	Symbol	Code		
0	00	1	18	Period	-	36		
1	01	J	19	Comma	,	37		
2	02	к	20	Fraction	1	38		
3	03	L	21	Question	?	39		
4	04	M	22	Word space		40		
5	05	N	23	End-of-message	(AR)	41		
6	06	0	24	Wait	(AS)	42		
7	07	Р	25	Break	(BK)	43		
8	08	a	26	Double dash	(BT)	44		
9	09	R	27	End-of-work	(SK)	45		
A	10	s	28	Hyphen	-	46		
В	11	т	29	Colon	1	47		
С	12	U	30	Semicolon	-	48		
D	13	V	31	Parenthesis	()	49		
E	14	W	32	Apostrophe	,	50		
F	15	Х	33	Exclamation	1	51		
G	16	Y	34	Quotation	10	52		
Н	17	Z	35	Understood	(SN)	53		
				At-symbol	@	54		



Messages – Custom Tones

### **Custom Tone Frequencies**

- Sample Table to the right
  - Entire table too large to add here
- Tone Code from table is used in commands
- 5 Hz steps from 260 Hz to 3000 Hz
- Easy to calculate
  - ToneCode = (Freq 260) / 5

Tone Code Table										
Freq	Code	Freq	Code	Freq	Code	Freq	Code	Free		
260	0000	460	0040	660	0080	860	0120	106		
265	0001	465	0041	665	0081	865	0121	106		
270	0002	470	0042	670	0082	870	0122	107		
275	0003	475	0043	675	0083	875	0123	107		
280	0004	480	0044	680	0084	880	0124	108		
285	0005	485	0045	685	0085	885	0125	108		
290	0006	490	0046	690	0086	890	0126	109		
295	0007	495	0047	695	0087	895	0127	109		
300	0008	500	0048	700	0088	900	0128	110		
305	0009	505	0049	705	0089	905	0129	110		
310	0010	510	0050	710	0090	910	0130	111		
315	0011	515	0051	715	0091	915	0131	111		
320	0012	520	0052	720	0092	920	0132	112		
325	0013	525	0053	725	0093	925	0133	112		
330	0014	530	0054	730	0094	930	0134	113		
335	0015	535	0055	735	0095	935	0135	113		
340	0016	540	0056	740	0096	940	0136	114		
345	0017	545	0057	745	0097	945	0137	114		
350	0018	550	0058	750	0098	950	0138	115		
355	0019	555	0059	755	0099	955	0139	115		
360	0020	560	0060	760	0100	960	0140	116		
365	0021	565	0061	765	0101	965	0141	116		
370	0022	570	0062	770	0102	970	0142	117		
375	0023	575	0063	775	0103	975	0143	117		
380	0024	580	0064	780	0104	980	0144	118		
385	0025	585	0065	785	0105	985	0145	118		
390	0026	590	0066	790	0106	990	0146	119		
395	0027	595	0067	795	0107	995	0147	119		
400	0028	600	0068	800	0108	1000	0148	120		



Messages – Pre-defined Beeps

### **Factory Fixed Frequency Beeps**

• Standard Tones Defined In Two Digits

### **Owner Fixed Frequency Beeps**

- Standard Tones Defined In Two Digits
- Used In Beep Messages
- Example: Single-Tone Beeps
  - C3 C4 C5

9910 00 12 24

	Factory-Fixed Frequency Beeps											
	Control Character 9910/9901/9902											
Freq (Hz)	Note	Beep	Freq (Hz)	Note	Beep	Freq (Hz)	Note	Beep				
262	C3	00	659	E4	16	1661	G#5	32				
277	C#3	01	698	F4	17	1760	A5	33				
294	D3	02	740	F#4	18	1865	A#5	34				
311	D#3	03	784	G4	19	1976	B5	35				
330	E3	04	831	G#4	20	2093	C6	36				
349	F3	05	880	A4	21	2217	C#6	37				
370	F#3	06	932	A#4	22	2349	D6	38				
392	G3	07	988	B4	23	2489	D#6	39				
415	G#3	08	1046	C5	24	2637	E6	40				
440	A3	09	1109	C#5	25	2794	F6	41				
466	A#3	10	1175	D5	26	2960	F#6	42				
494	B3	11	1244	D#5	27	3136	G6	43				
523	C4	12	1319	E5	28	3322	G#6	44				
554	C#4	13	1397	F5	29	3520	A6	45				
587	D4	14	1480	F#5	30	3729	A#6	46				
622	D#4	15	1568	G5	31	3951	B6	47				

### Owner-Fixed Frequency Single-Tone Beeps Control Character 9910/9911/9912 Beep Code Frequency (Fill In) Default (Hz) 48 500 49 750

48	500
49	750
50	1000
51	1250
52	1500
53	1750



Messages – Single-Tone Beep

#### Single-Tone Beep Messages

- Always and Interruptable versions
- Standard and Custom Tone, Gap and Durations
- Commands to set Default Gap and Durations
- Default and Custom Message Level
- Example:
  - 350 Hz, Default Gap, 440 Hz at Default Durations

9915 05 09

Single-Tone Beep Parameters (General)						
Control Character 9910/9911/99	12					
Beep Parameter	Code					
Custom Single-Tone Beep	57xxxxyy					
Custom Single-Tone Beep delay	58xx					
Automatic beep gap OFF	55					
Automatic beep gap ON	56					

Single-Tone Beep Gap Change Characters							
Control Character	8810/8811/8812						
Beep Gap (ms)	Code						
10	60						
20	61						
30	62						
40	63						
60	64						
80	65						
120	66						
160	67						
240	68						
320	69						

#### Single-Tone Beep Duration Change Characters

Control Character 9910/9911/9912						
Beep Duration (ms)	Code					
10	70					
20	71					
30	72					
40	73					
60	74					
80	75					
120	76					
160	77					
240	78					
320	79					

SICO



Messages – Dual-Tone Beep

#### **Dual-Tone Beep Messages**

- Always and Interruptable versions
- Standard and Custom Tone, Gap and Durations
- Commands to set Default Gap and Durations
- Default and Custom Message Level
- Example:
  - 320 mS of simultaneous 350 Hz/440 Hz
     9915 79 05 09

Dual-Tone Beep Parameters						
Control Character 9915/9916/9917						
Beep Parameter Code						
custom dual-tone beep	57xxxxyyyyzz					
custom beep delay	58xx					
automatic beep gap OFF	55					
automatic beep gap ON	56					

Dual-Tone Beep Gap Change Characters							
Control Characte	9915/9916/9917						
Beep Gap (ms)	Code						
10	60						
20	61						
30	62						
40	63						
60	64						
80	65						
120	66						
160	67						
240 68							
320	69						

#### Dual-Tone Beep Duration Change Characters

Control Character 9915/9916/9917						
Beep Duration (ms)	Code					
10	70					
20	71					
30	72					
40	73					
60	74					
80	75					
120	76					
160	77					
240	78					
320	79					



Messages -- Speech

#### **Speech Messages**

- Always and Interruptable versions
- Standard Library, English
  - ~1600 Words
- Custom Library
  - User-Built Library
  - Up to 2000 "Words"
  - Up to 13 Minutes divided up any way you want
    - Could define 1 "Word" 13 minutes long
    - Could define 2000 individual words
    - 7K Speech Synthesizer words available as a custom library
- Default and Custom Message Level

Speech Message Level Change					
Change	Code				
Message Level	9963xx (xx = Msg Level)				

Speech Intra-Message Delay						
Delay	Code	Data Digits				
Speech Intra-Message Delay (10-990mS)	70xx	00-99 x 10mS				
Speech Intra-Message Delay (100-9900mS)	71xx	00-99 x 100mS				

• Example: Speak "WA1JHK"

9960 0067 0045 0001 0054 0052 0055



### Messages -- Vocabulary

Numbers								
Word	Code	Word	Code	Word	Code	Word	Code	
zero	0000	sixth	0012	twelve	0023	twentieth	0034	
one	0001	seven	0013	twelfth	0024	thirty	0035	
first	0002	seventh	0014	thirteen	0025	forty	0036	
two	0003	eight	0015	fourteen	0026	fifty	0037	
second	0004	eighth	0016	fifteen	0027	sixty	0038	
three	0005	nine	0017	sixteen	0028	seventy	0039	
third	0006	niner	0018	sixteenth	0029	eighty	0040	
four	0007	ninth	0019	seventeen	0030	ninety	0041	
fourth	0008	ten	0020	eighteen	0031	hundred	0042	
five	0009	tenth	0021	nineteen	0032	thousand	0043	
fifth	0010	eleven	0022	twenty	0033	million	0044	
six	0011							

Calendar							
Word	Code	Word	Code	Word	Code	Word	Code
January	0071	Sunday	0083	day	0096	today	0109
February	0072	Monday	0084	days	0097	tomorrow	0110
March	0073	Tuesday	0085	hour	0098	tonight	0111
April	0074	Wednesday	0086	hours	0099	yesterday	0112
May	0075	Thursday	0087	minute	0100	weekday	0113
June	0076	Friday	0088	minutes	0101	weekend	0114
July	0077	Saturday	0089	second	0102	weekly	0115
August	0078	date	0090	seconds	0103	AM	0116
September	0079	time	0091	week	0104	PM	0117
October	0080	year	0092	morning	0105	noon	0118
November	0081	yearly	0093	afternoon	0106	oclock	0119
December	0082	month	0094	evening	0107	zulu	0120
		monthly	0095	night	0108		

All Words Alphabetic Listing							
Word	Code	Word	Code	Word	Code	Word	Code
Α	0045	alert	0205	Arizona	0448	band	0223
abeam	0386	all	0206	Arkansas	0449	Bangor	0480
Abington	0388	Allenton	0421	armed	0450	bank	0481
Able	0387	Allentown	0422	army	0451	Barbara	0482
able	0389	aloft	0423	arrival	0452	barometric	0483
abnormal	0390	alpha	0424	as	0215	bars	0484
abort	0391	alternate	0425	ask	0217	base	0224
about	0392	altimeter	0426	Aspen	0453	bath	0485
above	0393	altitude	0427	assign	0454	Baton Rouge	0486
accelerate	0394	always	0428	assistance	0455	battery	0225
accelerated	0395	AM	0116	association	0218	baud	0487
access	0396	amateur	0207	astro	0456	Bavarian	0488
acknowledge	0397	amateurs	0208	at	0219	hav	0489

Letters								
Word	Code Word Code Word Code Wo						Code	
A	0045	Н	0052	0	0059	U	0065	
В	0046	1	0053	Р	0060	V	0066	
С	0047	J	0054	Q	0061	W	0067	
D	0048	К	0055	R	0062	Х	0068	
E	0049	L	0056	S	0063	Υ	0069	
F	0050	М	0057	Т	0064	Z	0070	
G	0051	N	0058					

Measurements							
Word Code Word Code Word Code Word Code							
feet	0121	micro	0129	point	0137	Hertz	0145
meter	0122	milli	0130	Amps	0138	ohm	0146
meters	0123	kilo	0131	byte	0139	percent	0147
inch	0124	mega	0132	Celsius	0140	power	0148
mile	0125	minus	0133	current	0141	voltage	0149
miles	0126	plus	0134	degree	0142	volts	0150
pico	0127	decimal	0135	degrees	0143	watt	0151
nano	0128	dot	0136	Farenheit	0144	watts	0152



Messages – Paging

### Single-Tone Page Messages

- Always version only, never interruptable
- Custom Tones and Duration
- Default and Custom Inter-Page Delay
- Default and Custom Message Level

#### **Two-Tone Sequential Page Messages**

- Always version only, never interruptable
- Custom Tones and Duration
- Default and Custom Inter-Page Delay
- Default and Custom Message Level

#### 5/6-Tone Page Messages

- Always version only, never interruptable
- Default and Custom Inter-Page Delay
- Default and Custom Message Level

#### Message Control Characters

	Control Character	r Definition		
	97xx	Message Routing characters follow	6-4	
	9900	CW characters follow	6-13	
	9901	CW Primary characters follow	6-13	
	9902	CW Secondary characters follow	6-13	
	9903	CW Speed Change characters follow	6-15	
	9904	CW Frequency Change characters follow	6-15	
	9905	CW Message Level characters follow	6-14	
	9910	Single-Tone Beep characters follow	6-21	
	9911	Single-Tone Beep Primary characters follow	6-21	
	9912	Single-Tone Beep Secondary characters follow	6-21	
	9913	Single-Tone Beep Message Level characters follow	6-22	
	9915	Dual-Tone Beep characters follow	6-31	
	9916	Dual-Tone Beep Primary characters follow	6-31	
	9917	Dual-Tone Beep Secondary characters follow	6-31	
	9918	Dual-Tone Beep Message Level characters follow	6-32	
<	9920	Single-Tone page follows	6-38	
<	9930	Two-Tone Sequential page follows	6-40	
<	9940	5/6-Tone page follows	6-42	
	9950	DTMF page follows	6-44	
	9955	SELCAL page follows	6-52	
	9960	Speech characters follow	6-54	
	9961	Speech Primary characters follow	6-54	
	9962	Speech Secondary characters follow	6-54	
	9963	9963 Speech Message Level characters follow		
	9991	9991 Mixed Audio Allowed		
	9992	Non-Mixed Audio Only	6-6	
	9993	Pause characters follow	6-7	
	9999	Execute the macro that follows	6-8	



### Messages – Run-Time Variables

### Speech or CW of Controller Variables

- Clock and Calendar Data
  - Hour and Minute
    - 12- and 24-Hour Time Format
    - AM/PM
    - "morning", "afternoon", "evening"
  - Day of Week
  - Day of Month
    - Cardinal or Ordinal
  - Month
  - Seconds
    - Useful for testing clock accuracy
- Software Version

### Coming Soon!

- Analog Input Readings
- Readback of many datatypes

#### Message Run-Time Variables

Run- Time Variable	Meaning	Format	Example
9810	Hour & Minute, 12-hr format	CW	2 45
9811	AM/PM	CW	PM
9812	Hour & Minute, 24-hr format	CW	14 45
9813	Day of Week	CW	WED
9814	Month	CW	JAN
9815	Day of Month	CW	1
9816	Seconds	CW	27 in CW
9820	Hour & Minute, 12-hr format	Speech	Two forty-five
9821	AM/PM	Speech	PM
9824	Hour & Minute, 24-hr format	Speech	14 hours, 45 minutes
9825	same as 9824 without "hours" & "minutes"	Speech	Fourteen forty-five
9826	Day of Week	Speech	Wednesday
9827	Cardinal Day-of-Month	Speech	One
9828	Ordinal Day-of-Month	Speech	First
9829	Month	Speech	January
9831	"morning, afternoon. evening"	Speech	Afternoon
9832	Seconds	Speech	Twenty-seven
9896	Call Count	CW	105
9897	Call Count	Speech	One zero five
9898	Software Version	CW	300
9899	Software Version	Speech	Three point zero zero

Note: Call Count is a leftover Autopatch variable that always reads zero.



### **Receiver Timing**

### **COR/CTCSS** Delay

- Programmable timers that filter narrow pulses on the COR and CTCSS logic inputs.
  - Disabled by default.
- Reduces nuisance repeater key-ups due to noise.

### **Flutter Filter**

- The opposite of the COR/CTCSS Delay.
- Programmable timer that filters narrow dropouts of weak signals.
  - Default is Disabled.
- Reduces the effects of "picket fencing".
- Holds the audio path open to reduce audio dropouts.
- Minimizes Courtesy Beeps on weak

### **Anti-Kerchunk Filter**

- COR filter that removes brief user "kerchunks".
  - (NOBODY does THAT!)
  - Default is Disabled.
- *Key-up Delay* specifies minimum keyup time.
  - Default is 1.00 second.
- *Re-Arm Delay* specifies repeater idle time before the filter is re-armed.
  - Default is 60 seconds.
- No-Hangtime Mode keys the repeater during the Key-Up Delay time, but eliminates the tail if unkey occurs before the delay time.



#### Macros

### What's a Macro?

- A *Macro* is a list of controller commands or other macros that are executed in sequence.
- A *Macro* is assigned a unique name that is specified to cause execution of the sequence.
- Each macro is up to 200 digits long.
- Default is no macros defined.
- Directory and storage support 340 macros.
- Names are 1, 2, 3, or 4 DTMF digits.
  - DTMF digits 0 thru 9 and A thru D.
  - \* and # cannot be used.
  - Examples:

```
1*
40B*
789*
160 © Copyright 2017, SCOM, LLC
```

### What are they good for?

- Speak the Date and Time
- Generate DTMF Pages
- Change which ports are linked
- Reset a Path Timeout Timer
- Speak a message when a Logic Input changes state.
- Perform custom timing sequences.
- Implement Rotating Identifier Messages
- Implement a Grandfather Clock
- Implement Top-of-the-Hour Meeting Announcements



#### Macros

#### **Create Macro**

- Command to allocate storage, define the name used to execute the macro, and store the first command.
  - Added command must be valid.
  - Name must be unique.
  - Ex. 99 20 1234 99 63 0141 1 \*

### **Append To Macro**

- Command to append additional commands to existing macro storage that will be executed in sequence.
  - Ex. 99 29 1234 99 63 0142 1 \*

#### **Execute Macro**

- Type the name of the macro to execute
  - Ex. 1234 \*

#### **Command Examples**

```
7330>99 20 1234 99 63 0141 1 *
OK
7330>99 20 1234 99 15 12 23 15 *
Error: Macro name already exists
7330>99 29 4321 99 34 0110 *
Error: Macro name not found
7330>99 29 1234 99 34 0110 *
OK
7330>1234*
OK
7330>
```



**Event-Triggered Macros** 

### Allow Controller Events To Trigger Macros

- Assign Macro commands to configure the macro name to be executed at an event
- Many, many events defined
  - Power-On Reset is commonly used.
  - Logic Inputs useful for alarm inputs.
  - PTT Active-to-Inactive used for Fan control.
- Ex. Set Power-On Reset Macro to 1234.
   99 26 0000 1234 \*

#### Command Form:

Command	Form
Assign Macro to Any-Path-Active to TX1	(PW) 26 0102 (macro name) *
Assign Macro to All-Paths-Inactive to TX1	(PW) 26 0103 (macro name) *
Assign Macro to Any-Path-Active to TX2	(PW) 26 0202 (macro name) *
Assign Macro to All-Paths-Inactive to TX2	(PW) 26 0203 (macro name) *

	General Event Macros					
Number Page Description						
0000	5-28	Power-On Reset Macro				
0001	5-31	Battery Good-to-Not-Good Macro				
0061	14-2	Logic Input 1 Hi-to-Lo Macro				
0062	14-2	Logic Input 1 Lo-to-Hi Macro				
0063	14-2	Logic Input 2 Hi-to-Lo Macro				

Port-Specific Event Macros Replace the "r" with the Receiver/DTMF Decoder Number Replace the "t" with the Transmitter Number						
Number	Page	Description				
0r00	7-31	DTMF Decoder Any Long Tone Macro				
0r01	7-25	DTMF Decoder Digit-Decoded Macro				
0t02	11-30	Any-Path-Active To TX Macro				
0t03	11-30	All-Paths-Inactive To TX Macro				
0t04	11-15	TX Dropout Macro				
0t05	11-19	PTT Inactive-to-Active Macro				
0t06	11-19	PTT Active-to-Inactive Before Unkey Delay Macro				
0t07	11-19	PTT Active-to-Inactive After Unkey Delay Macro				
0t08	12-7	Initial ID Macro				
0t09	12-7	Polite ID Macro				
0t10	12-7	Impolite ID Macro				
0t11	13-9	CTCSS Encoder Inactive-to-Active Macro				
0t12	13-9	CTCSS Encoder Active-to-Inactive Macro				
0t13	11-16	TX Start-of-Activity Macro				
0t14	11-16	TX End-of-Activity Macro				
0r15	10-19	COR Input Hi-to-Lo Macro				
0r16	10-19	COR Input Lo-to-Hi Macro				
0r17	10-20	CTCSS Input Hi-to-Lo Macro				
0r18	10-20	CTCSS Input Lo-to-Hi Macro				



### **CTCSS** Encoder

### **CTCSS Encoder**

163 © Copyrig

- Control internal or external CTCSS Encoder
- Internal CTCSS Encoder Hardware
  - Select from 65 subaudible tones
  - Select Mode for when tone is enabled.
  - Select Reverse Burst Option.

Modes:	
Mode	Meaning
0	OFF
1	Follows transmitter PTT, but tums OFF before the Minimum Unkey Delay period
2	Follows transmitter PTT
3	Turns ON when transmitter PTT is keyed and OFF at the end of the CTCSS ON Time (ON time is programmable)
4	Turns ON when Any Path is Active to a selected transmitter, then a timer starts when All Paths are Inactive to that transmitter. When the timer expires the encoder is turned OFF (ON time is programmable).
5	Always ON
Reverse	e Burst Options:
Mode	Meaning
0	OFF
1	120-degree Reverse Burst
2017 <b>2</b>	180-degree Reverse Burst

	CTCSS Tone Numbers					
	Tone #	Freq Hz	EIA Code	Tone #	Freq Hz	EIA Code
	0	33.0	•	32	123.0	3Z
	1	35.4	•	33	127.3	3A
	2	36.6	•	34	131.8	3B
	3	37.9	•	35	136.5	4Z
	4	39.6	•	36	141.3	4A
	5	44.4	•	37	146.2	4B
	6	47.5	•	38	151.4	5Z
	7	49.2	•	39	156.7	5A
	8	51.2	•	40	159.8	•
	9	53.0	•	41	162.2	5B
	10	54.9	•	42	165.5	•
	11	56.8	•	43	167.9	6Z
	12	58.8	•	44	171.3	•
	13	63.0	•	45	173.8	6A
	14	67.0	XZ	46	177.3	•
	15	69.4	•	47	179.9	6B
	16	71.9	XA	48	183.5	•
	17	74.4	WA	49	186.2	7Z
	18	77.0	XB	50	189.9	•
	19	79.7	SP	51	192.8	7A
	20	82.5	YZ	52	196.6	•
	21	85.4	YA	53	199.5	•
	22	88.5	YB	54	203.5	M1
	23	91.5	ZZ	55	206.5	8Z
	24	94.8	ZA	56	210.7	M2
	25	97.4	ZB	57	218.1	M3
	26	100.0	1Z		225.7	M4
	27	103.5	1A	59	229.1	9Z
	28	107.2	1B	60	233.6	M5
	29	110.9	2Z	61	241.8	M6
	30	114.8	2A	62	250.3	M7
	31	118.8	2B	63	254.1	0Z
				64	150.0	•
* = not a standard code 150.0 Hz Used by U.S. Military						



### **CTCSS** Encoder

### "Chicken Burst"

- Problem
  - Most amateur radios don't respond to Reverse Burst.
  - Turning the CTCSS Encoder off before Tx unkeys eliminates unkey squelch burst in user radio.
  - Use Tx PTT Minimum Unkey Delay to implement "Chicken Burst"
  - Works with all radios.

### Example

- Setup internal encoder
  - Enable encoder on Tx1
  - 100.0 Hz
  - On whenever Tx is keyed
  - Reverse Burst 180-Degree
  - Support for "Chicken Burst"
  - 99 02 1 1 2 \* ; set Tx1 mode, and reverse burst
  - 99 03 1 26 \* ; set Tx1 frequency
  - 99 09 0102 75 \* ; set Tx1 Unkey Delay 750 mS

Scheduler Setpoints

### **Schedule Events Based On Time and Date**

- Execute a macro based on combinations of month, day, day-of-week, hour, minute.
- Accepts wildcards to program recurring events
- Day Codes support special day matching
- Clock/Calendar provides accurate date/time
- Event stored in a Setpoint
  - e.g. 2nd Tuesday of the month
  - Ex., Speak Grandfather Clock macro 1234 every month, every day, every hour on the hour.
  - Macro speaks time.
    - 99 28 00 1234 99 99 99 00 \* 99 20 1234 99 15 9824 \*

Scheduler Day Code Table						
Day Code	Explanation	Day Code	Explanation			
01-31	calendar day-of-month	58	3rd Wednesday of month			
32	weekdays (Mon-Fri)	59	3rd Thursday of month			
33	weekends (Sat-Sun)	60	3rd Friday of month			
34	Sundays	61	3rd Saturday of month			
35	Mondays	62	4th Sunday of month			
36	luesdays	63	4th Monday of month			
37	Wednesdays	64	4th Tuesday of month			
38	Thursdays	65	4th Wednesday of month			
39	Fridays	66	4th Thursday of month			
40	Saturdays	67	4th Friday of month			
41	1st Sunday of month	68	4th Saturday of month			
42	1st Monday of month	69	5th Sunday of month			
43	1st luesday of month	70	5th Monday of month			
44	1st Wednesday of month	11	5th luesday of month			
45	1st Thursday of month	72	5th Wednesday of month			
46	1st Friday of month	73	5th Thursday of month			
4/	1st Saturday of month	74	5th Friday of month			
48	2nd Sunday of month	75	5th Saturday of month			
49	2nd Monday of month	76	Last Sunday of month			
50	2nd Tuesday of month	11	Last Monday of month			
51	2nd Wednesday of month	78	Last luesday of month			
52	2nd Thursday of month	79	Last Wednesday of month			
53	2nd Friday of month	80	Last Thursday of month			
54	2nd Saturday of month	81	Last Friday of month			
55	3rd Sunday of month	82	Last Saturday of month			
56	3rd Monday of month	99	every day (wild card)			
5/	3rd Tuesday of month					

#### Command Eorm Data Digit Create setpoint (PW) 28 (setpoint number, macro, month, day, hour, minute) \* from table below.



# Agenda

#### Introduction

• Who is S-COM?

#### **The Basics**

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 166 CTresting Youn Results

#### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

#### File Management

Introducing SBOOT

#### **PC-Based Utilities**

• S-COM Custom Audio Utility

#### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



Introducing SBOOT

#### The SBOOT Menu

- Manage your controller files
  - Set the Clock/Calendar
  - Update Firmware
  - Load Speech Libraries
  - Save/Restore Controller Configuration
  - Configure the Serial Ports

SCOM 7330 SBOOT V1.4

7330 Controller Storage Management

T - Show Time Tmmddyyhhmmssw - Set Date and Time (w=0=Sunday)

- S Save Controller Configuration
- R Restore Controller Configuration
- E Erase Files
- L Load File from a PC to Flash
- U Upload File from Flash to a PC
- D Display Flash Directory
- P Set Baudrate of Console Port
- N Set Baudrate of Auxiliary Port
- W Set Console Port Number

B - Boot from Flash
X - Reboot SBOOT from Flash
H - Help

Time : 022114-222720-5 Battery: OK. SBOOT>





Introducing SBOOT

#### **Flash Directory**

- Displays Controller Information
- Display Filenames and Versions
  - Firmware Files
  - Configuration Files
  - Speech Files

Controller Information

Model Number : 7330 Serial Number : Proto1 Manufactured DT: 120113-124104-0 Formatted DT : 120113-123940-0 Customer Name : Dave's Proto

#### Firmware Files

Location	Name	Version	Date	Туре
SYSTEM SBOOT	BootROM 7330 SBoot	1.2.0	1/27/2014	Program
MFG DIAG	No File No File	1.0.1	_, _ ,	
SCOM_A SCOM_B	7330 No File	3.3.4	1/27/2014	Program

#### Configuration Files

]	Location	Name	Version	Date	Туре
	CONFIG_A CONFIG_B CONFIG_C CONFIG_D	W5JR140131 No File No File No File		1/31/14 09:27	Configuration
Spe 1	ech Files Location	Name	Version	Date	Туре

LIB	SCOM Sp Lib Eng	1.2.0	5/8/2011	Speech Library
CUSTOM	No File			



Introducing SBOOT

#### **Erase Files**

- Prepare for a firmware update
- Free configuration space

Erase a File from Flash:

Location Description 0 - SBOOT -- File Management Utility 1 - DIAG -- Diagnostics 2 - SCOM\_A -- 7330 Repeater Controller 3 - LIB -- Speech Library 4 - CUSTOM -- Custom Audio Library 5 - CONFIG\_A -- Configuration A 6 - CONFIG\_B -- Configuration B 7 - CONFIG\_C -- Configuration C 8 - CONFIG\_D -- Configuration D Q - Return to Main Menu H - Redisplay these options

Enter File Erase Option>

Load a File to Flash from a PC:

Location	Description
0 - SBOOT	File Management Utility
1 - DIAG	Diagnostics
2 - SCOM_A	7330 Repeater Controller
3 - LIB	Speech Library
4 - CUSTOM	Custom Audio Library
5 - CONFIG_A	Configuration A
6 - CONFIG_E	Configuration B
7 - CONFIG	Configuration C
8 - CONFIG	Configuration D
Q - Return t	o Main Menu
H - Redispla	y these options

Enter File Load Option>

#### Load File from a PC to Flash

- Update Firmware
- Load a Custom Audio Library
- Load a Configuration File



### Introducing SBOOT

#### **Save Controller Configuration**

• Save the current controller configuration

#### **Restore Controller Configuration**

 Restore the current controller configuration

#### **Upload File to a PC from Flash**

• Upoad a Configuration File for storage or cloning.

Location Description 5 - CONFIG\_A -- Configuration A 6 - CONFIG\_B -- Configuration B 7 - CONFIG\_C -- Configuration C 8 - CONFIG\_D -- Configuration D Q - Return to Main Menu H - Redisplay these options

Enter File Erase Option>

Restore a Controller Configuration from a Flash File:

Location Description 5 - CONFIG\_A -- Configuration A 6 - CONFIG\_B -- Configuration B 7 - CONFIG\_C -- Configuration C 8 - CONFIG\_D -- Configuration D Q - Return to Main Menu H - Redisplay these options

Enter File Erase Option>

Upload a File to a PC from Flash:

Location Description
0 - SBOOT File Management Utility
1 - DIAG Diagnostics
2 - SCOM_A 7330 Repeater Controller
3 - LIB Speech Library
4 - CUSTOM Custom Audio Library
5 - CONFIG_A Configuration A
6 - CONFIG_B Configuration B
7 - CONFIG_C Configuration C
8 - CONFIG_D Configuration D
Q - Return to Main Menu
H - Redisplay these options

Enter File Load Option>

# Agenda

#### Introduction

• Who is S-COM?

#### The Basics

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 171 CTresting YouMResults

#### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

#### File Management

Introducing SBOOT

#### **PC-Based Utilities**

- S-COM Custom Audio Utility
- **Other Controller Topics**
- Digital Linking: IRLP, EchoLink, Allstar



### **PC-Based Utilities**

#### **Custom Audio**

#### Add .wav Files to your Controller

- Use a program like Audacity or SoX to record or prepare custom audio.
- S-COM provides a utility to prepare the file for download to the controller.
- Your audio becomes "Words" in the controller that you can play just like the built-in vocabulary.
- Add up to 2000 new "Words" to the controller.
- Divide up 13 minutes of storage into as many or as few "Words" as you need.





### **PC-Based Utilities**

**Custom Audio Library** 

#### **Build a Custom Audio Library**

 Assembles the converted .wav files into the format managed by the controller.

```
S-COM Build Speech Lib Utility, V1.0.0
Copyright S-COM, LLC. www.scomcontrollers.com All rights reserved, 2009
Pass 1: Create file list...Done
Number Files referenced in input file=12
Pass 2: getImageSize from all files...Done
Number of Bytes to Store Word Data=130116 (0x1FC44, Does not include
index and fileheader)
Number of SpeechLib Index Entries Required=3012 (0xBC4)
Pass 3: Build headers and Speech Library file...
Total File Size = 0x22E44
Flash Sectors Required to Store This File = 3 (0x3)...Done
[more...]
```



# Agenda

#### Introduction

• Who is S-COM?

#### **The Basics**

- Repeater Building Blocks
- What does a controller need to do?
- Common Terms
- Introducing the 7330

#### Wiring It Up

- Connectors, Jumpers, Pots
- Power
- Input Logic Signals
- Output Logic Signals
- Audio
- A-to-D Input Signals
- CTCSS Encoder

#### **Basic Programming**

- Testing on the Bench
- Initializing the Controller
- S-COM Command Formats
- Security
- Data Types
- Introduction to the Manual
- Getting Started with Programming Commands
- 174 CTESTING YOUM RESults

#### Advanced Programming

- Ports and Paths
- More About Messages
- Receiver Timing
- Macros
- CTCSS Encoder
- Scheduler

#### **File Management**

• Introducing SBOOT

#### **PC-Based Utilities**

• S-COM Custom Audio Utility

#### **Other Controller Topics**

• Digital Linking: IRLP, EchoLink, Allstar



# **Other Controller Topics**

**Future Topics** 

### **Digital Linking**

- Standards are a wonderful thing, everybody needs to have one.
  - IRLP
  - EchoLink
  - Allstar/APP\_RPT
  - DMR
  - D-STAR
  - C4FM

### **Other Controller Functions**

- Remote Base
- Autopatch







### References

http://www.scomcontrollers.com http://www.repeater-builder.com/rbtip/ http://www.repeater-builder.com/tech-info/ctcss/ctcss-overview.html



Port Resources

- Receiver
  - Audio
  - COR
  - CTCSS Decode
- Transmitter
  - Audio
  - PTT
  - CTCSS Encode
    - Audio OR
    - Logic







© Copyright 2014, SCOM, LLC

